



# WP8360 Installation Guide V20.2

## Table of Contents

V20.2 UPDATES .....	3	4.5.1 General guidance – Control panel flow-chart & menu options .....	29
<b>1. Introduction</b> .....	<b>6</b>	4.5.2 Configuring arming/disarming and exit/entry procedures .....	30
<b>1.1 System Features</b> .....	<b>6</b>	4.5.3 Configuring zones .....	31
<b>2. Choosing the installation location</b> .....	<b>9</b>	4.5.4 Configuring alarms and troubles .....	32
<b>3. Installation</b> .....	<b>10</b>	4.5.5 Configuring siren functionality.....	33
<b>3.1 LED indicators and connections</b> .....	<b>10</b>	4.5.6 Configuring audible and visual user interface .....	33
<b>3.2 Inserting the Battery</b> .....	<b>11</b>	4.5.7 Configuring jamming and supervision (missing device).....	34
<b>3.3 WP8360 connections</b> .....	<b>12</b>	4.5.8 Configuring miscellaneous features.....	35
<b>3.4 GSM connection and configuration</b> .....	<b>13</b>	<b>4.6 Communication</b> .....	<b>36</b>
<b>3.5 SIM card insertion</b> .....	<b>13</b>	4.6.1 General guidance – Communication flow-chart & menu options .....	36
<b>3.6 WP8360 prerequisites</b> .....	<b>13</b>	4.6.2 Configuring GSM-GPRS (IP) - SMS cellular connection .....	37
<b>3.7 Enrolling and deleting a Z-Wave device</b> ....	<b>13</b>	4.6.3 Configuring event reporting to monitoring stations .....	39
<b>3.8 Panel reset</b> .....	<b>14</b>	4.6.4 Configuring event reporting to private users .....	43
<b>3.9 Factory default restore</b> .....	<b>14</b>	4.6.5 Configuring motion cameras for visual alarm verification .....	43
<b>4. Programming</b> .....	<b>15</b>	4.6.6 Configuring upload / download remote programming access permissions .....	44
<b>4.1 General guidance</b> .....	<b>15</b>	4.6.7 Broadband .....	45
4.1.1 WP8360 panel indicators and controls .....	16	<b>4.6.8 Wi-Fi</b> .....	<b>46</b>
4.1.2 Feedback sounds .....	17	<b>4.7 PGM Output</b> .....	<b>47</b>
<b>4.2 Entering Installer Mode and selecting a menu option</b> .....	<b>17</b>	<b>4.7.1 General guidance</b> .....	<b>47</b>
4.2.1 Entering the Installer Mode when User Permit is enabled .....	17	<b>4.7.2 PGM output configuration</b> .....	<b>47</b>
4.2.2 Selecting options .....	18	<b>4.7.3 Entering Daytime Limits</b> .....	<b>48</b>
4.2.3 Exiting the installer mode .....	18	<b>4.8 Custom names</b> .....	<b>48</b>
<b>4.3 Setting installer codes</b> .....	<b>18</b>	4.8.1 Custom zone names .....	48
4.3.1 Identical installer and master installer codes .....	19	<b>4.9 Diagnostics</b> .....	<b>50</b>
<b>4.4 Zones and devices</b> .....	<b>19</b>	4.9.1 General guidance – Diagnostic flow-chart & menu options.....	50
4.4.1 General guidance & ZONES/DEVICES menu options .....	19	4.9.2 Testing wireless devices .....	50
4.4.2 Adding new wireless devices.....	20	4.9.3 Testing the GSM module .....	52
<b>Enrolling a Wired Input</b> .....	<b>21</b>	4.9.4 Testing the SIM number .....	53
4.4.3 Deleting a device .....	25	4.9.5 Testing the Broadband/PowerLink Module .....	54
4.4.4 Modifying or reviewing a device .....	25	4.9.6 Testing the WLAN Module .....	54
4.4.5 Replacing a device .....	26	<b>4.10 User settings</b> .....	<b>55</b>
4.4.6 Configuring soak test mode .....	27		
4.4.7 Defining configuration defaults for device settings.....	27		
4.4.8 Updating devices after exiting Installer Mode .....	28		
<b>4.5 Control panel</b> .....	<b>29</b>		

<b>4.11 Factory default</b> .....	<b>56</b>	<b>C2. Wireless</b> .....	<b>75</b>
<b>4.12 Serial number</b> .....	<b>56</b>	<b>C3. Electrical</b> .....	<b>76</b>
<b>4.13 Partitioning</b> .....	<b>57</b>	<b>C4. Communication</b> .....	<b>76</b>
4.13.1 General guidance – Partitioning menu .....	57	<b>C5. Physical Properties</b> .....	<b>76</b>
4.13.2 Enabling and disabling partitions .....	57	<b>C6. Peripherals and Accessory Devices</b> .....	<b>77</b>
<b>4.14 Operation mode</b> .....	<b>58</b>	<b>APPENDIX D. Working with Partitions</b> .....	<b>78</b>
4.14.1 General guidance – Operation mode menu .....	58	<b>D1. User Interface and Operation</b> .....	<b>78</b>
4.14.2 Select setting .....	58	<b>D2. Common Areas</b> .....	<b>78</b>
4.14.3 BS8243 Setup .....	58	<b>APPENDIX E. Detector Deployment &amp; Transmitter Assignments</b> .....	<b>79</b>
4.14.4 DD243 Setup .....	59	<b>E1. Detector Deployment Plan</b> .....	<b>79</b>
4.14.5 CP01 Setup .....	61	<b>E2. Keyfob Transmitter List</b> .....	<b>79</b>
4.14.6 Other setup .....	62	<b>E3. Emergency Transmitter List</b> .....	<b>80</b>
<b>5. Periodic test</b> .....	<b>64</b>	<b>E4. Non-Alarm Transmitter List</b> .....	<b>80</b>
<b>5.1 General guidance</b> .....	<b>64</b>	<b>APPENDIX F. Event Codes</b> .....	<b>81</b>
<b>5.2 Conducting a periodic test</b> .....	<b>64</b>	<b>F1. Contact ID Event Codes</b> .....	<b>81</b>
<b>6. Maintenance</b> .....	<b>68</b>	<b>F2. SIA Event Codes</b> .....	<b>81</b>
<b>6.1 Handling system faults</b> .....	<b>68</b>	<b>F3. Understanding the Scancom Reporting Protocol Data Format</b> .....	<b>82</b>
<b>6.2 Replacing the backup battery</b> .....	<b>70</b>	<b>F4. SIA over IP - Offset for Device User</b> .....	<b>82</b>
<b>6.3 Replacing and relocating detectors</b> .....	<b>70</b>	<b>APPENDIX G. Sabbath mode</b> .....	<b>83</b>
<b>6.4 Annual system check</b> .....	<b>70</b>	<b>G1. General guidance</b> .....	<b>83</b>
<b>7. Reading the event log</b> .....	<b>71</b>	<b>G2. Connection</b> .....	<b>83</b>
<b>APPENDIX A. Working with the AlarmInstall Application</b> .....	<b>72</b>	<b>G3. Arming the system by Sabbath clock</b> .....	<b>83</b>
Adding a panel .....	73	<b>APPENDIX H. Glossary</b> .....	<b>84</b>
<b>APPENDIX C. Specifications</b> .....	<b>75</b>	<b>APPENDIX I. Compliance with standards</b> .....	<b>86</b>
<b>C1. Functional</b> .....	<b>75</b>	<b>WP8360 Quick user guide</b> .....	<b>91</b>

## V20.2 UPDATES

Refer to the following changes that replace the equivalent information in the supplied installer guide.

### 4.4.2 Adding new wireless devices or wired sensors

#### **Part B – Configuration**

##### **Zone Type List**

No.	Zone Type	Description
25	Custom 1	A custom zone type that reports to private phone, and SMS numbers without activating any sirens. This setting is configured to perimeter by default. To define the setting default, refer to section 4.8.2 <i>Custom Zone Types</i> .
26	Custom 2	A custom zone type that reports to private phone, and SMS numbers without activating any sirens. This setting is configured to perimeter by default. To define the setting default, refer to section 4.8.2 <i>Custom Zone Types</i> .

### 4.4.7 Defining configuration defaults for "device settings"

The default configuration of the 'VIEW ON DEMAND' feature is 'disabled'. To change the default configuration, complete the following steps:

① <b>Changing VIEW ON DEMAND defaults</b>	
[1]	<b>Enter the installer menu and select 02:ZONES/DEVICES</b>
[2]	<b>Select DEFINE DEFAULTS</b>
[3]	<b>Select MOTION SENSORS</b>
[4]	<b>Select VIEW ON DEMAND and choose the desired default setting from the list of options</b>
	<b>Note:</b> The selected default setting is marked with ■
	<b>Note:</b> The new default affects only new motion cameras enrolled after the change is performed.

### 4.5.5 Configuring sirens functionality

In previous versions, an alarm that occurred in a single partition activated all sirens in the system. From version 20.2 onwards, you can configure the system so that the siren sounds only when an alarm is triggered within the same partition.

Option	Configuration Instructions
<b>48:SRN PER PRTN</b>	<p>This setting determines if the siren activates when an alarm occurs within the same partition.</p> <p><b>Note:</b> This option does not apply to sirens that are embedded in the panel or wired sirens that are connected to expanders or PGMs.</p> <p>If you set the siren to <b>Enable</b>, and an alarm is triggered in the same partition, the siren sound and the exit and entry beeps activate.</p> <p><b>Note:</b> To silence a siren within a partition, you must have access privileges to that partition.</p> <p>If set to <b>Disable</b>, the siren sound, as well as exit and entry beeps, are activated when an alarm is triggered in any partition.</p> <p>If you set the siren to <b>Disable</b>, and an alarm is triggered in any partition, the siren sound and the exit and entry beeps activate.</p> <p>Options: <b>Disable</b> (default) or <b>Enable</b>.</p>

### 4.5.6 Configuring audible & visual user interface

Option	Configuration Instructions
<b>56:SCREEN SAVER</b> With partition disabled	<p>The screen saver option - when activated - replaces the status display on the control panel with the words "SECURITY SYSTEM" if no key is pressed for more than 30 seconds.</p>

## 4.6.6 Configuring motion cameras for visual alarm verification

In previous versions, changing the VIEW ON DEMAND setting configured all enrolled motion cameras at once. From version 20.2 and later, you can configure each motion camera individually to the required viewing setting.

From version 20.2 onwards, the location for VIEW ON DEMAND has changed:

**Version 19.4 or earlier:**



**Version 20.2 or later:**



Option	Configuration Instructions
<b>VIEW ON DEMAND</b>	The VIEW ON DEMAND configuration determines in which arming modes the feature is enabled. Options: <b>disabled</b> (default); <b>in all modes</b> ; <b>in AWAY only</b> ; <b>in HOME only</b> ; <b>in HOME &amp; AWAY</b> ; <b>DISARM &amp; AWAY</b> ; <b>DISARM &amp; HOME</b> ; and <b>in DISARM only</b> .

**Note:** Other configurations related to this feature, such as VIEW TIME WINDOW, UPLOAD FILM and KIDS COME HOME are unchanged.

## 4.7.2 PGM output configuration

From version 20.2 onwards it is possible to:

- (1) You can activate a PGM output for up to six sensors (zones). See PGM: BY SENSOR for more details.
- (2) You can activate a PGM output in response to temperature, presence, and light sensor signals. See PGM: BY SENSOR for more details.
- (3) You can program an output using both wired and wireless sirens and strobes. See PGM: BY OTHER for more details.





Option	Configuration Instructions
<b>PGM:BY SENSOR</b> → Zone A Z: __ → Zone B Z: __ → Zone C Z: __ → Zone D Z: __ → Zone E Z: __ → Zone F Z: __	<p>You can trigger a PGM output when any of the six available sensors activate. The output triggers when the system is either armed or disarmed.</p> <p><u>To configure and PGM output, complete the following steps:</u></p> <p>Press <b>OK</b> to enter the <b>PGM: BY SENSOR</b> sub menu and then select the zone you wish to program, for example <b>Zone A</b>. If the zone was configured before, the display shows the current zone number (<b>Z:xx</b>) and if not, the zone number is blank (<b>Z: _ _</b>).</p> <p>To configure the zone number, press <b>OK</b>. Enter the two digit zone number that you wish to activate the PGM output for and press <b>OK</b> to confirm.</p> <p>Select <b>ZONE ACTIVITY</b> to define which activity in the selected zone will trigger the PGM. Options: <b>Open/Violate</b> (default); <b>Close</b>; <b>Presence</b>; <b>No Presence</b>; <b>Light ON</b>; <b>Light OFF</b>; <b>Very HOT</b>; <b>Very HOT RSTR</b>; <b>Cold</b>; <b>Cold RSTR</b>; <b>Freezing</b>; <b>Freezing RSTR</b>; <b>Freezer</b>; <b>Freezer RSTR</b></p> <p>Select <b>PGM ACTION</b> to define the PGM behavior. <b>Note:</b> If you select <b>toggle</b>, the PGM output turns on when an event occurs in any of these zones and is turned off when the next event occurs, alternately. <b>Note:</b> If the zone number needs to be updated for an existing PGM configuration, the PGM action must be changed for the update to take effect. In order to do this, change the PGM action to a temporary value and then return to the menu to change it back to the required action.</p> <p>To add another sensor, select another zone (<b>Zone B to Zone F</b>,) and repeat the above process.</p> <p>When the procedure is complete, press <b>Home</b> to return to the home screen. <b>Note:</b> After you exit from the installer mode, all PGM outputs are turned off</p> <p>Options: <b>disabled</b> (default); <b>turn ON</b>; <b>turn OFF</b>; <b>activate PULSE</b>; <b>toggle</b></p>

## 4.8 Custom names

### 4.8.1 Custom zone names

From version 20.2 onwards the name of **06: Custom Names** and **Cust. Zones Name** has changed:

**Version 19.4 or earlier:**

06:CUSTOM NAMES   ...  CUST.ZONES NAME 

**Version 20.2 or later:**

06:CUSTOM DEF.   ...  ZONE NAMES 

### 4.8.2 Custom zone types

From version 20.2 onwards it is possible to define up to two custom zone types. You can configure these two zones types to meet specific installation requirements and to enroll devices to the custom zone types sub menu.

To define a custom zone type, from the installer menu, follow the flow diagram below:

06:CUSTOM DEF.   ...  ZONE TYPES 

Enter the **CUSTOM 1** or **CUSTOM 2** sub menu and complete the following instructions:

Option	Configuration Instructions
<b>TYPE</b>	Use this configuration to define the zone type. <b>Note:</b> See the installation manual for a description of the zone types. Options: <b>Perimeter</b> (default); <b>Perim-Follow</b> ; <b>Interior</b> ; <b>Inter-Follow</b> and <b>24h</b>
<b>REPORT TO</b>	Use this configuration to define where the event message is reported to. Select <b>Private</b> to send the event to private telephone or SMS numbers. Select <b>C.S.</b> to send the event to the central monitoring station, Select <b>Private and C.S.</b> to send the event to both private telephone/SMS numbers and central monitoring station. Options: <b>Private</b> (default); <b>C.S.</b> ; and <b>Private and C.S.</b>
<b>ACTIVATE SIRENS</b>	Use this configuration to define whether sirens enrolled in the zone are activated following an event. Select <b>Enable</b> to activate sirens on the zone. Select <b>Disable</b> to prevent sirens from being activated on the zone. Options: <b>Disable</b> (default); and <b>Enable</b>

# 1. Introduction

The WP8360 security and smart home platform is a comprehensive security system based on the WP wireless panel security logic and PowerG proven RF security technology with IP communication. The WP8360 platform has dual path configuration: IP via Ethernet to the customer-premises gateway and cellular modem (2G or 3G). The reporting is done through IP as primary and cellular modem as secondary. Property owners receive notifications of events by email and/or SMS. In addition, the system includes a Wi-Fi module that supports IP cameras and a Z-Wave controller that supports Z-Wave devices.

The WP8360 security system is accessible to home and property owners through their mobile devices. Installers program and configure the system remotely through the AlarmInstall application (see [APPENDIX A](#)).

This manual refers to WP8360 v18 and above. The most updated manuals can be downloaded from the DSC Web site <http://www.dsc.com>.

## 1.1 System Features

The following table lists the WP8360 features with a description of each feature and how to use it.

<b>Feature</b>	<b>Description</b>	<b>How to configure and use</b>
Visual alarm verification	When used with PGx934 PIR-camera detector or PGx944, and GPRS or Ethernet communication, the WP8360 is able to provide the Monitoring Station with clips captured in alarm situations. The system sends the clips to the Monitoring Station automatically for burglary alarms and, depending on setup, also for fire and personal emergency alarms.	<b>1. Setup GPRS communication:</b> see GSM Module Installation (section 3.4). <b>2. Configure camera settings:</b> refer to the PGx934 Installation Instructions. <b>3. Enable fire and personal alarm verification:</b> see section 4.6.5 Configuring Motion Cameras for Video Alarm Verification.
On demand clips from cameras	The WP8360 can provide images from the PGx934 or PGx944 by demand from a remote PowerManage server. Pictures are taken based on a command from the monitoring station via the ConnectAlarm application. To protect customers' privacy, the system can be customized to enable the <b>On Demand View</b> only during specific system modes (i.e. Disarm, Home & Away) and also to a specific time window following an alarm event.	<b>1. Setup the On demand feature:</b> see section 4.6.5 Configuring Motion Cameras for Video Alarm Verification. <b>2. To request and view images:</b> refer to the PowerManage User's Guide, Chapter 5 Viewing and Handling Events.
Easy enrollment	PowerG devices are enrolled from the control panel's Virtual Keypad. Pre-enrollment can also be performed by entering the PowerG device ID number and then activating the device in the vicinity of the panel.	<b>To enroll or pre-enroll devices:</b> see section 4.4.2 Adding New Wireless Devices.
Device configuration	Device parameters and related system behavior can be configured from the control panel or from a remote location. Each PowerG device has its own settings which can be configured through the control panel by entering the DEVICE SETTINGS menu. <b>Note:</b> <i>The minimum configuration of the system includes one detector.</i>	<b>To configure devices from the control panel:</b> see Chapter 4 Programming and also the individual device's Installation Instructions. <b>To configure devices from a remote location:</b> refer to the PowerManage User's Guide Chapter 3 Working with Panels.

Diagnostics of the control panel and peripherals	You can test the function of all wireless sensors deployed throughout the protected area, to collect information about the received signal strength from each transmitter and to review accumulated data after the test.	<b>To perform diagnostics and to obtain signal strength indication:</b> see section 4.8 Diagnostics.
Conducting periodic tests	The system should be tested at least once a week and after an alarm. The periodic test can be conducted locally or from a remote location (with the assistance from a non-technical person in the house).	<p><b>To conduct a walk test locally:</b> see Chapter 5 Periodic Test.</p> <p><b>To conduct a walk test from remote location:</b> refer to the section "Performing a walk test in the Diagnostics tab" in AlarmInstall app User Guide.</p>
Partitions	The partitioning feature, when enabled, divides your alarm system into distinct areas each of which operates as an individual alarm system. Partitioning can be used in installations where shared security systems are more practical, such as a home office or warehouse building.	<p><b>1. Enable partitioning:</b> see section 4.12 Partitioning.</p> <p><b>2. Setup partition association for each device:</b> see section 4.4.2 Adding New Wireless Devices.</p> <p><b>To understand more about partitioning:</b> see <a href="#">APPENDIX D. Working with Partitions</a> and the User's Guide.</p>
Device configuration templates	The default parameters with which a new device is enrolled into the system can be set before you enroll devices. This default template saves time on device configuration.	<p><b>1. Define enrollment defaults for devices:</b> see section 4.4.7 Defining Configuration Defaults for Device Settings.</p> <p><b>2. Enroll or pre-enroll devices:</b> see section 4.4.2 Adding New Wireless Devices.</p>
SirenNet - distributed siren using Smoke detectors	All PowerG smoke detectors are able to function as sirens, alerting on any of 4 types of alarm in the system: fire, gas, burglary and flood.	<b>Enable and configure SirenNet for each smoke detector:</b> refer to the PGx936 Installation Instructions.
Reporting to private users and/or monitoring station by SMS and IP communication	The WP8360 system can be programmed to send notifications of alarm and other events to 4 SMS cellular phone numbers and to report these events to the Monitoring Station by SMS or IP communication. Users can also receive notifications on the ConnectAlarm application.	<p><b>To configure notifications to Private phones:</b> refer to section 4.6.4 Configuring event reporting to private users</p> <p><b>To configure reporting to the Monitoring Station:</b> see section 4.6.3 Configuring Events Reporting to Monitoring Stations.</p>
Quick installation with link quality indication	With PowerG devices, there is no need to consult the control panel when mounting a wireless device, because PowerG devices include a built-in link quality indicator. Choosing the mounting location is a quick and easy process.	To choose the ideal location to mount a wireless device, see Chapter 2 Choosing the Installation Location.
Device Locator	Helps you to identify open or troubled devices indicated on the Alarm Install Virtual Keypad display. While the Virtual Keypad displays an open or faulty device, the LED on the respective device flashes indicating "it's me". The "it's me" indication appears on the device within max. 16 seconds and lasts for as long as the Virtual Keypad displays the device	

Guard key-safe	The system is able to control a safe that holds site keys that are accessible only to the site's guard or Monitoring Station's guard in the event of an alarm. Operates with the magnetic contact device with auxiliary input only (PGx945)	<p><b>1. Configure the safe's zone type to Guard Zone:</b> see section 4.4.2 Adding New Wireless Devices.</p> <p><b>2. Setup guard code:</b> see section 4.3 Setting Installer Codes.</p>
Arming Key	External system can control arming and disarming of the system.	Refer to the WK241 and WK160 Installation Instructions.
GPRS usage	The installer can define GPRS usage of third-party home automation application.	

## 2. Choosing the installation location

To ensure the best possible mounting location for the WP8360 control panel, the following points should be observed when selecting a location:

- Place approximately in the center of the installation site between all the transmitters, preferably in a hidden location.
- Place in close proximity to an AC source.
- Place where there is good cellular coverage, if a cellular module is used.
- Place in close proximity to a home router wired Ethernet (LAN) connections.
- Place far from sources of wireless interference, such as:
  - Computers or other electronic devices, power conductors, cordless phones, light dimmers, etc.
  - Large metal objects such as metal doors or refrigerators

**Note:** A distance of at least 1 meter (3 ft.) is recommended.

When mounting wireless devices, ensure that the following conditions are in place:










- Ensure the signal reception level for each device is either **Strong** or **Good**, but not **Poor**.
- Install wireless magnetic contacts in a vertical position and as high up the door or window as possible.
- Install wireless PIR detectors upright at the height specified in the relevant installation manual.
- Locate repeaters high on the wall mid-distance between the transmitters and the control panel.


**WARNING!** To comply with FCC and IC RF exposure compliance requirements, the control panel should be located at a distance of at least 20 cm from all persons during normal operation. The antennas used for this product must not be co-located or operated in conjunction with any other antenna or transmitter.

Le dispositif doit être placé à une distance d'au moins 20 cm à partir de toutes les personnes au cours de son fonctionnement normal. Les antennes utilisées pour ce produit ne doivent pas être situés ou exploités conjointement avec une autre antenne ou transmetteur.

# 3. Installation

## 3.1 LED indicators and connections


	<ul style="list-style-type: none"><li>A. Power indicator </li><li>B. Status indicator </li><li>C. Trouble indicator </li><li>D. Service server indicator </li><li>E. Smart Home Service Indicator </li><li>F. Wi-Fi indicator </li></ul>
	<ul style="list-style-type: none"><li>G. Micro USB connection</li><li>H. 5V DC power connection</li><li>I. LAN connection</li></ul>
	<ul style="list-style-type: none"><li>J. Functional pushbuttons:<ul style="list-style-type: none"><li>+ button - Add PowerG / Z-Wave devices</li><li>- button - Delete PowerG / Z-Wave devices</li><li>+ and - buttons simultaneously – Installer Wi-Fi activation and deactivation</li></ul></li><li>K. Opening for reset button</li><li>L. <b>Restore to factory default settings:</b> Press for 30 sec. to restore system parameters to factory defaults.</li><li>M. Micro SD memory card holder (for future use)</li><li>N. Enroll LED</li></ul>




- O. Battery plug socket
- P. SIM card holder
- Q. Rechargeable battery

*Figure 3.1 – Connections and LED indications*

### 3.2 Inserting the Battery




1. Press on the tab inward and lift to remove the battery cover.
2. Insert the battery cable plug into the battery socket.
3. To close the battery cover, align the two tabs of the battery cover with their respective slots and press down on the cover in the direction shown until a click is heard.



**Figure 3.2 – WP8360 Battery Insertion**

### 3.3 WP8360 connections



**Figure 3.3 – WP8360 Panel Connections**

**Note:** If there is a GSM module in your control panel, first connect the SIM card before performing the following procedure, see section 3.5 for details:

1. Connect the DC power supply from the mains electrical socket to the power connection.
2. Connect the IP cable from the LAN connection to the local home-router connection.
3. To work with the Configurator, connect the micro USB cable from the micro USB connection to the PC/laptop/tablet connection. Configurator software can be downloaded from [www.visonic.com](http://www.visonic.com) website if you are a registered user.
4. After completing the setup in the configurator, disconnect the USB cable from the WP8360.

**Note:** For details about installing and configuring the AlarmInstall Application, see [APPENDIX A. Working with the AlarmInstall Application](#).

### 3.4 GSM connection and configuration


The GSM modem auto detection feature enables automatic enrollment of the GSM modem into the control panel memory. GSM modem auto detection is activated after reset that is after power-up or after exiting the Installer Mode menu. This action causes the WP8360 to automatically scan the GSM COM ports for the presence of a GSM modem.

In the event that the GSM modem auto detection fails and the modem was previously enrolled in the control panel, the message **Cel Remvd Cnfrm** is displayed on the Configurator's Virtual Keypad. This message disappears from the display after you press **OK**. The modem is then considered as not enrolled and no GSM trouble messages are displayed.

**Notes:**

- 1) A message is displayed only when the alarm system is disarmed.
- 2) The GSM Alarm Transmission System is designed to comply with EN 50131-1 ATS4.

### 3.5 SIM card insertion



The following procedure outlines how to insert SIM card into the GSM module, see Figure 3.1 (O):

1. Slide the top cover.
2. Open the cover.
3. Align the SIM card in the cover (note cover orientation).
4. Slide the SIM card into the cover.
5. Rotate the cover to close.
6. Lock the cover to close.

**CAUTION!** Do not insert or remove the SIM card when the control panel is powered by AC power or battery.

To configure the GSM modem, see section 4.6.2.

### 3.6 WP8360 prerequisites

Connection to the PowerManage server requires the following ports to be open on the router to access the internet:

- TCP ports : 8080, 5001
- UDP port: 5001
- FTP port: 21

**Note:** In a typical home router these ports on the router are open.

### 3.7 Enrolling and deleting a Z-Wave device

#### Enrolling a Z-Wave device

To enroll a device, complete the following steps:

1. Press and hold the **(+)** button for 2 seconds, see Figure 3.1 (J). The red LED blinks slowly, see Figure 3.1 (N).
2. Press the **Enroll** button on the device.
3. The green LED blinks quickly, a success beep is emitted, and the LED turns off when the device is enrolled.

**Notes:**

- To cancel the enrollment, press and hold the **(+)** or **(-)** buttons for 2 seconds. The LED stops blinking.
- If the enrollment is not successful, the red LED remains on for 3 seconds and a failure beep is emitted.
- Long press on the **(+)** button, returns the panel to normal operation.

## Deleting a Z-Wave device

To delete an enrolled device, press and hold the (-) button for 2 seconds, see Figure 3.1 (J). The red LED blinks quickly, see Figure 3.1 (N) enroll LED. A success beep is emitted and the LED turns off.

### Notes:

- *To cancel the deletion, press and hold the (+) or (-) buttons for 2 seconds. The LED stops blinking.*
- *If the deletion is not successful, the red LED lights for 3 seconds and a failure beep is emitted.*
- *Long press on the (-) button, returns the panel to normal operation.*

## 3.8 Panel reset

To reset the panel, use a blunt instrument to press the **Reset** button, see Figure 3.1 (K). The orange LED lights constantly until panel initialization is completed, see Figure 3.1(N). When the PowerLink is reset, the orange LED (N) turns off.

## 3.9 Factory default restore

To restore system parameters to the factory default parameters, complete the following steps:

**Note:** The panel must be disarmed before performing the reset.

1. Press the Back to Factory button for 30 seconds; see Figure 3.1 (L).

**Note:** *During restore process, the red LED blinks; see Figure 3.1 (N).*

2. The green LED blinks 3 times and a success beep is emitted. The panel immediately initiates a software reset.

**Note:** *If the default restore is not successful, the red LED light remains on for 3 seconds and a failure beep is emitted.*

# 4. Programming

## 4.1 General guidance

This chapter explains the Installer programming (configuration) options of your WP8360 system and how to customize its operation to your particular needs and end user requirements.

Software configuration of the alarm system is performed using the Virtual Keypad which contains the control keys, numerical keypad and display.

The control panel includes a partition feature. Partitioning allows you to have up to three independently controllable areas with different user codes assigned to each partition. A partition can be armed or disarmed regardless of the status of the other partitions within the system.

The Soak Test feature allows selected zones to be tested for a pre-defined period of time. When in Soak Test mode, activating a zone does not cause an alarm and siren and strobe are not activated. The zone activation is recorded in the event log and is not reported to the Monitoring Station. The zone remains in Soak Test until the pre-defined period of time for the Soak Test has elapsed without any alarm activation. The zone then automatically removes itself from Soak Test mode and returns to normal operating mode.

### **Tech Tip** :

For your convenience, program the WP8360 on a work bench before the installation. You can obtain operating power from the backup battery or from the AC/DC adapter.

### **ATTENTION! FIRST SWITCH ON THE CONTROL PANEL and then INSERT BATTERIES INTO ACCESSORIES DEVICES.**

*The devices search for the control panels to which they are enrolled for a period of 24 hours only after you insert the battery.*

**Note:** *If you switch on the control panel a long time after inserting batteries into the accessories devices you must open and then close the cover of the WP8360 to activate the tamper switch. Alternatively, remove and reinsert the battery into the device.*

## 4.1.1 WP8360 panel indicators and controls

### LED indicators

















Figure 4.1 LED Indicators

No.	Function
A	<b>Power</b>  ( <b>Green</b> ) indicates that your system is connected to the power outlet.
B	<b>Arming status</b>  ( <b>Flashing Red / Static Red</b> ) indicates HOME / AWAY.
C	<b>Trouble condition (TRBL)</b>  ( <b>Orange</b> ) lights when the system detects an abnormal condition caused by a fault. See chapter 3 for details.
D	<b>Service Server</b>  ( <b>Blue</b> ) lights when the system is connected to the security server.
E	<b>Smart Home Service</b>  ( <b>Blue</b> ) lights when the system is connected to the smart home server.
F	<b>Wi-Fi</b>  ( <b>Green</b> ) indicates if the Wi-Fi module is enabled or disabled. The light blinks fast when activating or deactivating a Wi-Fi access point, and blinks slowly when the Wi-Fi access point is active.

### Control keys






The Virtual Keypad can only be used as part of the ConnectAlarm Mobile Application.

The Virtual Keypad's buttons are used for navigation and configuration when programming. For more information, refer to Appendix A.

To review the options within the control panel menus and select an option, repeatedly press the Next  or Back  until the desired option displays (also designated as  in this guide), then press the OK  to select the desired option (also designated as  in this guide). To return to the previous options, repeatedly press Home . To exit the programming menu, press Away .

## 4.1.2 Feedback sounds





The panel or PC provides the following audible indicators when configuring the panel:

Sound	Definition
	Single beep indicates that a key is pressed.
	Double beep indicates a return to the normal operating mode after a timeout.
	Three beeps indicate an abnormal condition in the system due to a fault.
	<b>Success Tune</b> (- - - —), indicates successful completion of an operation.
	<b>Failure Tune</b> (—), indicates an incorrect option or the value that is not accepted.

## 4.2 Entering Installer Mode and selecting a menu option

All Installer Mode options are accessed from the Installer Mode menu option.

To enter and select an option from the Installer Mode menu, complete the following steps:

Step 1	Step 2	Step 3	Step 4																											
Select <b>INSTALLER MODE</b> Option [1]	Enter Installer Code [2]	Select Installer Mode menu option [3]																												
 <p><b>READY 00:00</b></p> <p>↓</p> <p><b>INSTALLER MODE</b>  <b>ENTER CODE: ■</b></p> <p>If the <b>Installer Mode</b> is not shown, refer to section 4.2.1</p>	 <table border="1"> <thead> <tr> <th></th> <th>See</th> <th></th> <th>See</th> </tr> </thead> <tbody> <tr> <td><b>01:INSTALL CODES</b></td> <td>4.3</td> <td><b>08:USER SETTINGS</b></td> <td>4.9</td> </tr> <tr> <td><b>02:ZONES/DEVICES</b></td> <td>4.4</td> <td><b>09:FACTORY DEFLT</b></td> <td>4.10</td> </tr> <tr> <td><b>03:CONTROL PANEL</b></td> <td>4.5</td> <td><b>10:SERIAL NUMBER</b></td> <td>4.11</td> </tr> <tr> <td><b>04:COMMUNICATION</b></td> <td>4.6</td> <td><b>12:PARTITIONING</b></td> <td>4.12</td> </tr> <tr> <td><b>06:CUSTOM NAMES</b></td> <td>4.7</td> <td><b>13:OPERATION MOD</b></td> <td>4.13</td> </tr> <tr> <td><b>07:DIAGNOSTICS</b></td> <td>4.8</td> <td><b>&lt;OK&gt; TO EXIT</b></td> <td></td> </tr> </tbody> </table>		See		See	<b>01:INSTALL CODES</b>	4.3	<b>08:USER SETTINGS</b>	4.9	<b>02:ZONES/DEVICES</b>	4.4	<b>09:FACTORY DEFLT</b>	4.10	<b>03:CONTROL PANEL</b>	4.5	<b>10:SERIAL NUMBER</b>	4.11	<b>04:COMMUNICATION</b>	4.6	<b>12:PARTITIONING</b>	4.12	<b>06:CUSTOM NAMES</b>	4.7	<b>13:OPERATION MOD</b>	4.13	<b>07:DIAGNOSTICS</b>	4.8	<b>&lt;OK&gt; TO EXIT</b>		 <p>Go to the indicated section of the selected option</p>
	See		See																											
<b>01:INSTALL CODES</b>	4.3	<b>08:USER SETTINGS</b>	4.9																											
<b>02:ZONES/DEVICES</b>	4.4	<b>09:FACTORY DEFLT</b>	4.10																											
<b>03:CONTROL PANEL</b>	4.5	<b>10:SERIAL NUMBER</b>	4.11																											
<b>04:COMMUNICATION</b>	4.6	<b>12:PARTITIONING</b>	4.12																											
<b>06:CUSTOM NAMES</b>	4.7	<b>13:OPERATION MOD</b>	4.13																											
<b>07:DIAGNOSTICS</b>	4.8	<b>&lt;OK&gt; TO EXIT</b>																												

### ① - Entering the Installer Mode menu

- [1] You can access the **Installer Mode** only when the system is disarmed. The process described refers to the case where **User permit** is not required. If **User permit** is required, select the **User Settings** option and ask the Master User to enter his code and then scroll the **User Settings** menu and select the **Installer Mode** option (last option in the menu). Continue to Step 2.
- [2] If you have not already changed your Installer code number, use the default settings: 8888 for installer & 9999 for master installer.  
If you enter an invalid installer code 5 times, the keypad will be automatically disabled for a pre-defined period of time and the message **WRONG PASSWORD** will be displayed.
- [3] You have now entered the **Installer Mode menu**. Scroll and select the menu required and continue to its corresponding section in the guide (indicated on the right side of each option).

### 4.2.1 Entering the Installer Mode when User Permit is enabled

In certain countries the regulations may require that the user grants permission to make changes to the panel configuration. To comply with these regulations, the **Installer Mode** option can be accessed only from the **User Settings** menu. The Master user must first enter the **User Settings** menu then scroll until the **Installer Mode** option is shown and then the installer can continue as shown in the above table (see also ① [1] in Step 1 above).

To configure the panel to comply with **user permission** requirements - see option #91 **User Permit** in section 4.5.8.



## 4.2.2 Selecting options

### ① ① – Selecting an option from a menu

#### **Example: To Select an Option from the COMMUNICATION menu:**




- [1] Enter the **Installer Mode** menu and select the **04.COMMUNICATION** option (see section 4.2).
- [2] Select the sub-menu option you need, for example: **3: C.S. REPORTING**.
- [3] Select the parameter you require to configure for example: **11:RCVR 1 ACCOUNT**
- [4] To continue, go to the section of the selected sub-menu option, for example section 4.6.3 for the **3:C.S.REPORTING** menu, and look for the sub-menu you require to configure (e.g. **11:RCVR 1 ACCOUNT**). After configuring the selected parameter the display returns to step 3.

#### **To Change the Configuration of the Selected Option:**




When entering the selected option, the display shows the default (or the previously selected) **setting** marked with **■**. To change the configuration, scroll  the Options menu and select the setting you require and press  to confirm. When done, the display reverts to Step 3.

## 4.2.3 Exiting the installer mode

To exit the Installer Mode, proceed as follows:

Step 1	①	Step 2	①	Step 3	①
	[1]		[2]		[3]
Any screen	 or 	<OK> TO EXIT		READY 12:00	

### ① ① – Exiting the Installer Mode

- [1] To exit **INSTALLER MODE**, move up the menu by pressing the  button repeatedly until the display reads **<OK> TO EXIT** or preferably; press the  button once which brings you immediately to the exit screen **<OK> TO EXIT**.
- [2] When the display reads **<OK> TO EXIT**, press .
- [3] The system exits the **INSTALLER MODE** menu and returns to the normal disarm state while showing the **READY** display.

## 4.3 Setting installer codes

The WP8360 system provides two installer permission levels with separate installer codes, as follows:

- **Master Installer:** The Master Installer is authorized to access all Installer Mode menu and sub-menu options. The default code is: 9999 (\*).
- **Installer:** The Installer is authorized to access most but not all Installer Mode menu and sub-menu options. The default code is 8888 (\*).
- **Guard Code:** Enables an authorized guard to only Arm Away / Disarm the control panel. The default code is 0000 (\*).

The following actions require you to enter the **Master Installer code**:

- Changing the Master Installer code.
- Defining specific communication parameters – see **3:C.S REPORTING** in sections 4.6.2 and 4.6.3.
- Resetting the WP8360 parameters to the default parameters – see **09:FACTORY DEFLT** in section 4.11.

**Note:** Not every system includes a **Master Installer code** feature. In such systems, the **Installer** can access all **Installer Mode** menu and sub-menu options identical to the **Master Installer**.

(\*) You are expected to use the default codes only once for gaining initial access, and replace it with a secret code known only to yourself.

To change your Master Installer or Installer Codes proceed as follows:

Step 1	Step 2	Step 3	Step 4
Select <b>01:INSTALL CODES</b> Option	Select <b>Master Installer, Installer code or Guard code</b>	Enter <b>NEW Master Installer, Installer code or Guard code</b>	
INSTALLER MODE  ENTER CODE: █ ↓	NEW MASTER CODE ↓ or NEW INST. CODE ↓ or NEW GUARD CODE	MASTER CODE █999 or INST. CODE █888 or GUARD CODE █000	to step 2 to step 2 to step 2
01:INSTALL CODES			

① ① – Setting Installer Codes	
[1]	Enter the <b>Installer Mode menu</b> and select the <b>01:INSTALL CODES</b> option (see section 4.2).
[2]	Select the <b>NEW MASTER CODE, NEW INST. CODE or NEW GUARD CODE</b> . Some panels may have only the Installer Code and New Guard Code option.
[3]	Enter the new 4-digit Code at the position of the blinking cursor and then press .
<b>Notes:</b>	
1. Code 0000 is not valid for Master Installer or installer.	
2. Inserting 0000 for the Installer will delete the Installer Code.	
3. <b>Warning! Always use different codes for the Master Installer, for the Installer and for the Users.</b> If the Master Installer Code is identical to the Installer code, the panel will not be able to recognize the Master Installer. In such a case, you must change the Installer code to a different code. This will re-validate the Master Installer code.	

### 4.3.1 Identical installer and master installer codes

In a 2-installer code system, the non-master installer may inadvertently change his Installer Code to that of the Master Installer Code. In this case, the panel will allow the change in order to prevent the non-master installer from realizing the discovery of the Master Installer's Code. The next time the Master Installer enters the Installer Mode the Master Installer will be considered as an Installer and not as a Master Installer. In such a case the Master Installer should do the following:

1.
  - a) Change the Installer Code to a temporary code
  - b) Exit the Installer Mode
  - c) Enter the Installer Mode again using the Master Installer code (the Master Installer Code will now be accepted).
  - d) Change the Master Installer code to a different code.
  - e) Change the NON-Master Installer Code back again (that is, undo the change to the temporary code) so that the NON-Master Installer can still enter the system.

## 4.4 Zones and devices

### 4.4.1 General guidance & ZONES/DEVICES menu options

From the ZONES/DEVICES menu you can add, configure, and delete devices.

To select an option follow the instructions below. See section 4.2 for more information.

INSTALLER MODE	02:ZONES/DEVICES	MENU required	indicates scroll	and select	
----------------	------------------	---------------	------------------	------------	--


Option	Use	Section
ADD NEW DEVICES	To <b>enroll</b> and <b>configure</b> the device's operation according to your preference and in the case of sensors to also define their zone name (location), zone type, and chime operation.	4.4.2
DELETE DEVICES	To <b>delete</b> devices from the system and to reset their configuration.	4.4.3
MODIFY DEVICES	To <b>review</b> and/or <b>change</b> the device's configuration.	4.4.4
REPLACE DEVICES	To <b>replace</b> faulty devices with automatic configuration of the new device.	4.4.5
ADD TO SOAK TEST	To <b>enable</b> the Soak Test for device zones.	4.4.6
DEFINE DEFAULTS	To <b>customize</b> the defaults of the device's parameters according to your personal	4.4.7

preferences for each new device enrolled in the system.

## 4.4.2 Adding new wireless devices

### Part A - Enrollment

To enroll and configure a device, follow the instructions in the following chart:



①	① - Adding New Devices
[1]	Enter <b>INSTALLER MODE</b> , select <b>02:ZONES DEVICES</b> (see section 4.2) and then select <b>ADD NEW DEVICE</b> . Because of encryption, PowerG devices (including Keyfobs) cannot be used on more than one system at one time. Remember to verify panel and device compatibility.
[2]	See enrollment by button or device ID below. If enrollment is successful, the display reads <b>DEVICE ENROLLED</b> (or <b>ID ACCEPTED</b> ) and then shows the device details - see [3]. However, if the enrollment fails, the display will advise you the reason for failure, for example: <b>ALREADY ENROLLED</b> or <b>NO FREE LOCATION</b> . If the enrolled device is adapted to operate as another device that the panel recognizes, the display then reads <b>ADAPTED TO &lt;OK&gt;</b> .
[3]	The display shows the device details and the first available free Zone number for example: <b>Z01:Motion Sensor &gt; ID No. 120-1254</b> (or <b>K01:Keyfob / S01:Siren</b> etc. depending on the type of the enrolled device). Detectors can be enrolled in any zone number. To change the zone number, click the <b>▶▶</b> button or type in the zone number, and then press <b>ⓘ   OK</b> to confirm.
[4]	Continue to Part B to configure the device – see diagram below

#### Checking panel to device compatibility

Each PowerG device bears a 7-character Customer ID printed on the device sticker in the format: FFF-M:DDD, (for example, 868-0:012) where FFF is the frequency band and M:DDD is the variant code.

For PowerG system devices compatibility, make sure the frequency band (FFF) and the variant code (M) of the devices match. The DDD can be ignored if the panel displays ANY for DDD.

#### Enrollment by using Device ID

The 7-digit Device ID can be used to register a device into the panel locally or from a remote location using the AlarmInstall app. The enrollment by device ID is a 2 stage procedure.

In the 1<sup>st</sup> stage you register the devices' ID numbers into the panel and complete the device configuration. This can be done from a remote location using the AlarmInstall app. Following the 1<sup>st</sup> stage, the WP8360 panel waits for the device to appear on the network in order to complete the enrollment.

In the 2<sup>nd</sup> stage, the enrollment is completed when the panel is in full working mode by inserting the battery into the device, or by pressing the tamper or enrollment button on the device. This procedure is very useful for adding devices to existing systems without the need to provide technicians with the Installer Code, or to allow access to the programming menus.

#### **Notes:**

1. The system will display **NOT NETWORKD** until the 2<sup>nd</sup> stage of all registered devices is completed.
2. The Soak Test on pre-enrolled zones can be activated only when the zone is fully enrolled.

### Enrollment using the Enrollment button

The panel is set to the Enrollment mode (step #2 above) and the device is enrolled using the Enroll button (refer to the device information in the device Installation Instructions, then open the device and identify the Enroll button). For keyfobs and keypads, use the **AUX '\*'** button. For gas detectors, **insert the battery**.

Press the enroll button for 2-5 seconds until the LED lights steadily and then release the button. The LED will extinguish or may blink for a few more seconds until the enrollment is completed. If enrollment is successfully completed, the WP8360 sounds the Success Tune and the Virtual Keypad momentarily shows **DEVICE ENROLLED** and then reads the device details.

### Enrolling a Wired Input

To enroll a wired input to the detector, the following process should be followed:

①	① - <i>Adding a Wired Input</i>
[1]	Enter <b>INSTALLER MODE</b> , and select <b>02:ZONES DEVICES</b> (see section 4.2) .
[2]	Select <b>ADD WIRED SENSOR</b> .
[3]	Select the required sensor group, for example Contact Sensors, Shock Sensors.
[4]	Select the required device.
[5]	Select the required PIN number from the HW INPUT PIN #. The input is enrolled as a zone, <b>for example:Z02: Wired Sensor</b> with ID number <b>053-XXXX</b> .
[6]	Scroll to select the required zone number, location, zone type, chime configuration, and device setting. The device settings for a wired input include the following <b>Wiring Type</b> options: <ul style="list-style-type: none"><li>- EOL– end of line</li><li>- Normally open</li><li>- Normally closed</li><li>- Double EOL (not available for all devices – see device installation instructions)</li></ul>
[NOTE:]	Once a wired input is enrolled to a device, the menus <b>Input #1</b> (for PGx945) and <b>Aux Input</b> (for PGx935) are not available for further configuration in the device's <b>Device Settings</b> .
[NOTE:]	Deleting the device will automatically delete its wired input.

### Enrolling a PGM Output

To enroll a PGM output to the detector, the following process should be followed:

①	① - <i>Adding a PGM Input</i>
[1]	Enter <b>INSTALLER MODE</b> , and select <b>02:ZONES DEVICES</b> (see section 4.2) .
[2]	Select <b>ADD PGM OUTPUT</b> .
[3]	Select the required sensor group (Contact Sensors).
[4]	Select the required device.
[5]	Select the required PIN number from the PGM OUTPUT PIN #.
[6]	Scroll to select the required location name.

## Part B - Configuration

Step 1	Step 2	Step 3	Step 4
Enter Location Menu [1]	Select Location [2] (see list below)	Enter Zone Type [3]	Select Zone Type [4] (see list below)
→ Z10:LOCATION	↗ Dining room ■ ↓ Custom 5	→ Z10:ZONE TYPE	↗ 1:Exit/Entry1 ■ ↓ 5. Interior
Step 5	Step 6	Step 7	Step 8
Enter Chime Menu [5]	Select Chime option [6]	Enter Partitions Menu [7]	Select Partition options [8]
→ Z10:SET CHIME	↗ chime OFF ■ ↓ melody-chime	→ Z10:PARTITIONS	↗ Z10:P1 ■ P2 P3
Step 9	Step 10	Step 11	
Enter Device Settings Menu [9]	Configure Device Parameters [10]	Continue or End	
→ Z10:DEV SETTINGS	↗ Refer to device datasheet in the device Installation Instructions for specific configuration instructions.	To continue – See ⓘ [11]	

ⓘ	ⓘ - Configuring New Devices
	<b>Location (name) setting:</b>
[1]	To review or change the <b>Location</b> (name) setting, press the  button, otherwise scroll to the next option.
[2]	To change the Location name, enter the menu and select the name from the <b>Location List</b> below. You can assign additional custom names using the <b>06.CUSTOM NAMES</b> option in the Installer Mode menu. See section 4.7. <b>Note:</b> As a shortcut, press the 2 digit serial No. of the Custom Location, which takes you directly to its menu.
	<b>Zone Type setting:</b>
[3]	To review or change the <b>Zone Type</b> setting, press the  button, otherwise scroll to the next option.
[4]	The zone type determines how the system handles signals sent from the device. Press  and select a suitable zone type. The list of available <b>Zone Types</b> and the explanation for each zone type is provided below. <b>Note:</b> As a shortcut, press the 2 digit serial No. of the <b>Zone Type</b> shown in the Location List below, which takes you directly to its menu.
	<b>Chime setting:</b>
[5]	All zones are set to <b>chime OFF</b> by default. To configure the device to cause the panel to sound (when disarmed) a <b>Chime</b> melody when tripped, press the  button, otherwise scroll to the next option.
[6]	Select between <b>Chime OFF</b> , <b>melody-chime</b> , and <b>zone name-chime</b> . In <b>melody chime</b> the control panel sounds a chime melody when the sensor is tripped. In <b>zone name-chime</b> the control panel sounds the zone name when the sensor is tripped. The chime operates during the Disarm mode only.
	<b>Partitions setting:</b>
	<b>Note:</b> The <b>PARTITIONS</b> menu appears only if Partitions is enabled in the control panel (see section 4.13).
[7]	When entering the menu, the display shows the default Partition selection (marked with ■).
[8]	Use the keypad keys , ,  to assign partitions to the device.
	<b>Device Configuration:</b>
[9]	To review or change the <b>Device Configuration (settings)</b> , press the  button, otherwise scroll to the next option – see ⓘ [11].
[10]	To configure the device parameters, refer to its corresponding device datasheet in the device Installation Instructions. The defaults of the device parameters can be also configured as explained in section 4.4.7.
[11]	After completing the configuration of the device, the wizard brings you to the <b>Next Step</b> menu with the following 3 options:

① **① - Configuring New Devices**

**NEXT Device** to enroll the next device.

**MODIFY Same Dev.** reverts to Step 1 (i.e. **LOCATION**) to allow you to perform additional changes to the device, if needed.

**EXIT Enrollment** exits the enrollment procedure and returns to Step 1 bringing you back to the **ADD NEW DEVICES** menu.

**Location List**

No.	Location Name	No.	Location Name	No.	Location Name	No.	Location Name
01	Attic	09	Dining Room	17	Hall	25	Utility Room*
02	Back door	10	Downstairs	18	Kitchen*	26	Yard
03	Basement	11	Emergency	19	Laundry Room*	27	Custom1*
04	Bathroom	12	Fire	20	Living Room*	28	Custom2*
05	Bedroom	13	Front Door	21	Master Bath*	29	Custom3*
06	Child room	14	Garage	22	Master Bedr	30	Custom4*
07	Closet	15	Garage Door	23	Office	31	Custom5*
08	Den	16	Guest Room	24	Upstairs		










\* All location names can be customized by the **06:CUSTOM NAMES** menu (see section 4.7)

**Zone Type List**



No.	Zone Type	Description
1.	Exit/Entry 1	This Zone starts the exit time when the user arms the system or the entry time when the system is armed. To configure the Exit/Entry 1 time, see sections 4.5.1 & 4.5.2 - Installer Mode menu <b>03.CONTROL PANEL</b> options 01 and 03. (*)
2.	Exit/Entry 2	Same as Exit / Entry 1 but with a different delay time. Used sometimes for entrances closer to the panel. For configuring the Exit and Entry 2 delays, see sections 4.5.1 & 4.5.2 – Installer Mode menu <b>03.CONTROL PANEL</b> options 02 and 03. (*)
3.	Home Delay	Used for Door/Window Contacts and Motion sensors protecting entrance doors to interior living areas where you require to move freely when the system is armed HOME. Functions as a <b>Delayed</b> zone when the system is armed HOME and as a <b>Perimeter Follower</b> zone when the system is armed AWAY.
4.	Inter-Follow	Similar to <b>Interior</b> zone but temporarily ignored by the alarm system during entry/exit delay periods. Usually used for sensors protecting the route between the entrance door and the panel.
5.	Interior	This zone type generates an alarm only when the system is armed AWAY but not when the system is armed HOME. Used for sensors, installed in interior areas of the premises, that must be protected when people are not present inside the premises.
6.	Interior-Delay	This zone type behaves as an <b>Interior</b> zone when the system is armed <b>Home</b> and as a <b>Delayed</b> zone when the system is armed <b>Away</b> .
7.	Perimeter	This zone type generates an alarm when the system is armed both in AWAY and HOME modes. Used for all sensors protecting the perimeter of the premises.
8.	Perim-Follow	Similar to <b>Perimeter</b> zone, but is temporarily ignored by the alarm system during entry/exit delay periods. Usually used for sensors protecting the route between the entrance door and the control panel.
9.	24h silent	This zone type is active 24 hours, even when system is DISARMED. It is used to report alarm events from sensors or manually activated buttons to the Monitoring Station or private telephones (as programmed) without activating the sirens.
10.	24h audible	Similar to 24hr silent zone, but also provides an audible siren alarm. <b>Note:</b> <i>This zone type is used only for burglary applications.</i>
11.	Emergency	This zone type is active 24 hours, even when the system is DISARMED. It is used to report an emergency event and to initiate an <b>Emergency call</b> to the Monitoring Stations or private telephones (as programmed).
12.	Arming Key	An Arming key zone is used to control the arming and disarming of the system. <b>Note:</b> <i>Operates with the magnetic contact device, magnetic contact device with auxiliary input and vanishing magnetic contact device.</i>
13.	Non-Alarm	This zone does not create an alarm and is often used for non-alarm applications. For example, a detector used only for sounding a chime.
14.	Fire	A Fire zone is used for connecting the PGX945 (magnetic contact with hard-wired input) to a

No.	Zone Type	Description
17.	Guard keybox	wired smoke detector. A Guard keybox zone is usually connected to a metal safe containing the physical keys needed to enter the building. Following an alarm, the safe becomes available to a trusted Guard who can open the Guard keybox, obtain the keys and enter the secured premises. The Guard keybox zone acts just like a 24H audible zone. The Guard keybox zone also provides automatic audible internal and external siren alarm that is immediately reported to the Monitoring Station (and does not depend on the Abort Time). <b>Notes:</b> <i>1. Opening/closing the Guard keybox causes the WP8360 to signal the Monitoring Station. 2. Operates with the magnetic contact device with auxiliary input.</i>
18	Outdoor	A zone for outdoor areas where an activated alarm does not indicate intrusion into the house. <i>This zone generates and alarm when the system is armed both in AWAY and HOME modes. Events are sent to private phones and not to the monitoring station.</i>
19	Int./Delay	This zone type behaves as an Interior zone when the system is armed HOME and as Delayed zone when the system is armed AWAY.
20	Tamper	This is a 24 hour zone operating all of the time even when the system is disarmed. The tamper zone reports tamper alarm events from an external wired device.
21	Line Fail	This zone type is active 24 hours, even when the system is disarmed. It is used to report phone line fail troubles from an external wired receiver, connected to a phone line.
22	PSU Fail	This zone type is active 24 hours, even when the system is disarmed. It is used to report power supply fail troubles from an external wire device.
23	Panic	This zone type is active 24 hours, even when the system is disarmed. It is used to report panic events from panic devices to the monitoring station or private telephone numbers. A panic event generates an audible siren alarm.
24	Freezer Trbl	This is a 24 hour zone that operates all of the time, even when the system is disarmed. The freezer trouble zone reports a trouble from an external (3 <sup>rd</sup> party) temperature device if it detects a change in temperature. Freezer trouble beeps can also be produced by the siren if enabled. This zone type is often used with refrigerators with an external output temperature detector. If the temperature inside the refrigerator is above a defined value the refrigerator can trigger the output connected to the freezer trouble zone type and the WP panel will trigger a freezer trouble alert.
(*)	<i>These Zone types are useful mainly when you arm and disarm the system from inside the protected premises. If you arm and disarm the system from outside (without tripping any sensor), such as using a keyfob, it is preferred to use the other Zone Types.</i>	

### 4.4.3 Deleting a device










Step 1	Step 2	Step 3	Step 4	Step 5
Select "DELETE DEVICES" Option [1]	Select the respective device Group [2]	Select exact device you require to delete [3]	To delete the device: press the  key [4]	
 02:ZONES DEVICES ↓ DELETE DEVICES 	 CONTACT SENSORS ↓ MOTION SENSORS 	 Z01:Motion Sens  ID No. 120-1254 	<OFF> to delete  ↪ to step 2	

#### ① ① – Deleting a Device

- [1] Enter the **Installer Mode Menu**, select the **02.ZONES/DEVICES** option (see section 4.2) and then select the **DELETE DEVICES** option.
- [2] Select the respective group of the device you require to delete. For example, **MOTION SENSORS**.
- [3] Scroll the Device Group, identify (by zone and/or ID number) the exact device you require to replace, for example: **Z01: Motion Sensor > ID No. 120-1254** and press the  button.
- [4] The display prompts you **<OFF> to delete**. To delete the device, press the  (OFF) button.

### 4.4.4 Modifying or reviewing a device

To **Modify** or **Review** the device parameters proceed as follows:

Step 1	Step 2	Step 3	Step 4	Step 5
Select <b>MODIFY DEVICES</b> Option [1]	Select the respective device Group [2]	Select exact device you require to modify [3]	Select the Parameter you require to modify [4]	Modify the Parameter
 02:ZONES DEVICES ↓ MODIFY SENSORS 	 CONTACT SENSORS ↓ MOTION SENSORS 	 Z10:Motion Camra  ID No. 140-1737 	 Z10:LOCATION Z10:ZONE TYPE Z10:SET CHIME Z10:PARTITIONS Z10:DEV SETTINGS 	See ① [4] When done ↪ to step 2






#### ① ① – Modifying or Reviewing a Device

- [1] Enter the **Installer Mode menu**, select the **02:ZONES/DEVICES** option (see section 4.2) and then select the **MODIFY DEVICES** option.
- [2] Select the respective group of the device you require to review or modify. For example, **MOTION SENSORS**.
- [3] Scroll the Device Group, identify (by zone and/or ID number) of the exact device you require to modify or review, for example: **Z10:Motion Camra > ID No. 140-1737**.
- [4] From here on the process is same as the configuration process that follows the enrollment of that device. To continue, refer to Section 4.4.2 Adding a New Wireless Device Part B. When done, the display will show the next device of the same type (i.e. Motion camera).

## 4.4.5 Replacing a device

Use this option to replace a faulty device that is enrolled in the system with another device of the same type number (i.e. same first 3 digit of the ID number – see section 4.4.2.A) while keeping the same configuration of the original device. There is no need to delete the faulty device or to reconfigure the new device. Once enrolled, the new device will be configured automatically to the same configuration of the faulty (replaced) device.

To replace a device proceed as follows:

Step 1	Step 2	Step 3	Step 4	Step 5
Select <b>REPLACE DEVICES</b> Option [1]	Select the respective device Group [2]	Select exact device you require to replace [3]	Enroll the new device [4]	
 02:ZONES/DEVICES ↓ REPLACE DEVICES	 CONTACT SENSORS ↓ KEYFOBS	 K03:Keyfob ID No. 300-0307	 ENROLL NOW or ENTR ID:300-XXXX	 See ① [4].






### ① ① – Replacing a Device

- [1] Enter the **Installer Mode menu**, select the **02:ZONES/DEVICES** option (see section 4.2) and then select the **REPLACE DEVICES** option.
- [2] Select the respective group of the device you require to replace. For example, **KEYFOBS**.
- [3] Scroll the Device Group, identify (by zone and/or ID number) the exact device you require to replace, for example: **K03: Keyfob > ID No. 300-0307**.  
If you try to enroll a new device of a different type than the replaced device, the WP8360 will reject the new device and the Virtual Keypad display will read **WRONG DEV.TYPE**.  
When complete, the Virtual Keypad display shows the device details of the new device.

## 4.4.6 Configuring soak test mode

This option enables you to enter device zones into Soak Test mode.

To **Enable** the Soak Test proceed as follows:

Step 1	Step 2	Step 3	Step 4	Step 5
Select <b>ADD TO SOAK TEST</b> Option [1]	Select the respective device Group [2]	Select device zone number [3]	Select to enable or disable the Soak Test [4]	[5]
				

### ① – Enabling Soak Test mode









- [1] Enter the **Installer Mode menu**, select the **02.ZONES/DEVICES** option (see section 4.2) and then select the **ADD TO SOAK TEST** option.
- [2] Select the respective Group of the device you require to add the Soak Test. For example, **MOTION SENSORS**.
- [3] Scroll to select the specific device zone number.
- [4] Select between **Disable test** (default) or **Enable test**.
- [5] If set to **Enable Test** you must set the duration of the Soak Test before the Soak Test will start (see section 4.5.8). You can stop the test for the relevant zone by changing the setting to **Disable test** at any time during the testing period. All Soak test zones will be reset to start a new test upon occurrence of one of the following: 1) Power up of the system; 2) Setup of Factory Default; 3) Change in system Soak Time.

## 4.4.7 Defining configuration defaults for device settings



WP8360 enables you to define the **default parameters** used during enrollment and to change them whenever you require so that new devices enrolled into the system will be configured automatically with these default parameters without the need to modify the configuration of each new enrolled device. You can use a certain set of defaults for certain group of devices and then change the defaults for another group.

**IMPORTANT!** Devices that were already enrolled in the WP8360 system before the defaults have been changed will not be affected by the new default settings.

To define the default parameters of a device Group proceed as follows:

Step 1	Step 2	Step 3	Step 4	Step 5
Select <b>DEFINE DEFAULTS</b> Option [1]	Select the respective device Group [2]	Select the Default Parameter [3]	Select the new Default Setting [4]	[5]
 02:ZONES/DEVICES ↓ DEFINE DEFAULTS 	 CONTACT SENSORS ↓ MOTION SENSORS 	 Alarm LED Event Counter Disarm Activity ↓	 Low  High	 See ① [5] ↶ to Step 3

#### ① ① – Changing Defaults

- [1] Enter the **Installer Mode** menu, select the 02.ZONES/DEVICES option (see section 4.2) and then select the **DEFINE DEFAULTS** option.
- [2] Select the respective Group of the device you require to define the defaults for (for example, **MOTION SENSORS**).
- [3] Scroll the parameter list of the Device Group and select the Default Parameter you require to change, for example **Event Counter**. The list combines the parameters of all devices in the group, for example, the parameters of all types of Motion sensors.
- [4] In the example, the existing default setting of the **Event Counter** for enrolled motion sensors was **Low Sensitivity** (marked with ). To change it to **High**, scroll the menu until the display shows **High** and press the  button. The new default for the Event Counter parameter setting of Motion Sensors enrolled from now on will be **High**.
- [5] The new default does not affect motions sensors that were already enrolled before the change was made but only new motion sensors that will be enrolled in the WP8360 after the change is performed.

## 4.4.8 Updating devices after exiting Installer Mode

When exiting the **Installer Mode**, the WP8360 panel communicates with all devices in the system and updates them with the changes that have been performed in their Device Settings configuration. During the updating period, the display indicates **DEV UPDATING 018** where the number (for example, 018) is a countdown of the remaining number of devices yet to be updated.



## 4.5.2 Configuring arming/disarming and exit/entry procedures

The following table provides you with a detailed description of each option and its configuration settings. To select an option and change its configuration – refer to section 4.5.1.

Option	Configuration Instructions
<b>01:ENTRY DELAY1</b> <b>02:ENTRY DELAY2</b>	<p>Two different entry delays allow the user to enter the protected site (while the system is in the armed state) via dedicated exit/entry doors and routes without causing an alarm.</p> <p>Following entry, the user must disarm the control panel before the entry delay expires. Slow-rate warning beeps start sounding via the Configuration device (PC or mobile) once the door is opened, until the last 10 seconds of the delay, during which the beeping rate increases. The <b>ENTRY DELAY 1</b> and <b>ENTRY DELAY 2</b> options allow you to program the time length of these delays.</p> <p>Options: <b>00 seconds</b>; <b>15 seconds</b> (default for entry delay 2); <b>30 seconds</b> (default for entry delay 1); <b>45 seconds</b>; <b>60 seconds</b>; <b>3 minutes</b> and <b>4 minutes</b>.</p> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li><i>In some WP8360 variants, these menus are displayed in the Operation Mode only (see section 4.14).</i></li> <li><i>To comply with EN requirements, the entry delay must not exceed 45 sec.</i></li> </ol>
<b>03:EXIT DELAY</b>	<p>This option allows programming the time length of the exit delay. An exit delay allows the user to arm the system and leave the protected site via specific routes and exit/entry doors without causing an alarm. Slow-rate warning beeps start sounding via the Configuration device (PC or mobile) once the arming command has been given, until the last 10 seconds of the delay, during which the beeping rate increases.</p> <p>Options: <b>30 seconds</b>; <b>60 seconds</b> (default); <b>90 seconds</b>; <b>120 seconds</b>, <b>3 minutes</b> and <b>4 minutes</b>.</p>
<b>04:EXIT MODE</b>	<p>The <b>Exit Delay</b> time can be further adjusted according to your preferred exit route. The control panel provides you with the following <b>Exit Mode</b> options:</p> <p><b>A: normal</b> - The exit delay is exactly as defined.</p> <p><b>B: restrt+arm home</b> - Exit delay restarts when the door is reopened during exit delay. If no door was opened during exit delay <b>AWAY</b>, the control panel will be armed <b>HOME</b>.</p> <p><b>C: restart&gt;reentry</b> - The exit delay restarts when the door is reopened during exit delay. The restart occurs once only. Restarting the exit delay is helpful if the user re-enters immediately after going out to retrieve an item that he left behind.</p> <p><b>D: end by exit</b> - The exit delay expires (ends) automatically when the exit door is closed even if the defined exit delay time was not completed.</p> <p>Options: <b>normal</b> (default); <b>restrt+arm home</b>; <b>restart&gt;reentry</b> and <b>end by exit</b>.</p> <p><b>Note:</b> <i>In some WP8360 variants, this menu is displayed in the Operation Mode only (see section 4.14).</i></p>
<b>05:QUICK ARM</b>	<p>Define whether or not the user will be allowed to perform quick arming or not. Once quick arming is permitted, the control panel does not request a user code before it arms the system.</p> <p>Options: <b>OFF</b> (default) and <b>ON</b> (default in USA).</p>
<b>06:BYPASS ARM</b>	<p>Define whether or not the user will be allowed to manually <b>bypass</b> individual zones, or allow the system to perform automatic bypassing of open zones during the exit delay (i.e. <b>force arm</b>). If a zone is open and <b>forced arming</b> is not permitted, the system cannot be armed and NOT READY is displayed. If <b>no bypass</b> is selected, neither manual bypassing nor force arming is allowed which means that all zones must be secured before arming.</p> <p>Options: <b>no bypass</b> (default); <b>force arm</b> and <b>manual bypass</b> (default in USA).</p> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li><i>To comply with EN requirements, "manual bypass" must be selected.</i></li> <li><i>The option force arm is not applicable in the UK.</i></li> <li><i>A zone in Soak Test mode that is configured as bypass will trigger a test fail event if the system detects a potential alarm event.</i></li> <li><i>There is no limit of reported events when a bypass zone is in Soak Test mode.</i></li> </ol>
<b>07:LATCHKEY ARM</b>	<p>When <b>ON</b>, a <b>latchkey</b> message will be reported by SMS message to users (see Note) upon disarming by a <b>latchkey user</b> (users 5-8 or keyfob transmitters 5-8). This mode is useful when parents at work want to be informed of a child's return from school.</p> <p>Options: <b>OFF</b> (default) and <b>ON</b>.</p> <p><b>Note:</b> <i>To enable the reporting, you must configure the system to report <b>alt</b> events to Private users (Latchkey belongs to the <b>alerts</b> group of events). Refer to section 4.6.4 <b>REPORTED EVENTS</b> option in both <b>VOICE REPORT &amp; SMS REPORT</b> menus.</i></p>

Option	Configuration Instructions
<b>08:DISARM OPTION</b>	<p>Certain regulations require that when the system is armed in AWAY mode, it may not be disarmed from the outside of the house (such as by keyfobs) before entering the protected premises and activating an <b>Entry Delay</b> zone. To answer this requirement, the WP8360 provides you with the following configurable options to disarm the system:</p> <p><b>A:</b> At <b>any time</b> (default), the system can be disarmed at all times from all devices.</p> <p><b>B:</b> During entry delay, the system can be disarmed only using keyfob or prox operated devices (<b>on entry wrless</b>).</p> <p><b>C:</b> During entry delay by code, the system can be disarmed only using the Configuration device (PC or mobile) (<b>entry + away kp.</b>).</p> <p><b>D:</b> During entry delay, the system can be disarmed using keyfobs or by code using the Configuration device (PC or mobile) (<b>on entry all.</b>).</p> <p><b>Note:</b> <i>In some WP8360 variants, this menu is displayed in the Operation Mode only (see section 4.14).</i></p>
<b>09:ARMING KEY</b>	<p>Determine that, when activated, the Arming Key will arm AWAY or HOME.</p> <p>Options: <b>arm AWAY</b> (default) and <b>arm HOME</b>.</p>

### 4.5.3 Configuring zones

The following table provides you with a detailed description of each option and its configuration settings. To select an option and change its configuration – refer to section 4.5.1.

Option	Configuration Instructions
<b>21:SWINGER STOP</b>	<p>Define the number of times a zone is allowed to initiate an alarm within a single arming/disarming period (including tamper &amp; power failure events of detectors, etc.). If the number of alarms from a specific zone exceeds the programmed number, the control panel automatically bypasses the zone to prevent recurrent siren noise and excessive reporting to the Monitoring Station. The zone will be reactivated upon disarming, or 8 hours after having been bypassed (if the system remains armed).</p> <p>Options: <b>after 1 alarm</b> (default); <b>after 2 alarms</b> (default in USA); <b>after 3 alarms</b> and <b>no stop</b>.</p> <p><b>Note:</b> <i>When a detector is in Soak Test<sup>1</sup> mode and also set to bypass, Swinger Stop will not prevent the sending of events. This may result in excessive reporting of Soak Fail events.</i></p>
<b>22:CROSS ZONING</b>	<p>Define whether cross zoning will be active <b>ON</b> or inactive <b>OFF</b> (default). Cross zoning is a method used to counteract false alarms – an alarm will be initiated only when two adjacent zones (zone couples) are violated within a 30-second time window.</p> <p>This feature is active only when the system is armed AWAY and only with respect to the following zone couples: 18+19, 20+21, 22+23, 24+25, 26+27.</p> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li><i>1. If one of the two crossed zones is bypassed (see Section 4.5.2), the remaining zone will function independently.</i></li> <li><i>2. It is recommended that crossed zones will be only zones used for detection of burglary i.e. Zone Types: Entry/ Exit, Interior, Perimeter and Perimeter follower.</i></li> <li><i>3. If a cross zone is in Soak Test mode, then each zone of this zone couple functions independently.</i></li> </ol> <p><b>Important!</b> <i>Do not define cross zoning to any other zone types such as Fire, Emergency, 24h audible, 24h silent etc.</i></p>

## 4.5.4 Configuring alarms and troubles

The following table provides you with a detailed description of each option and its configuration settings. To select an option and change its configuration, refer to section 4.5.1.

Option	Configuration Instructions
<b>31: PANIC ALARM</b>	<p>Define whether or not the user will be allowed to initiate a Panic Alarm from keypads (by simultaneously pressing the two <b>Panic</b> buttons) or keyfobs (by simultaneously pressing the <b>Away</b> and <b>Home</b> buttons), and whether the alarm will be silent (that is, only reporting of the event) or audible (that is, the sirens will also sound).</p> <p>Options: <b>audible</b> (default); <b>silent</b> and <b>disabled</b>.</p>
<b>32: DURESS ALARM</b> (not applicable in UK)	<p>A duress (ambush) alarm message can be sent to the Monitoring Station if the user is forced to disarm the system under violence or menace. To initiate a duress message, the user must disarm the system using a duress code (2580 by default).</p> <p>To change the code, enter the new 4-digit of the new Duress code at the position of the blinking cursor or enter 0000 to disable the duress function and press <b>OK</b>.</p> <p><b>Notes:</b> <i>The system does not allow programming a duress code identical to an existing user code.</i></p>
<b>33: INACTIVE ALRT</b> Previously known as <b>NOT ACTIVE</b>	<p>If no sensor detects movement in interior zones at least once within the defined time window, an <b>inactive alert</b> event is initiated.</p> <p>Define the <b>time window</b> for monitoring the <b>lack of motion</b>.</p> <p>Options: <b>disabled</b> (default); <b>after: 3/6/12/24/48/72 hours</b></p>
<b>34: TAMPER ALARM</b>	<p>Define whether the Tamper switch protection of all zones and other peripheral devices (except the control panel) are <b>active</b> (default) or <b>not active</b>.</p> <p><b>Warning!</b> <i>If you select <b>not active</b>, be aware that no alarm or report will be initiated in case of tampering with any of the system peripheral devices.</i></p>
<b>35: AC FAIL REPRT</b>	<p>To avoid nuisance reporting in case of short interruptions in the house of AC power, the system reports an AC Fail message only if the AC power does not resume within a pre-determined time delay.</p> <p>Options: <b>after 5 minute</b> (default), <b>after 30 minute</b>, <b>after 60 minute</b> or <b>after 3 hours</b>.</p> <p><b>Note:</b> <i>To comply with EN requirements, the time delay must not exceed 60 min.</i></p>
<b>36: CONFIRM ALARM</b> Previously known as <b>CONFIRM TIME</b>	<p>If two successive alarm events occur within a specific time window, the system can be configured to report the second alarm event as a <b>confirmed alarm</b> (see section 4.6.3 option 61). You can activate this feature and set the respective time window.</p> <p>Options: <b>disable</b> (default in USA); <b>in 30/45/60</b> (default)/<b>90 minutes</b></p> <p><b>Note:</b> <i>In some WP8360 variants, this menu is displayed in the Operation Mode only (see section 4.14).</i></p>
<b>37: ABORT TIME</b>	<p>The WP8360 can be configured to provide a delay before reporting an alarm to the Monitoring Station (not applicable to alarms from 24H SILENT and EMERGENCY zones). During this delay period, the siren sounds but the alarm is not reported. If the user disarms the system within the delay time, the alarm is aborted. You can activate the feature and select the <b>Abort Time</b> interval.</p> <p>Options: <b>in 00</b> (default in USA)/<b>15/30</b> (default)/<b>45/60 seconds</b>; <b>in 2/3/4 minutes</b></p> <p><b>Note:</b> <i>In some WP8360 variants, this menu is displayed in the Operation Mode only (see section 4.14).</i></p>
<b>38: CANCEL ALARM</b> Previously known as <b>ALARM CANCEL</b>	<p>The WP8360 can be configured to provide a <b>Cancel Alarm</b> time window that starts upon reporting an alarm to the Monitoring Station. If the user disarms the system within that <b>cancel alarm</b> time, a <b>cancel alarm</b> message is sent to the Monitoring Station indicating that the alarm was canceled by the user.</p> <p>Options: <b>not active</b> (default in USA); <b>in 1/5</b> (default)/<b>15/60 minute(s)</b> and <b>in 4 hours</b>.</p>

Option	Configuration Instructions
	<p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>In some WP8360 variants, this menu is displayed in the Operation Mode only (see section 4.14).</li> <li>Since the Soak Test zone does not report an alarm event to the Monitoring Station, the WP8360 will not send a <b>cancel alarm</b> message to the Monitoring Station even if disarmed within the Cancel Alarm period.</li> </ol>
<b>39:ALARM RESET</b> Previously known as <b>RESET OPTION</b>	<p>The WP8360 provides you with the following configurable options for resetting the alarm condition and rearming the system:</p> <p>By the user as usual - <b>by user</b> (default). By the engineer (installer) by entering and exiting the <b>Installer Mode</b>, by entering and exiting the Event Log using the Installer Code or by accessing the system remotely via the PowerManage server using the Installer Code (<b>by engineer</b>). For accessing the system via the PowerManage server, see the PowerManage User's Guide.</p> <p><b>Note:</b> This feature is not applicable in the USA.</p>
<b>40:ABORT FIRE T.</b>	<p>Select the length of time allowed by the system to abort a Fire alarm. The WP8360 is able to provide an abort interval that starts upon detection of a Fire event. During this interval, the buzzer sounds a warning but the siren remains inactive and the alarm is not reported. If the user disarms the system within the allowed abort interval, the alarm is aborted.</p> <p>Options: <b>in 00 (default)/30/60/90 seconds</b></p>


## 4.5.5 Configuring siren functionality


The following table provides you with a detailed description of each option and its configuration settings. To select an option and change its configuration – refer to section 4.5.1.

Option	Configuration Instructions
<b>44:SIREN TIME</b> Previously known as <b>BELL TIME</b>	<p>Define the period of time the sirens will sound upon alarm.</p> <p>Options: <b>1 minute/90 seconds/3/4 minutes (default)/8/10/15/20 minute(s).</b></p> <p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>To comply with <b>EN</b> requirements, the <b>Siren Time</b> must not exceed 15 minutes.</li> <li>For Canada, the <b>Siren Time</b> must be set to 8 minutes.</li> </ol>
<b>45:STROBE TIME</b>	<p>Define the length of time the strobe light will flash upon alarm.</p> <p>Options: <b>5/10/20 (default)/40/60 minutes.</b></p>

## 4.5.6 Configuring audible and visual user interface

The following table provides you with a detailed description of each option and its configuration settings. To select an option and change its configuration – refer to section 4.5.1.

Option	Configuration Instructions
<b>53:MEMORY PROMPT</b>	<p>Define whether or not the user will receive <b>Memory</b> indication on the Virtual Keypad that an alarm has been activated. By pressing the  button in standby mode, you can view details of the alarm memory.</p> <p>Options: <b>ON</b> (default) and <b>OFF</b>.</p>
<b>54:LOW-BAT ACK</b>	<p>You can activate or deactivate the <b>Low Battery Acknowledge</b> requirement from the user whose keyfob's battery is low. For further information, see WP8360 User's Guide, Acknowledging keyfob low battery.</p> <p>Options: <b>OFF</b> (default) – acknowledge not needed; <b>ON</b> – acknowledge required.</p>
<b>56:SCREEN SAVER</b> With Partition disabled	<p>The Screen Saver option (when activated) replaces the status display on the virtual keypad with <b>WP8360</b> display if no key is pressed during more than 30 seconds.</p> <p>You can activate the Screen Saver and determine whether the status display will resume following any key press (<b>refresh by Key</b>) or by entering a code (<b>refresh by Code</b>). If <b>refresh by Key</b> is selected, the first pressing of any key (except Fire and Emergency) will produce the status display and the second press will perform the key function.</p> <p>Options: <b>OFF</b> (default); <b>refresh by Code</b> and <b>refresh by Key</b>.</p>

Option	Configuration Instructions
	<p><b>Notes:</b></p> <ol style="list-style-type: none"> <li>1. To comply with <b>EN</b> requirements, <b>refresh by code</b> must be selected.</li> <li>2. For Fire and Emergency keys, the first key press will produce the status display and will also perform the Fire/Emergency function.</li> </ol>
<b>56:SCREEN SAVER</b> With Partition enabled	<p>Certain regulations require that the system status display will not be exposed to unauthorized persons. The Screen Saver option (when activated) replaces the system status indication on the Virtual Keypad with idle text if no key is pressed during more than 30 seconds.</p> <p>You can activate the Screen Saver option and determine whether the status display will resume following any key press (<b>Text – by Key</b>) or by entering a code (<b>Text – by Code</b>). If <b>Text by Key</b> is selected, the first pressing of any key (except Fire and Emergency) will produce the status display and the second press will perform the key function. Regarding the Fire and Emergency keys, the first key press will produce the status display and will also perform the Fire/Emergency function.</p> <p>You can also determine that if no key is pressed during more than 30 seconds the date and time will appear on the display. You can determine that normal display will return after pressing the  button followed by entering user code (<b>Clock - by Code</b>) or after pressing any key (<b>Clock - by Key</b>).</p> <p>Options: <b>OFF</b> (default); <b>Text - by code</b>; <b>Text - by Key</b>; <b>Clock - by Code</b>; <b>Clock - by Key</b>.</p> <p><b>Note:</b></p> <ol style="list-style-type: none"> <li>1. To comply with <b>EN</b> requirements, <b>refresh by code</b> must be selected.</li> <li>2. For Fire and Emergency keys, the first key press will produce the status display and will also perform the Fire/Emergency function.</li> </ol>

#### 4.5.7 Configuring jamming and supervision (missing device)

The following table provides you with a detailed description of each option and its Options. To select an option and change its setting (configuration) – refer to section 4.5.1.

Option	Configuration Instructions															
<b>61:JAM DETECT</b>	<p>Define whether jamming (continuous interfering transmissions on the radio network) will be detected and reported or not. If any of the jam detection options is selected, the system will not allow arming under jamming conditions. The WP8360 provides several jam detect and reporting options to comply with the following standards:</p> <p><b>Note:</b> <i>Jamming is identified by the message <b>system jammed</b> displayed on the Virtual Keypad.</i></p> <table border="1"> <thead> <tr> <th>Option</th> <th>Standard</th> <th>Detection and Reporting occurs when:</th> </tr> </thead> <tbody> <tr> <td><b>UL 20/20</b></td> <td>USA</td> <td>There is continuous 20 seconds of jamming</td> </tr> <tr> <td><b>EN 30/60</b></td> <td>Europe</td> <td>There is an accumulated 30 seconds of jamming within 60 sec.</td> </tr> <tr> <td><b>Class 6 (30/60)</b></td> <td>British Standard</td> <td>Like EN (30/60) but the event will be reported only if the jamming duration exceeds 5 minutes.</td> </tr> <tr> <td><b>disabled</b></td> <td>(default)</td> <td>No jamming detection and reporting.</td> </tr> </tbody> </table> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>To comply with <b>EN</b> requirements, <b>EN 30/60</b> must be selected.</li> <li>To comply with <b>UK Class-6</b> requirements, <b>class 6 (30/60)</b> must be selected.</li> </ul>	Option	Standard	Detection and Reporting occurs when:	<b>UL 20/20</b>	USA	There is continuous 20 seconds of jamming	<b>EN 30/60</b>	Europe	There is an accumulated 30 seconds of jamming within 60 sec.	<b>Class 6 (30/60)</b>	British Standard	Like EN (30/60) but the event will be reported only if the jamming duration exceeds 5 minutes.	<b>disabled</b>	(default)	No jamming detection and reporting.
Option	Standard	Detection and Reporting occurs when:														
<b>UL 20/20</b>	USA	There is continuous 20 seconds of jamming														
<b>EN 30/60</b>	Europe	There is an accumulated 30 seconds of jamming within 60 sec.														
<b>Class 6 (30/60)</b>	British Standard	Like EN (30/60) but the event will be reported only if the jamming duration exceeds 5 minutes.														
<b>disabled</b>	(default)	No jamming detection and reporting.														
<b>62:MISSING REPRT</b> Previously known as <b>SUPERVISION</b>	<p>Define the time window for reception of supervision (keep alive) signals from the various wireless peripheral devices. If any device does not report at least once within the selected time window, a <b>MISSING</b> alert is initiated.</p> <p>Options: <b>after 1/2/4/8/12</b> (default) <b>hour(s)</b>; and <b>disabled</b>.</p> <p><b>Note:</b> <i>To comply with <b>EN</b> requirements, 1 hour or 2 hours must be selected.</i></p>															
<b>63:NOT READY</b>	<p>Define that in case of a supervision problem (i.e. a device is <b>missing</b> – see <b>62: MISSING REPRT</b>) whether the system will continue to operate as <b>normal</b> or the system status will become <b>Not Ready (upon missing)</b> for as long as the <b>Missing</b> trouble exists.</p> <p>Options: <b>normal</b> (default) and <b>if missing dev</b>.</p>															
<b>64:MISS/JAM ALRM</b>	<p><b>EN/UL standards</b> require that if a supervision (missing) or jamming trouble occurs during</p>															

Previously known as  
**BELL/REP.OPT**

AWAY arming, the siren will sound and the event will be reported as a tamper event.  
Define whether the system will behave according to **EN standard** or as **normal** (default).

**Note:** To comply with **EN requirements EN standard** must be selected.

**65:SMOK FAST MIS**

Determine that If the smoke detector does not report at least once within a time window of 200 seconds, a **MISSING** alert is initiated.

Options: **Disabled** (default) and **Enabled**.

## 4.5.8 Configuring miscellaneous features

The following table provides you with a detailed description of each option and its configuration settings. To select an option and change its configuration – refer to section 4.5.1.

Option	Configuration Instructions
<b>80:3<sup>rd</sup> PARTY H.A</b>	Determines if a third party home automation interface is connected or not Options: <b>disable</b> (default) or <b>enable</b>
<b>91:USER PERMIT</b>	User Permission enables you to determine whether access to the INSTALLER MODE requires the user's permission or not. If you select <b>enabled</b> , the installer will be able to access the system only through the user menu after the user code has been entered (see section 4.2). Options: <b>disable</b> (default) or <b>enable</b> (default in UK). <b>Note:</b> To comply with <b>EN requirements, Enable</b> must be selected.
<b>93:SOAK PERIOD</b>	Define the period of time for the Soak Test. Options: <b>Disable</b> (default), <b>7 days</b> , <b>14 days</b> or <b>21 days</b> . <b>Notes:</b> <ol style="list-style-type: none"><li>1. If set to one of the above pre-defined period of times, to be operational Soak Test mode must also be set to <b>Enable Test</b> from the <b>02:ZONES/DEVICES</b> menu (see Section 4.4.6).</li><li>2. If a change is made to the period of time of the Soak Test while the zone is currently being tested, this will restart the Soak Test.</li><li>3. The start of the Soak Test period is defined in the factory from 9 AM (09:00).</li></ol>

## 4.6 Communication









### 4.6.1 General guidance – Communication flow-chart & menu options

The COMMUNICATION menu enables you to configure and customize the communication and reporting of alarm, troubles and other system events for monitoring companies or private users according to your local requirements and personal preferences. WP8360 offers a variety of communication means including Cellular GSM, GPRS, EMAIL, MMS or SMS, and IP via broadband internet connection.

The **04.COMMUNICATION** menu contains several sub-menu options, each covering a group of configurable features and parameters related to the communication and reporting as follows (see detailed list in Step 3 of the chart below):

Option	Description of features and parameters	Section
<b>2:GSM/GPRS/SMS</b>	Contains configurable features and parameters related to the Cellular connection of the WP8360 system.	4.6.2
<b>3:C.S. REPORTING</b>	Contains configurable features and parameters related to Reporting of event messages to Monitoring Stations via cellular or IP broadband communication.	4.6.3
<b>4:PRIVATE REPORT</b>	Contains configurable features and parameters related to Reporting event messages to Private Users via email, MMS or SMS.	4.6.4
<b>5:MOTION CAMERA</b>	Contains configurable features and parameters related to Motion Cameras for Video Alarm Verification.	4.6.5
<b>6:UP/DOWNLOAD</b>	Contains configurable connection information, access permission and security codes related to the Upload/Download procedures via GPRS.	4.6.6
<b>7:BROADBAND<sup>1</sup></b>	Contains DHCP Client settings, enables to enter LAN parameters, to reset broadband module and to enter LAN parameters.	4.6.7
<b>8:WiFi</b>	Contains configurable Wi-Fi connection parameters. Wi-Fi connection is only used when a wired connection is not available. From V19.4 onwards WP8360 has the ability to connect to an internet router by Wi-Fi to communicate and report alarms, troubles, and other system events. Wi-Fi client configuration is available through the ConnectAlarm application.	

To enter the **04.COMMUNICATION** menu and to select and configure an option, proceed as follows:

Step 1	Step 2	Step 3	Step 4
Select <b>COMMUNICATION</b>	Select Communication Sub-menu option	Select the <b>Communication</b> Parameter you require to configure	
 <b>INSTALLER MODE</b> ↓ <b>04.COMMUNICATION</b> 	 <b>2:GSM/GPRS/SMS</b>  ↓ <b>3:C.S. REPORTING</b>  ↓ (*) These options are available only to the "Master Installer"	 <b>SMS REPORT</b> GPRS APN GPRS USERNAME  <b>SIM PIN CODE</b>  <b>01:REPORT EVENTS *</b> 02:1st RPRT CHAN 05:DUAL REPORT 11:RCVR1 ACCOUNT * 12:RCVR2 ACCOUNT * 21:IP RCVR 1 * 22:IP RCVR 2 *  26:SMS RCVR 1 * 27:SMS RCVR 2 * 28 : RCVR 1 DNS 29 : RCVR 2 DNS  <b>64:SYST.INACTIVE</b> <b>66:24H ZONE RPRT</b>	 <b>GPRS PASSWORD</b>  <b>NETWORK ROAMING</b> <b>REQUEST OPERATOR</b> <b>OP. BLACK LIST</b> <b>NETWORK TYPE</b> <b>GPRS ALWAYS ON</b> <b>GSM KEEP ALIVE</b> <b>TRANS. PROTOCOL</b> <b>PLINK GPRS</b>  <b>47:GSM RETRIES</b> <b>48:BB IP RETRIES</b> <b>51: AUTO-TST LOOP</b> <b>52:AUTO-TST TIME</b> <b>53:COM.FAIL RPRT</b> →GSM/GPRS FAIL →BROADBAND FAIL <b>61:RPRT CNF ALRM</b> <b>62:RECENT CLOSE *</b> <b>63:ZONE RESTORE</b>
			See
			4.6.2
			4.6.3

<sup>1</sup> The name of the product is PowerLink3 IP Communicator

Step 1	Step 2	Step 3	Step 4
Select <b>COMMUNICATION</b>	Select Communication Sub-menu option	Select the <b>Communication</b> Parameter you require to configure	
	4:PRIVATE REPORT	SMS REPORT →REPORTED EVENTS →1st SMS tel# →2nd SMS tel# →3rd SMS tel# →4th SMS tel# →SMS Permission	EMAIL BY SERVER →1st E-MAIL →2nd E-MAIL →3rd E-MAIL →4th E-MAIL
	↓	SMS/MMS BY SRVR →1st SMS/MMS →2nd SMS/MMS →3rd SMS/MMS →4th SMS/MMS	4.6.4
	5:MOTION CAMERA	VIEW ON DEMAND VIEW TIME WINDOW VIEW OTHER ALARM UPLOAD FILM KIDS COME HOME	4.6.5
	↓		
	6:UP/DOWNLOAD	UP/DOWNLOAD PARAM →Remote access →Mast. UL/DL code →Inst. UL/DL code →UL/DL Modes	GPRS UP/DOWNLOAD →Panel SIM Tel. # →1st caller ID# →2nd caller ID#
	↓		4.6.6
	7:BROADBAND <sup>1</sup>	DHCP Client Manual IP PLNK curr.params →Curr.IP address →Curr.subnet mask →Current Gateway →Current Path	RESET MODULE
	↓		4.6.7
	8:WiFi	ACCESS-POINT →A.POINT MOE →START A.POINT →STOP A.POINT	4.6.8

## 4.6.2 Configuring GSM-GPRS (IP) - SMS cellular connection

The GSM/GPRS module is capable of communicating with the Monitoring station receiver by GPRS or SMS channels. The GPRS channel is always enabled. If for any reason the GPRS module is not able to communicate successfully, the message is sent by SMS.

**04:COMMUNICATION** **2:GSM/GPRS/SMS** **PLINK GPRS** **MENU**

Enter **2:GSM/GPRS/SMS**, select the menu you require to configure (see guidance above and in section 4.6.1), then refer to the table below which provides you with detailed explanations and configuration instructions for each option.

Option	Configuration Instructions
<b>SMS REPORT</b>	Define whether the system will report events to the Monitoring Stations' <b>SMS receivers</b> via the <b>SMS</b> Channel. For further information, see section 4.6.3 options 26 & 27. Options: <b>disable</b> (default); <b>enable</b> .

**GPRS APN** Enter the name of the **APN Access Point** used for the internet settings for the **GPRS**

<sup>1</sup> The name of the product is PowerLink3 IP Communicator

(up to 40 digits string).

**Note:** To enter the APN Access Point, use the **String Editor** in section 4.8.1.

---

**GPRS USERNAME**

Enter the **Username** of the **APN** used for **GPRS** communications (up to 30 digits string).

**Note:** To enter the Username, use the **String Editor** in section 4.8.1.

---

**SIM PIN CODE**

Enter the **PIN code** of the **SIM card** installed in the **GSM** module (up to 8 numerical digits).

**Note:** To enter the numerical PIN code, use the numerical keyboard.

---

**GPRS PASSWORD**

Enter the **Password** of the **APN** used for **GPRS** communications (up to 16 digits string).

**Note:** To enter the Password, use the **String Editor** in section 4.8.1.

---

**NETWORK ROAMING**

A new cellular roaming algorithm to support cases where the panel is successfully connected to a network but GPRS connection has timed-out.

With the new roaming algorithm, in such cases the panel attempts to connect to a different network.

**Modem roam en:** when selected, the panel uses the internal Cellular modem's algorithm for roaming. (en) = enable

**Roam disable:** when selected, roaming is not allowed. Only the 'Home' network is accepted.

**Manual roam en :** when selected, the panel uses its own algorithm to select the best cellular operator. (en) = enable

**Lock network:** when selected, the panel uses the operator defined in Requested Network. (en) = enable

---

**REQUEST OPERATOR**

Specifies a preferred network (for example, Vodafone) that the panel should attempt to register with if the signal strength is above the Minimum CSQ value. Where a Requested Operator is specified, the panel should attempt to return to this network on every other attempt.

**Note:** Contains an editable line to enter up to 6 numbers MCC (Mobile country code) +MNC (Mobile network code)

---

**OP. BLACK LIST**

Used to avoid certain networks, for example, when a high signal strength operator is unreliable or the device oscillates between networks (country borders).

**Note:** Contains an editable line to enter up to 6 numbers MCC (Mobile country code) +MNC (Mobile network code)."

---

**NETWORK TYPE**

Define whether to use a 2G or 3G network or whether to enable the panel to use a 3G network as first priority or a 2G network as second priority.

Options: **automatic** (default); **3G**; **2G**.

---

**GPRS ALWAYS ON**

Define whether the control panel will stay continuously connected **enabled**, via GPRS communication, or disconnect **disabled** (default), after each report session.

---

**GSM KEEP ALIVE**

Some GSM Service providers tend to disconnect the GSM connection if the user has not initiated any outgoing telephone calls during the last 28 days. To prevent from disconnecting the GSM connection, you can configure the system to generate a **keep alive GSM** call **every 28 days** sending a test message either to the first SMS number (if exists) or alternatively first private telephone number.

Options: **Disable** (default) or **Every 28 days**.

---

**TRANS. PROTOCOL**

Select the IP protocol used to transfer data over the internet/GPRS.

Options: **TCP** (default); or **UDP**.

## PLINK GPRS

The GSM/GPRS module is capable of communicating with the monitoring station receiver by GPRS or SMS channels. The GPRS channel is always enabled. If it fails, the GPRS module will try to communicate via SMS.

**Limited (default)** – Plink uses GPRS only when the wired Ethernet channel is not functional, and for event and film reports (keep-alive and NTP mechanism will not use the GPRS channel).

**Unlimited** – Plink uses GPRS only when the wired Ethernet channel is not functional, and for any other purpose.

**Disable** – Plink does not use GPRS for event reports, film reports, or the home automation app.

## 4.6.3 Configuring event reporting to monitoring stations





The WP8360 control panel is designed to report alarm, alerts, troubles and other events and messages to two Monitoring Stations C.S.1 and C.S.2 via Cellular i.e. GPRS (IP) & SMS or Broadband IP communications channels. In this section you configure and define all parameters and features required for the reporting of the event messages to Monitoring Stations such as:



- The events reported to each of the two Monitoring Stations C.S.1 and C.S.2 and corresponding backups.
- The communication means (channel) used for the reporting and the backup means (channel) in case of failure.
- The customer's (subscriber) account number(s) to be reported to each Monitoring Station.
- The IP addresses, SMS numbers and reporting formats of the corresponding alarm receivers at the two Monitoring Stations, C.S.1 and C.S.2, and the number of reporting retry attempts in case of failure to report.
- The communication Auto Tests and communication Fail reports.
- The reporting of certain system function events such as Confirmed Alarm, Recent Close, Zone Restore and System Not-Used.

04:COMMUNICATION ... 3:C.S.REPORTING ... MENU required

Enter **3:C.S.REPORTING**, select the menu you require to configure (see guidance above and in section 4.6.1), then refer to the table below which provides you with detailed explanations and configuration instructions for each option.

Option	Configuration Instructions												
<b>01:REPORT EVENTS</b>	<p>Define which events (i.e. <b>Alarms (alm)</b>; <b>Open/close (o/c)</b>; <b>Alerts (alrt)</b>; <b>All events (all)</b>; <b>Maintenance</b> and <b>Troubles</b>) will be reported to the Monitoring Stations.</p> <p>The minus (-) symbol means less/except, for example <b>all (-alrt)</b> means <b>all</b> events except <b>alerts</b>.</p> <p>The asterisk (*) is a separator between events reported to <b>Monitoring Station 1</b> (C.S.1) and events reported to <b>Monitoring Station 2</b> (C.S.2). For detailed and more complete explanation see the <b>Event Reporting Chart</b> at the end of this section.</p> <table border="1"><tr><td>Options:</td><td><b>all-o/c* backup</b> (default)</td><td><b>all-o/c*o/c</b></td><td><b>disable report</b></td></tr><tr><td></td><td><b>all *all</b></td><td><b>all(-alrt)*alrt</b></td><td><b>all *backup</b></td></tr><tr><td></td><td><b>all-o/c*all-o/c</b></td><td><b>alm*all(-alm)</b></td><td></td></tr></table> <p><i>Note: Alarm events (alm) have highest priority and Alert events (alrt) have lowest priority.</i></p>	Options:	<b>all-o/c* backup</b> (default)	<b>all-o/c*o/c</b>	<b>disable report</b>		<b>all *all</b>	<b>all(-alrt)*alrt</b>	<b>all *backup</b>		<b>all-o/c*all-o/c</b>	<b>alm*all(-alm)</b>	
Options:	<b>all-o/c* backup</b> (default)	<b>all-o/c*o/c</b>	<b>disable report</b>										
	<b>all *all</b>	<b>all(-alrt)*alrt</b>	<b>all *backup</b>										
	<b>all-o/c*all-o/c</b>	<b>alm*all(-alm)</b>											
<b>02:1st RPRT CHAN</b>	<p>If the system is equipped also with Cellular communicators, you <u>must</u> define which of the communicating channels (i.e. Cellular or Broadband) the system will use as the main channel (i.e. 1<sup>st</sup> priority) for reporting event messages to Monitoring Stations.</p> <p>Enter the <b>1<sup>st</sup> RPRT CHAN</b>; option and define which of the communication channels the system will use as the main reporting channel.</p> <p>Options: <b>broadband first</b> (default); <b>disable</b>; and <b>cellular first</b>.</p> <p><b>Important:</b> <i>If the selected main reporting channel fails, the system will use the other communication channel to report event messages to Monitoring Stations. If none is selected, the reporting to Monitoring Stations will be disabled.</i></p>												
<b>05:DUAL REPORT</b>	<p>Define whether or not to report events using broadband and cellular communication channels.</p> <p>Options: <b>disable</b> (default); <b>broadbnd &amp; cell</b>.</p>												
<b>11:RCVR1 ACCOUNT</b>	<p>Enter the respective 1<sup>st</sup> Account (subscriber) number (11:RCVR 1 ACCOUNT) that will identify</p>												

Option	Configuration Instructions																								
<b>12:RCVR2 ACCOUNT</b>	<p>your specific alarm system to the <u>1<sup>st</sup></u> Monitoring Station (designated as RCVR1 or RCV1) and a <u>2<sup>nd</sup></u> Account (subscriber) number (12:RCVR 2 ACCOUNT) that will identify the system to the <u>2<sup>nd</sup></u> Monitoring Station (designated as RCVR2 or RCV2). Each of the Account numbers consists of 6 hexadecimal digits.</p> <p>To enter Hexadecimal digits, use the following table:</p> <table border="1"> <thead> <tr> <th></th> <th colspan="7">Entering Hexadecimal Digits</th> </tr> <tr> <th>Digit</th> <th>0....9</th> <th>A</th> <th>B</th> <th>C</th> <th>D</th> <th>E</th> <th>F</th> </tr> </thead> <tbody> <tr> <th>Keying</th> <td>0....9</td> <td>[#]→[0]</td> <td>[#]→[1]</td> <td>[#]→[2]</td> <td>[#]→[3]</td> <td>[#]→[4]</td> <td>[#]→[5]</td> </tr> </tbody> </table>		Entering Hexadecimal Digits							Digit	0....9	A	B	C	D	E	F	Keying	0....9	[#]→[0]	[#]→[1]	[#]→[2]	[#]→[3]	[#]→[4]	[#]→[5]
	Entering Hexadecimal Digits																								
Digit	0....9	A	B	C	D	E	F																		
Keying	0....9	[#]→[0]	[#]→[1]	[#]→[2]	[#]→[3]	[#]→[4]	[#]→[5]																		
Master Installer only																									
<b>21:IP RCVR 1</b> <b>22:IP RCVR 2</b>	<p>The WP8360 can be programmed to report the event messages defined in Report Events option (option 01) to two IP Receivers, PowerManage model. IP reporting can be performed via GPRS (IP) channel using SIA IP format or via Broadband IP channel using SIA IP.</p> <p>Enter the two IP addresses (000.000.000.000) of the IP Receiver 1 located at the <u>1<sup>st</sup></u> Monitoring Station (21:IP RCVR 1) and IP Receiver 2 located at the <u>2<sup>nd</sup></u> Monitoring Station (22:IP RCVR 2).</p> <p><b>Note:</b> You must enter the IP address of the receiver, even if you enter the Domain Name System (DNS) server name where the receiver is installed. See option <b>28: RCVR 1 DNS</b> and <b>29: RCVR 2 DNS</b> for details on how to enter the DNS name.</p>																								
Master Installer only																									
<b>26:SMS RCVR 1</b> <b>27:SMS RCVR 2</b>	<p>If equipped with GSM module, the WP8360 can be programmed to report the event messages defined in Report Events option (option 01) to two SMS Receivers via the GSM SMS channel using a special SMS text format. For further details concerning the SMS text format please contact DSC.</p> <p>Enter the two telephone numbers (including area code – maximum 16 digits).of the SMS Receiver 1 located at the <u>1<sup>st</sup></u> Monitoring Station (26:SMS RCVR 1) and SMS Receiver 2 located at the <u>2<sup>nd</sup></u> Monitoring Station (27:SMS RCVR 2).</p> <p><b>Note:</b> To enter the international prefix (+) at the <u>1<sup>st</sup></u> digit – key-in [#]→[1].</p>																								
Master Installer only																									
<b>28:RCVR 1 DNS</b> <b>29:RCVR 2 DNS</b>	<p>Specifies the DNS name of the servers where the IP receivers are installed. Enter the DNS name of the servers where receiver 1 and receiver 2 are installed; the name can contain a maximum of 32 characters. The DNS name one (28: RCVR 1 DNS) must be resolved to IP receiver one (21: IP RCVR1) and the DNS name two (29: RCVR 2 DNS) must be resolved to IP receiver two (22: IP RCVR2).</p> <p><b>Note:</b> If you enter the DNS name you must also enter the corresponding IP receiver's address. See option <b>21: IP RCVR 1</b> and <b>22: IP RCVR 2</b> for details on how to enter the IP receiver's address.</p>																								
Master Installer only																									
<b>47:GSM RETRIES</b>	<p>Define the number of times the system will retry to report to the Monitoring Station in case of failure to report via the cellular connection - GPRS (IP) and SMS.</p> <p>Options: <b>2 attempts; 4 attempts</b> (default); <b>8 attempts; 12 attempts</b> and <b>16 attempts</b>.</p>																								
<b>48:BB IP RETRIES</b>	<p>Define the number of times the system will retry to report to the Monitoring Station in case of failure to report via the Broadband Module connection.</p> <p>Options: <b>2 attempts; 4 attempts</b> (default); <b>8 attempts; 12 attempts</b> and <b>16 attempts</b>.</p>																								
<b>51: AUTO-TST LOOP</b>	<p>To verify a proper communication channel, the WP8360 can be configured to send a test event to the Monitoring Station periodically. You can set the interval between the consecutive test events or disable the automatic sending of this event entirely. If the interval is set for every one day or more then the exact hour of reporting can be selected with option 52.</p> <p>Options: <b>test OFF</b> (default); <b>every 1/2/5/7/14/30 day(s)</b>; and <b>every 5 hours</b>.</p>																								
<b>52:AUTO TST TIME</b>	<p>Enter the exact time (<b>auto test time</b>) during the day at which the Auto Test message (if enabled in option 51) will be sent to the Monitoring Station.</p> <p><b>Note:</b> If the AM/PM format is used, you can set the <b>AM</b> digit with the   button and the <b>PM</b> digit with the   button.</p>																								
<b>53:COM.FAIL RPRT</b>	<p>Determine whether a failure in the system communication channel i.e. GSM/GPRS will be</p>																								

Option	Configuration Instructions
→ <b>GSM/GPRS FAIL</b>  (Return)	reported or not, and the time delay between detection of the failure and reporting of the failure event to the Monitoring Station. A trouble event (for example, GSM line fail) is stored in the event log.
→ <b>BROADBAND FAIL</b>  (Return)	Determines whether a failure in the broadband communication channel is reported or not. You can specify the time delay between the detection of the failure and reporting of the failure event to the Monitoring Station. This event is stored in the event log.
Previously known as LINE FAIL REPORT	Options: <b>after 1/2/5/15/30 min, 1/3/6 hours, and do not report</b> (default).
<b>61:RPRT CNF ALRM</b>	Define whether the system will report whenever 2 or more events (confirmed alarm) occur during a specific period or enable the report and bypass the detector. Options: <b>rprt disabled</b> (default), <b>rprt ena+bypass</b> and <b>rprt enabled</b> <b>Note:</b> <i>In some WP8360 variants, this menu is displayed in the Operation Mode only.</i>
<b>62:RECENT CLOSE</b>	False alarms may occur if users do not exit the premises within the exit delay period, resulting in a false alarm a short time later. In such cases, inform the Monitoring Station that the alarm occurred shortly after the system was armed (this event is known as <b>Recent Close</b> ). The report enabled option sends a recent closing report to the Monitoring Station if an alarm occurs within 2 minutes from the end of the exit delay. Options: <b>report disabled</b> (default) and <b>report enabled</b>
<b>63:ZONE RESTORE</b>	Some Monitoring Stations require that following an alarm event from a specific zone, the system will also report when the alarming zone has restored to normal. Options: <b>report enabled</b> (default) and <b>report disabled</b>
<b>64:SYST.INACTIVE</b>	The WP8360 can report a <b>System Inactive</b> event message (CID event 654) to the Monitoring Station if the system is not used (armed) during a predefined time period. Options: <b>report disabled</b> (default); <b>after 7/14/30/90 days</b> .
<b>66:24H ZONE RPRT</b> Applicable in UK only	Define whether 24 hour (silent and audible) zones will function as normal 24 hour zones or as panic zones. Options: <b>audible as panic; silent as panic; both as panic;</b> and <b>both burglary</b> (default).

## Event reporting chart

To simplify the configuration of reporting system events to Monitoring Stations, the event messages are divided into 4 Event Groups as described in the table below. Due to lack of space in the display, the following abbreviations are used: **alarm**, **alrt**, **o/c**, and **all** (all events).

Event Group	Abbr.	Events Messages Reported
Alarms	<b>alarm</b>	Fire, CO, Burglary, Panic, Tamper
Open/close	<b>o/c</b>	Arming AWAY, Arming HOME, Disarming
Alerts	<b>alrt</b>	No-activity, Emergency, Latchkey
Trouble	-	All other Trouble events not indicated above, e.g. Missing, Jamming, Communication Fail, Low Battery, AC failure etc.

**Note:** *Alarms group has the highest priority and Alerts group has the lowest priority.*

The WP8360 allows you also to select which event groups will be reported to each of the two Monitoring Stations. The table below describes the available reporting options. The minus (-) symbol means "but/less/except" e.g. **all(-alrt)** means **all** events except **alrt**. The asterisk (\*) is a separator between event messages reported to **Monitoring Station 1 (C.S.1)** and event messages reported to **Monitoring Station 2 (C.S.2)**.

Available Reporting Options	Events Reported to C.S. 1	Events reported to C.S. 2
<b>all * backup</b>	All	All, only if C.S.1 does not respond
<b>all-o/c * backup</b>	All but open/close	All but open/close, only if C.S. 1 does not respond
<b>all * all</b>	All	All
<b>all-o/c * all-o/c</b>	All but open/close	All but open/close
<b>all-o/c * o/c</b>	All but open/close	Open/close
<b>all(-alrt) * alrt</b>	All but alerts	Alerts
<b>alarm * all(-alarm)</b>	Alarms	All but alarms
<b>disable report</b>	None	None

**Note:** *all means that all 5 Groups are reported including trouble messages – sensor / system low battery, sensor inactivity, power failure, jamming, communication failure.*

## 4.6.4 Configuring event reporting to private users

The WP8360 system can be programmed to send various SMS event notifications such as alarm, arming or trouble events, if a GSM option is installed. The system can send the messages also to 4 emails, MMS and SMS telephone numbers via the server. These reports can be programmed either instead of or in addition to the reports transmitted to the monitoring company. In this section you configure:

- The specific events you require the system to report.
- The 1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup>, and 4<sup>th</sup> SMS numbers of the private subscribers.
- Event notification messages to be sent to 1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup>, and 4<sup>th</sup> private emails and private MMS and SMS telephone numbers via the server.

SMS Permission defines if the panel accepts SMS commands from any number or only from known numbers. For a detailed description of this menu options, refer to the User's Guide, Receiving SMS notifications. To select and configure an option follow the instructions below. Additional guidance is provided in section 4.6.1.

04:COMMUNICATION   ...  4:PRIVATE REPORT   ...  MENU required 

The 4:PRIVATE REPORT menus and sub-menus configuration is shown in the table in section 4.6.1.

## 4.6.5 Configuring motion cameras for visual alarm verification

The WP8360 can communicate to Monitoring Stations (equipped with PowerManage server) with image clips captured by Motion Cameras (models PGx934 and PGx944). The Monitoring Station can use the video clips for verification of Burglary alarms detected by the Motion Cameras. The system can be configured to capture image clips also upon occurrence of Non-Burglary alarms (Fire, Duress, Emergency, and Panic). The server can then forward the images to the management computer of the Monitoring Station or to 4 private emails and/or 4 mobile phones by MMS images. In addition, the Monitoring Station can log into the PowerManage server and request the system to provide image clips On Demand and to forward them as defined in the PowerManage application. To protect customers' privacy, the WP8360 can be customized to enable the On Demand View only during specific system modes (Disarm, Home, and Away), and also to a specific time window following an alarm event.

04:COMMUNICATION   ...  5:MOTION CAMERAS   ...  MENU required 

Enter 5:MOTION CAMERAS, select the menu you require to configure (see guidance above and in section 4.6.1), then refer to the table below which provides you with detailed configuration instructions.

Option	Configuration Instructions
<b>VIEW ON DEMAND</b>	By enabling the <b>On Demand View</b> , you can determine during which arming modes (system states) the <b>On Demand View</b> will be permitted. In the next option VIEW TIME WINDOW you can determine when, during the permitted arming modes, the On Demand View will be enabled. Options: <b>disabled</b> (default); <b>in all modes</b> ; <b>in AWAY only</b> ; <b>in HOME only</b> ; <b>in HOME &amp; AWAY</b> ; <b>DISARM &amp; AWAY</b> ; <b>DISARM &amp; HOME</b> ; and <b>in DISARM only</b> .
<b>VIEW TIME WINDOW</b> VIEW TIME WINDOW menu appears only if VIEW ON DEMAND was enabled	If the <b>On Demand View</b> is enabled in the previous option, you can further determine whether the <b>On Demand View</b> will be possible at any time during the selected arming modes (Always) or restricted only to a specific limited time window that follows an alarm event. Options: <b>Always</b> (default); <b>Alarm + 5 min.</b> ; <b>Alarm + 15 min.</b> ; <b>Alarm + 1 hour</b>
<b>VIEW OTHER ALARM</b>	Define whether the system will capture and forward image clips also upon occurrence of Non-Burglary alarms (Fire, Duress, Emergency, and panic). Options: <b>Enable</b> (default); <b>Disable</b> .
<b>KIDS COME HOME</b>	Define that upon PIR-camera detection, the system will send up to 4 images to a 3rd party server if the system is disarmed via keypad or proximity tag by latchkey users 5 to 8 and only when the system was in Entry Delay or the Abort Time was enabled. Options: <b>Enable</b> ; <b>Disable</b> (default). <b>Note:</b> At least one PIR camera must be defined as one of the following zone types: Perim-Follow / Inter-Follow / Exit/Entry 1 / Exit/Entry 2.
<b>UPLOAD FILM</b>	Define whether to enable / disable the sending of images to the PowerManage server. Options: <b>Enable</b> (default); <b>Disable</b> .

## 4.6.6 Configuring upload / download remote programming access permissions

Using a PC, the WP8360 can be configured (by upload/download) either locally or from remote via GPRS cellular communication.

**Local programming** can be performed by directly connecting the computer to the panel's USB port using the Configurator software or AlarmInstall app in Direct Mode.

**Remote programming via GPRS** is performed using a PowerManage server and AlarmInstall app. The PowerManage server calls from a cellular modem to the Panel's SIM card number. The panel checks the caller ID and if identical with any of the two callers ID 1 or 2 programmed in the **GPRS UP/DOWNLOAD** menu (see table below), the panel initiates a GPRS connection with the respective IP Receiver 1 or 2 (as configured in section 4.6.3 options 21 & 22). When connection is established, the monitoring company can perform the upload/download procedure via the established secured GPRS connection. For further information refer to the PowerManage User's Guide.

In this section you can configure the access permissions (i.e. security codes and identification) and determine the functionality of the upload/download procedures via GPRS channel.

04:COMMUNICATION ... 6:UP/DOWNLOAD ... MENU required

Enter **6:UP/DOWNLOAD**, select the menu to configure (see guidance above and in section 4.6.1), then refer to the table below for configuration instructions.

Option	Configuration Instructions
<b>UP/DOWNLOAD PARAM</b>	Configure the Upload/Download functionality. The functionality is determined through a sub-menu of the <b>UP/DOWNLOAD</b> option as shown below. <u>To program:</u> Press  to enter the <b>UP/DOWNLOAD</b> sub menu and then select and configure each of the sub-menu options as shown below. When done, press  to return.
→ <b>Remote access</b>	Enable or disable the <b>remote access</b> to the system. If disabled, the system cannot be <b>accessed</b> remotely thereby inhibiting the Upload/Download and the Remote Control via GSM analog communication channel.  Options: <b>enabled</b> (default); <b>disabled</b> .
→ <b>Mast. UL/DL code</b>	Enter the 4-digit <b>password</b> (Master Installer download code) code that will allow the <b>Master Installer</b> to access the system remotely and upload/download data to the WP8360 panel.  <b>Note:</b> 0000 is not a valid code and must not be used.
→ <b>Inst. UL/DL code</b>	Enter the 4-digit <b>password</b> (Installer download code) code that will allow the <b>Installer</b> to access the system from remote and upload or download data into the WP8360 panel.  <b>Notes:</b> 1. 0000 is not a valid code and must not be used. 2. The installer can configure via UL/DL only the options he is authorized to configure from the control panel.
→ <b>UL/DL modes</b>	Define whether the downloading/uploading can be performed in Disarm mode (state) only or in all modes (Away, Home, and Disarm).  Options: <b>in all modes</b> (default) or <b>in DISARM only</b> .

(Return)

## GPRS UP/DOWNLOAD

Configure the Upload/Download functionality via GPRS. The functionality is determined through a sub-menu of the **GPRS UP/DOWNLOAD** option as shown below.

To program:

Press **OK** to enter the **GPRS UP/DOWNLOAD** sub menu and then select and configure each of the sub-menu options as shown below. When done, press **↩** to return.

→ **Panel SIM Tel.#**  
(Previously known as  
"My SIM Tel.#")

Enter the WP8360 **SIM card** telephone number. The PowerManage server at the Monitoring Station sends an SMS or voice message to this number for the panel to call back the PowerManage server via GPRS for initiating the uploading / downloading process.

Enter the SIM card telephone number of the panel's GSM module.

→ **1st caller ID#**

Enter the **Caller ID** (i.e. telephone number) from which **Monitoring Station #1** (C.S.1) / **Monitoring Station #2** (C.S.2) calls the control panel for initiating the Up/Download process. If the sender's Caller ID matches with the 1<sup>st</sup> caller ID# / 2<sup>nd</sup> caller ID#, the WP8360 will call back the PowerManage server using **IP RCVR 1** / **IP RCVR 2** address as configured in Section 4.6.3, options 21 and 22.

→ **2nd caller ID#**

**Note:** Caller ID#1/ID#2 must contain at least 6 digits otherwise the process will not work.

**↩** (Return)

## 4.6.7 Broadband<sup>1</sup>

In this section you can configure how to obtain an IP address, enter LAN parameters and reset broadband module settings. In addition, the PLNK curr.params menu enables reading the current IP addresses of the PowerLink for support purposes only.

04:COMMUNICATION **OK** ▶▶ ... ▶▶ 7:BROADBAND **OK** ▶▶ ... ▶▶ MENU required **OK**

Enter **7:BROADBAND**, select the menu to configure (see guidance above and in section 4.6.1), then refer to the table below for configuration instructions.

Option	Configuration Instructions
<b>DHCP Client</b>	Define whether to obtain an IP address automatically using a DHCP server or to enter an IP address manually. Options: <b>disable</b> ; <b>enable</b> (default).
<b>Manual IP</b>	Manually enter LAN parameters. <b>Note:</b> This menu will appear only if DHCP Client is disabled.
<b>PLNK curr.params</b>	Displays the current IP addresses of the PowerLink.
→ <b>Curr.IP address</b>	Displays the current PowerLink IP address.
→ <b>Curr.subnet mask</b>	Displays the current PowerLink subnet mask.
→ <b>Current Gateway</b>	Displays the current PowerLink default gateway.
→ <b>Current Path</b>	Displays the current PowerLink mode of communication.
<b>RESET MODULE</b>	
→ <b>Reboot</b>	Determine whether to reset the broadband module (reboot).
→ <b>Factory defin.</b>	Set PLINK parameters back to factory settings.

<sup>1</sup> The name of the product is PowerLink3 IP Communicator

## 4.6.8 Wi-Fi

You can configure the panel remotely from the installer configurator application using a wireless device such as a mobile phone or tablet.

To connect a wireless network device to the panel, complete the following steps:

1. From the **8 WiFi > ACCESS-Point > A. POINT Mode** menu, select **Enable**. The installer must configure this option to activate Wi-Fi access. This option is disabled by default. Please enable it using AlarmInstall remote connection or using the Configurator software.
2. From the **ACCESS-Point** menu, select **START A.Point** to activate the access-point.

The Wi-Fi status indicator light on the panel blinks fast during the activation process and blinks slowly when the access-point is active.

Access-point can also be activated by pressing both (+) and (-) buttons for 5 seconds.

*Note:* When the system is armed or a USB cable is connected to the panel, you cannot activate the Wi-Fi access-point.




3. Connect the wireless device to the panel's Wi-Fi access-point. Enter the Panel ID when requested to enter the SSID (Panels Services Set Identifier) and enter the serial number of the panel when requested to enter the password. Both numbers are printed on a sticker on the panel. Alternatively, select the **INSTALLER > 10: SERIAL NUMBER** menu to view this information.
4. When the wireless device is connected to the panel, start the configuration application.
5. When the configuration is complete, from the **ACCESS-Point** menu, select **STOP A.Point** to close the access-point.

Access-point can be deactivated by pressing both (+) and (-) buttons for 30 seconds.

*Note:* By default the total time for access-point activity is one hour. Five minutes before the access-point is deactivated, a message is sent to the installer. You can extend the time by activating the access-point again from the menu.

From the installer mode menu, select the following options:

04:COMMUNICATION   ...  8: WiFi   ...  ACCESS-POINT 

Option	Configuration Instructions
8:WiFi > ACCESS-POINT	From the Wi-Fi <b>ACCESS-POINT</b> menu you can enable, activate, and deactivate an access-point.
8: WiFi > ACCESS-POINT > A.POINT MODE	To enable Wi-Fi access, from the <b>ACCESS-POINT</b> menu select <b>A.POINT MODE</b> . Select enable to activate or disable to deactivate wireless activity. Options: <b>Disable</b> (default); <b>Enable</b> . Press  to return.
8:WiFi > ACCESS-POINT > START A.POINT	To activate an access-point channel for wireless access, from the <b>ACCESS-POINT</b> menu select <b>START A.POINT</b> . The panel shows the status when you open the access-point channel. For example, <b>Please Wait</b> , <b>OK</b> , or <b>Fail</b> . Press  to return.
8: WiFi > ACCESS-POINT > STOP A.POINT	To close the access-point channel, from the <b>ACCESS-POINT</b> menu, select <b>STOP A.POINT</b> . The panel shows the status when you close the access-point channel. Press  to return.

## 4.7 PGM Output

### 4.7.1 General guidance

The “05:OUTPUTS” menu enables you to select events/conditions under which the PGM (programmable) output will function.

To configure a PGM output located on the WL-IOG general Inputs / Outputs wireless transceiver device, use the following menu path:

05:OUTPUTS **OK** **▶▶** ... **▶▶** PGM OUTPUTS **OK** ... PGM ON CONTACTS **OK** ... MENU you wish **OK**

Enter “PGM ON CONTACTS”, select the device and the PGM PIN number you wish to configure and then refer to the table in section 5.7.3 for PGM configuration instructions.

**Note:** PGM is not enabled in UL Listed Products.

### 4.7.2 PGM output configuration

Define which factors, including any combination of factors, will determine the PGM output.

Option	Configuration Instructions
PGM: BY ARM AWAY PGM: BY ARM HOME PGM: BY DISARM	Determine to activate the PGM output upon arming <b>Away / Home / Disarm</b> . Options: <b>disable</b> (default); <b>turn ON</b> ; <b>turn OFF</b> ; <b>activate PULSE</b> .
PGM: BY MEMORY	Determine to activate the PGM output upon registration of an alarm in the memory. The output will restore to normal upon memory clearing. Options: <b>disable</b> (default); <b>turn ON</b> ; <b>turn OFF</b> ; <b>activate PULSE</b> . <b>Note:</b> In Soak Test <sup>1</sup> mode and when BY MEMORY is enabled, the PGM will not be activated.
PGM: BY DELAY	Determine to activate the PGM output during the <b>Exit and Entry</b> delays. Options: <b>disable</b> (default); <b>turn ON</b> ; <b>turn OFF</b> ; <b>activate PULSE</b> .
PGM: BY KEYFOB	Determine to activate the PGM output upon pressing the AUX ( <b>*</b> ) button of keyfob transmitters configured to activate the PGM output. For further details, refer to the configuration instructions of the AUX ( <b>*</b> ) button of the respective keyfobs' datasheets. Options: <b>disable</b> (default); <b>turn ON</b> ; <b>turn OFF</b> ; <b>activate PULSE</b> ; <b>toggle</b>
PGM: BY SENSOR	Determine to activate the PGM output upon activation of any one of up to 3 sensors (zones) in the systems irrespective of whether the system is armed or disarmed. <u>To configure:</u> Press <b>OK</b> to enter the "PGM: BY SENSOR" sub menu and then select the Zone you wish to program, for example "Zone A". If the zone was configured before, the display shows the current zone number ("Z:xx") and if not, the zone number will be blank ("Z:_ _"). To configure the zone number, press <b>OK</b> . Enter the Zone number (2 digits) you wish to activate the PGM output and press <b>OK</b> to confirm. To add another sensor, select any of the other two options ("Zone B" and "Zone C") and repeat the above process. When done press <b>⏪</b> to return. Options: <b>disabled</b> (default); <b>turn ON</b> ; <b>turn OFF</b> ; <b>activate PULSE</b> ; <b>toggle</b> <b>Note:</b> If you select <b>toggle</b> , the PGM output will be turned on upon event occurrence in any of these zones and will be turned off upon next event occurrence, alternately.
PGM:BY LINE FAIL	Determine to activate the PGM output following failure of the PSTN line Options: <b>by line fail NO</b> (default); <b>by line fail YES</b> .
PGM: BY OTHER	Determine the PGM by one of the following options: Disable (default) <b>ON by Com Fail:</b> The PGM output is activated when the panel fails to report an event. <b>ON by Siren:</b> The PGM output is activated by an external wired siren.

**ON by strobe:** The PGM output is activated by a strobe.

<b>PGM:PULSE TIME</b>	Determine the PGM output pulse time. This value is the same for all events (by ARM AWAY, by ARM HOME, by DISARM etc.) which were selected with "activate PULSE" option.
Options: <b>pulse time 2s</b> (default); <b>pulse time 30s</b> ; <b>pulse time 2m</b> ; <b>pulse time 4m</b> .	

## 4.7.3 Entering Daytime Limits

05:OUTPUTS ... LOCKOUT TIME ...

Enter the "LOCKOUT TIME" menu and enter the daytime limits through which the PGM device will turn off, even when the associated sensors are triggered.

Step 1	Step 2	Step 3	Step 4
Select "05:OUTPUTS" menu	Select "LOCKOUT TIME" menu	Press	Enter the time at which you wish the lockout state to begin
05:OUTPUTS	LOCKOUT TIME	start- HH:MM	TIME <u>11:30</u>
Step 5	Step 6	Step 7	Step 8
Press	Press	Enter the time at which you wish the lockout state to end	Press  to return to "LOCKOUT TIME" or  to take you to "<OK> TO EXIT"
start- HH:MM	stop- HH:MM	TIME <u>19:00</u>	stop- HH:

## 4.8 Custom names

### 4.8.1 Custom zone names

During the device enrollment process you also define the Location name where the device is installed. The location name is selected from a Location List of Custom names - see Section 4.4.2, Part B, for Location List and instructions. Define the custom location names according to your specific needs and use them during device enrollment.

To define the Custom Location names, follow the instructions below. Additional guidance is provided in section 4.2.

06:CUSTOM NAMES ... CUST.ZONES NAME

Enter **CUST.ZONES NAME** (see guidance above), then refer to the table below which provides you with detailed explanations and programming instructions to edit the desired custom location.

**Note:** All 31 location names can be edited.

#### Configuration Instructions

Enter the Custom Location names you require to edit.

To edit:

Press to enter the **CUST. ZONES NAME** sub menu and then press again to select the Location # you require to edit, for example **TEXT LOC. #01** – the display alternates with the current Custom name, for example, **Master Bdrm**. To change the name, at the blinking cursor, enter the Location name you require and at the end, press to confirm. When done, press to return.

**Note:** To enter the Location name use the String Editor below.

**IMPORTANT!** The editing of a custom zone name automatically deletes the original text.

## WP8360 String Editor

Key	String Editor Functionality
	'', '0'
	':', '!', '1'
	'a', 'A', 'b', 'B', 'c', 'C', '2'
	'd', 'D', 'e', 'E', 'f', 'F', '3'
	'g', 'G', 'h', 'H', 'i', 'I', '4'
	'j', 'J', 'k', 'K', 'l', 'L', '5'
	'm', 'M', 'n', 'N', 'o', 'O', '6'
	'p', 'P', 'q', 'Q', 'r', 'R', 's', 'S', '7'
	't', 'T', 'u', 'U', 'v', 'V', '8'
	'w', 'W', 'x', 'X', 'y', 'Y', 'z', 'Z', '9'
	!, #, %, &, ', *, +, -, /, =, ^, @, _, " , :
	Moves the digits cursor from <b>left to right</b> .
	Moves the digits cursor from <b>right to left</b> .
	<b>Changes</b> between <b>lowercase</b> letters (a,b,c...z), <b>uppercase</b> letters (A,B,C...Z) and <b>numbers</b> (1,2,3).
	<b>Clears a single digit</b> of the string by cursor.
	<b>Clears a single digit</b> of the string to the left of cursor.
	<b>Confirms and saves</b> the edited string and reverts to previous menu.
	<b>Exiting</b> the edit screen and moves one level up to previous or top menu without saving the edit string.
	<b>Exiting</b> the edit screen and moves to the <OK> TO EXIT screen without saving the edit string.



Enter the **WL DEVICES** menu, select the type of test you require to perform (see guidance above and in section 4.8.1), then refer to the table below which provides you with detailed explanations for each option.

Option	Instructions
<b>TEST ALL DEVICES</b>	<p>You can test all wall-mounted devices automatically, one after the other, after which the installer tests the other devices in the following order: vanishing magnetic contact devices, keyfobs and then panic buttons.</p> <p>While in <b>TEST ALL DEVICES</b>, press <b>OK</b> to initiate the test. The following screen will appear: <b>TESTING Xxx NNN</b>, where Xxx indicates the type of device and NNN indicates the number of enrolled devices in the panel that have not been tested yet. This number automatically drops one count for every tested device.</p> <p>Pressing any key during the testing process will open the following options:</p> <ol style="list-style-type: none"> <li>1. Press <b>▶</b> to jump to the next device group. For example, from wall-mounted devices to keyfobs.</li> <li>2. Press <b>OK</b> to continue the testing process</li> <li>3. Press <b>🔒</b> to exit the test process.</li> </ol> <p>When all wall-mounted devices have completed the test procedure, you can test vanishing magnetic contact devices.</p> <p>While in the vanishing test process, indicated by the corresponding display, for example, <b>TEST VANISH NNN</b>, momentarily open the door or window.</p> <p>When all vanishing magnetic contact devices have been tested, you can test keyfobs. While in the keyfobs test process, indicated by the corresponding display, for example, <b>TEST KEYFOBS NN</b>, press any key of the selected device to initiate the test.</p> <p>When all keyfobs have been tested, you can test panic buttons. While in the panic button test process, indicated by the corresponding display, for example, <b>TEST PANIC BT. NN</b>, press a button on the pendant.</p> <p>At the end of the test process, the panel will present the following: <b>SHOW ALL DEVICES</b>. Press <b>OK</b> to view devices' status.</p> <p><i>Note: Refer to <b>SHOW ALL DEVICES</b> section below for further information on device status.</i></p>
<b>TEST ONE DEVICE</b> →CONTACT SENSORS →MOTION SENSORS →GLASSBREAK SENS. →SHOCK SENSORS →SMOKE SENSORS →CO SENSORS →GAS SENSORS →FLOOD SENSORS →TEMPERATURE SENS. →KEYFOBS →PANIC BUTTONS →KEYPADS →SIRENS →REPEATERS	<p>You can select a specific device group you require to test, for example, Motion Sensors.</p> <p>Press <b>OK</b> to enter the <b>TEST ONE DEVICE</b> sub menu and use <b>▶</b> to scroll through the device families. Press <b>OK</b> to enter the <b>&lt;device family&gt;</b> sub menu, for example: <b>MOTION SENSORS</b>.</p> <p><i>Note: If there is no enrolled device, <b>NO EXISTING DEV.</b> will be displayed.</i></p> <p>The following screens will then appear: <b>Xxx:&lt;device name&gt; ↺ &lt;location&gt;</b>, where Xxx indicates the device number. You can now select a specific device.</p> <p>Press <b>OK</b> to test the selected device. The following screen will appear: <b>TESTING Xxx 001</b>.</p> <p>While in the keyfobs, panic button or vanishing magnetic contact test process, indicated by the corresponding display, for example, <b>Xxx ACTIVATE NOW</b>, press any key of the selected keyfob or panic buttons, or momentarily open the door or window, to initiate the test.</p> <p>At the end of the test process, the panel will present the devices' status:  <b>Xxx: 24hr: &lt;status&gt;<sup>1</sup> ↺ Xxx: NOW: &lt;status&gt;<sup>1</sup>.</b></p> <p><i>Note: Refer to the <b>SHOW ALL DEVICES</b> section for further information on device status.</i></p>
<b>SHOW ALL DEVICES</b>	<p>You can view the devices status.</p> <p><i>Note: This option is available only after testing process was done.</i></p> <p>Press <b>OK</b> to view the devices' status.</p> <p>The following screens will appear: <b>Xxx: 24hr: &lt;status&gt;<sup>1</sup> ↺ Xxx: NOW: &lt;status&gt;<sup>1</sup></b></p> <p>Use <b>▶</b> to scroll between the device's families.</p>

<sup>1</sup> The signal strength indications are as follows: **STRONG; GOOD; POOR; 1-WAY** (the device operates in 1-way mode or, the **NOW** communication test failed); **NOT TST** (results are shown without any performed test); **NOT NET** [device is not networked (not fully enrolled)]; **NONE** (keyfob 24Hr result); or **EARLY** (result of the last 24Hrs without

Option	Instructions
	To view additional information of the selected device, press <b>OK</b> . The following screens will appear: <b>Xxx &lt;device name&gt;¹ ↻ &lt;location&gt;¹</b> . If the control panel receives information via a repeater, it will be displayed as follows: <b>Xxx &lt;device name&gt;¹ ↻ &lt;location&gt;¹ ↻ RPx:Via Repeater↻</b>
<b>SHOW RF PROBLEMS</b>	You can view only the devices which have RF problems. <b>Note:</b> <i>This option is available only after testing process was done.</i> Press <b>OK</b> to view the devices' status. The following screens will appear: <b>Xxx: 24hr: &lt;status&gt;¹ ↻ Xxx: NOW: &lt;status&gt;¹</b> Use <b>▶▶</b> to scroll between the device's families. To view additional information of the selected device, press <b>OK</b> . The following screens will appear: <b>Xxx &lt;device name&gt;¹ ↻ &lt;location&gt;¹</b> . If the control panel receives information via a repeater, it will be displayed as follows: <b>Xxx &lt;device name&gt;¹ ↻ &lt;location&gt;¹ ↻ RPx:Via Repeater↻</b>
<b>&lt;OK&gt; TO END</b>	Select to terminate the diagnostics test.

### 4.9.3 Testing the GSM module

The WP8360 enables to test the panel's integrated GSM module.

**07:DIAGNOSTICS** **OK** **▶▶** ... **▶▶** **GSM/GPRS** **OK** Please wait...

Enter the **GSM/GPRS** menu, and press **OK** to initiate the GSM diagnostic test. Upon test completion, the WP8360 will present the test result.


The following table presents the test result messages.

Message	Description
Unit is OK	GSM / GPRS is functioning correctly
GSM comm. loss	GSM/GPRS module does not communicate with the Panel
Pin code fail	Missing or wrong PIN code. (Only if SIM card PIN code is enabled.)
GSM net. fail	Unit failed with registration to local GSM network.
SIM card fail	SIM not installed or SIM card failure.
GSM not detected	GSM auto enroll failed to detect GSM/GPRS module.
No GPRS service	The SIM card does not have the GPRS service enabled.
GPRS conn. fail	Local GPRS network is not available or, wrong setting to GPRS APN, user and/or password.
Srvr unavailable	PowerManage receiver cannot be reached – check the Server IP
IP not defined	Server IP #1 and #2 are not configured.
APN not defined	APN is not configured.
SIM card locked	After entering a wrong PIN code 3 consecutive times the SIM is locked. To unlock it enter a PUK number. The PUK number cannot be entered by the control panel.
Denied by server	PowerManage denies the connection request. Check that the panel is registered to PowerManage.

## 4.9.4 Testing the SIM number

You can test the SIM number to ensure that the SIM number was entered correctly in the control panel (see section 4.6.2) and to coordinate with the operator.

07:DIAGNOSTICS   ...  SIM NUMBER TEST  ...

Enter the **SIM NUMBER TEST** menu, select the IP server (out of two) used for the verification of the SIM and press . The server sends a test SMS to the panel.

If the panel receives the SMS, a **SIM# verified** message is displayed and the test ends successfully. If the SMS was not received, for example, if there is no connection between the control panel and server, a **SIM not verified** message is displayed.

During testing the following messages are displayed and can help troubleshoot problems:


Message	Description
SIM # verifies	Test successful
SIM NOT verified	Test fails
SIM TEL. missing	Test fails because the panel SIM is not defined
GSM init.	Test is in progress waiting for GSM modem to initialize
Connect svr.	Test is in progress waiting for connection to the server
Request SMS	Test is in progress requesting server to send SMS
Wait for SMS	Test is in progress waiting to receive SMS from server

## 4.9.5 Testing the Broadband/PowerLink Module <sup>1</sup>

The Broadband diagnostic procedure enables to test the communication of the Broadband Module (see section 4.6.7) with the PowerManage server and reports the diagnostic result. In case of communication failure, detailed information of the failure is reported.

07:DIAGNOSTICS   ...  **BROADBAND MODULE**  ... PLEASE WAIT... Unit is OK

### Notes:

1. When the  button is pressed, the test result may take up to 4 min. before it is displayed.
2. If the Broadband Module is not registered to the WP8360, the menu **BROADBAND MODULE** will not be displayed.

The following table presents the list of messages that may be reported:

Message	Description
<b>Unit is ok</b>	Broadband Module is functioning correctly.
<b>Test aborted</b>	The diagnostic test is aborted, as follows: <ul style="list-style-type: none"> <li>• AC failure – Broadband Module is set to OFF mode.</li> <li>• Broadband Module has not completed the power-up procedure. In this case, the installer should wait a maximum of 30 seconds before re-testing.</li> </ul>
<b>Comm. loss</b>	The RS-232 serial interface between the Broadband Module and the WP8360 failed.
<b>Rcvr Ip missing</b>	Receivers IP 1 and 2 settings are missing in the WP8360.
<b>Cable unplugged</b>	The Ethernet cable is not connected to the Broadband Module.
<b>Check lan config</b>	This message appears in any of the following cases: <ul style="list-style-type: none"> <li>• Incorrect Broadband Module IP has been entered.</li> <li>• Incorrect subnet mask has been entered.</li> <li>• Incorrect default gateway has been entered.</li> <li>• DHCP server failure.</li> </ul>
<b>Rcvr#1 UnReach.</b> <b>Rcvr#2 UnReach.</b>	Receiver 1 or 2 is inaccessible, as follows: <ul style="list-style-type: none"> <li>• Wrong receiver IP has been entered.</li> <li>• Receiver failure.</li> <li>• WAN Network failure.</li> </ul>
<b>Rcvr#1 UnReg.</b> <b>Rcvr#2 UnReg.</b>	The WP8360 unit is not registered to IP receiver 1 or 2.
<b>Timeout err.</b>	Broadband Module does not respond to test result within 70 sec.
<b>Invalid result</b>	Broadband Module responds with a result code that is not recognized by the WP8360.

## 4.9.6 Testing the WLAN Module

The WLAN diagnostic procedure enables a test of the communication of the WLAN Module with the PowerManage server and reports the diagnostic result. In case of communication failure, detailed information of the failure is reported.

07:DIAGNOSTICS   ...  **08: WLAN**  ... PLEASE WAIT... Unit is OK

The following table presents the list of messages that might be reported:

Message	Description
<b>“Please wait...”</b>	Test in progress
<b>0 – “Success”</b>	WLAN is ok
<b>1 – “Wi-Fi disabled”</b>	Wi-Fi client is not enabled
<b>2 – “Router disconn.”</b>	No connection to router (no link, or wrong SSID or password)
<b>3 – “DHCP failure”</b>	Plink fail to get IP from DHCP server (router)
<b>4 – “Wrong password”</b>	Wrong SSID or password
<b>5 – “No WAN”</b>	Plink fail to connect DNS or 8.8.8.8

<sup>1</sup> The name of the product is PowerLink3 IP Communicator

<b>6 – “Wi-Fi is OK”, status of both servers.</b> <b>“RCV1: OK RCV2: OK”</b> <b>“RCV1: OK RCV2: --”</b> <b>“RCV1: OK RCV2: ER”</b>	<b>“ER” – No connection to server</b> <b>“--” – Empty IP Unreachable</b>
<b>7 –“Plink general err”</b>	General Plink error
<b>8 – “No Wi-Fi module”</b>	No Wi-Fi module detected
<b>9 – “Eth. connected”</b>	Ethernet connection detected

## 4.10 User settings

The USER SETTINGS menu provides you with a gateway to the user settings through the regular user menus. Refer to the WP8360 User's Guide for detailed procedures.

## 4.11 Factory default

The FACTORY DEFLT menu enables you to reset the WP8360 parameters to the factory default parameters. To obtain the relevant parameters defaults, contact the WP8360 dealer. Reset factory default parameters as follows:






Step 1	Step 2	Step 3	Step 4	Step 5
Select 09:FACTORY DEFLT menu	Select <OK> to restore	Enter Installer Code	Resetting of factory default parameters is underway	
 09:FACTORY DEFLT  <OK> to restore  ENTER CODE: ■  PLEASE WAIT...  to Step 1				

### Notes:

- 1) For WP8360 with 2 installer codes, INSTALLER code and MASTER INSTALLER code, only the master installer code enables to perform the factory default function.
- 2) If the Soak Test is active, performing factory default will restart the Soak Test.

## 4.12 Serial number

The SERIAL NUMBER menu enables reading the system serial number and similar data for support purposes only. To read the system serial number and other relevant data proceed as follows:

Step 1	Step 2	Step 3
Select 10:SERIAL NUMBER menu	Click next repeatedly to view relevant data.	
 10:SERIAL NUMBER  <div style="float: right;">    to Step 1         </div>		
<b>Definition</b>		
	0907030000.	Control panel serial number
	JS702766 R19.412	Control panel software version
	PANEL ID: 18DD6	Control panel ID for PowerManage connectivity
	J-702770 R19.412	Control panel default version
	JS702767 R01.033	Control panel boot version
	JS702768 L02.036	Control panel Remote Software Upgrade downloader version
	PL8.0.92.3 raw	Displays the PowerLink software version
	GE910 QUAD V3	Displays the cellular modem type.








## 4.13 Partitioning

### 4.13.1 General guidance – Partitioning menu

This menu allows you to enable/disable partitions in the system (for further details, see APPENDIX D).

### 4.13.2 Enabling and disabling partitions

To enable or disable the partition feature, proceed as follows:

Step 1	Step 2	Step 3	Step 4
Select <b>12:PARTITIONING</b> menu	Select whether to <b>Enable</b> or <b>Disable</b> Partitions	Partitions are now enabled	
 <b>12:PARTITIONING</b> 	 <b>Disable</b>  ↓ <b>Enable</b> 	<b>Enable</b> 	 to Step 1

## 4.14 Operation mode

*Note: The Operation Mode feature is applicable only in specific WP8360 variants.*

### 4.14.1 General guidance – Operation mode menu

This mode allows you to select an operation mode for the control panel according to specific compliance standards. Each operation mode has its own configuration.

### 4.14.2 Select setting

To select the desired operation mode, proceed as follows:

Step 1	Step 2	Step 3	Step 4
Select 13:OPERATION MOD menu	Enter 01:SELECT MODE	Select <b>NORMAL</b> , <b>EN-50131</b> , <b>DD243</b> , <b>BS8243</b> , <b>INCERT</b> or <b>CP01</b>	
13:OPERATION MOD	01 SELECT MODE	<b>NORMAL</b>	to Step 2

*Note: If you select Normal / EN-50131 / INCERT, the control panel will operate according to OTHERS setup configuration (see section 4.14.6).*

### 4.14.3 BS8243 Setup

13:OPERATION MOD ... 02:BS8243 SETUP

Enter the **02:BS8243 SETUP** menu to configure its settings.

Option	Configuration Instructions
<b>01:DISARM OPTION</b>	<p>Define when it is possible to disarm the system:</p> <p><b>entry/BS devs</b> (default) – By keypad after the entry delay has expired and if an alarm occurred in the system. By keyfob or WK160 at all times.</p> <p><b>entry/all devs</b> - During entry delay, when the system is armed AWAY, by all devices. When not in entry delay by keyfob or WK160 only.</p> <p><b>entry/DD devs</b> - During entry delay, when the system is armed AWAY, by using the keyfob or WK160. Keypads cannot disarm at all.</p> <p><b>anytime/all dev</b> – At any time and by all devices.</p>
<b>02:ENTRY ALARM</b>	<p>Define whether the system will report a confirmed alarm during an entry delay (see CONFIRM ALARM below).</p> <p><b>BS8243</b> (default) – An alarm initiated by another detector during the entry delay is regarded as a confirmed alarm. An additional 30 seconds delay is added to the entry delay for reporting the event (does not affect the Abort Time, see section 4.5.4).</p> <p><b>BS8243 no cnfrm</b> - The panel will not send any confirmed alarm once a delay zone has been activated, until the control panel is disarmed.</p> <p><b>DD243</b> - An alarm initiated by another detector during the entry delay is not regarded as a confirmed alarm.</p> <p><b>normal mode</b> - The control panel will report a confirmed alarm for the second alarm that is triggered from a different zone within the confirmation time. There are no alarm restrictions during entry delay or for the delay zone.</p>
<b>03:END EXIT MODE</b>	<p>Define how the exit delay is terminated or restarted according to the following options:</p> <p><b>door/fob only</b> (default) - When the door is closed, or by pressing the AUX button on the keyfob<sup>1</sup>, whichever first.</p> <p><b>restart&gt;reentry</b> - Exit delay restarts when the door is reopened during exit delay. The restart occurs once only. Restarting the exit delay is helpful if the user re-enters immediately after going out to retrieve an item that was left behind.</p> <p><b>door/fob/timer</b> - When the door is closed, by pressing the AUX button on the keyfob<sup>1</sup>, or when the exit delay has expired, whichever first.</p> <p><b>fob/timer</b> - By pressing the AUX button on the keyfob<sup>1</sup>, or when the exit delay has expired, whichever first.</p>

<sup>1</sup> Applies only when the keyfob is defined as **skip exit delay** (for further details, see the keyfob's User's Guide)

Option	Configuration Instructions
04:FOB/KP PANIC	Define the devices that cannot trigger a panic alarm. <b>BS8243</b> (default) – PGx939 and PGx929. <b>all</b> - All devices can trigger a panic alarm
05:CONFIRM ALARM	Define a specific time period that if 2 successive alarms occur, the second alarm will be considered as a <b>confirmed alarm</b> , (see RPT CNFM ALRM below). Options: <b>in 30</b> (default)/ <b>45/60/90 minutes</b>
06:CONFIRM PANIC	A confirmed panic alarm is reported if one of the following occurs within the confirmation time: a) A second panic device is activated. b) A second panic alarm on the same device is activated. c) A tamper event is activated (not from the zone / device that initiated the panic alarm). Options: <b>in 4/8/12/20</b> (default)/ <b>24 hours and disabled</b>
07:RPT CNFM ALRM	Define whether the system will report a confirmed alarm. <b>enable + bypass</b> (default) - The system will report a confirmed alarm and will bypass all alarmed open zones when the siren ends or when the confirmation timer expires. <b>disable</b> - The system will not report a confirmed alarm. <b>enable</b> - The system will report a confirmed alarm.
08:ENTRY DELAY 1 09:ENTRY DELAY 2	Two different entry delays allow the user to enter the protected site (while the system is in the armed state) via 2 specific doors and routes without causing an alarm. Following entry, the user must disarm the control panel before the entry delay expires. Slow-rate warning beeps start sounding once the door is opened, until the last 10 seconds of the delay, during which the beeping rate increases. Locations No. 1 (entry delay 1) and 2 (entry delay 2) allow you to program the length of these delays. Options: <b>10/15/30</b> (ENTRY DELAY 1 <i>default</i> )/ <b>45/60</b> (ENTRY DELAY 2 <i>default</i> ) <b>seconds; 3/4 minutes</b>
10:ABORT TIME	The WP8360 can be configured to provide a delay before reporting an alarm to the Monitoring Station (not applicable to alarms from FIRE, 24H SILENT and EMERGENCY zones). During this delay period, the siren sounds but the alarm is not reported. If the user disarms the system within the delay time, the alarm is aborted. You can activate the feature and select the <b>Abort Time</b> interval. Options: <b>in 00</b> (default in USA)/ <b>15/30</b> (default)/ <b>45/60 seconds; in 2/3/4 minutes</b>
11:CANCEL ALARM	The WP8360 can be configured to provide a <b>Cancel Alarm</b> time window that starts upon reporting an alarm to the Monitoring Station. If the user disarms the system within that <b>cancel alarm</b> time, a <b>cancel alarm</b> message is sent to the Monitoring Station indicating that the alarm was canceled by the user. Options: <b>not active</b> (default in USA); <b>in 1/5</b> (default)/ <b>15/60 minute(s)</b> and <b>in 4 hours</b> .

#### 4.14.4 DD243 Setup

13:OPERATION MOD   ...  03:DD243 SETUP 

Enter the **03:DD243 SETUP** menu to configure its settings.

Option	Configuration Instructions
01:DISARM OPTION	Define when it is possible to disarm the system: <b>entry/wl+awy kp</b> – By the control panel when the system is armed AWAY. By keyfob or WK160 during entry delay only. <b>entry/all devs</b> – During entry delay, when the system is armed AWAY, by all devices. When not in entry delay by keyfob or WK160 only. <b>entry/DD devs</b> (default) – During entry delay, when the system is armed AWAY, by using the keyfob or WK160. Keypads cannot disarm at all. <b>anytime/all dev</b> – At any time and by all devices.

Option	Configuration Instructions
02:ENTRY ALARM	<p>Define whether the system will report a confirmed alarm during an entry delay (see CONFIRM ALARM below).</p> <p><b>DD243</b> (default) – An alarm initiated by another detector during the entry delay is not regarded as a confirmed alarm.</p> <p><b>normal mode</b> – The control panel will report a confirmed alarm for the second alarm that is triggered from a different zone within the confirmation time. There are no alarm restrictions during entry delay or for the delay zone.</p>
03:END EXIT MODE	<p>Define how the exit delay is terminated or restarted according to the following options:</p> <p><b>door/fob only</b> – When the door is closed, or by pressing the AUX button on the keyfob<sup>1</sup>, whichever first.</p> <p><b>restart&gt;reentry</b> – Exit delay restarts when the door is reopened during exit delay. The restart occurs once only. Restarting the exit delay is helpful if the user re-enters immediately after going out to retrieve an item that was left behind.</p> <p><b>door/fob/timer</b> – When the door is closed, by pressing the AUX button on the keyfob<sup>1</sup>, or when the exit delay has expired, whichever first.</p> <p><b>fob/timer</b> (default) – By pressing the AUX button on the keyfob<sup>1</sup>, or when the exit delay has expired, whichever first.</p>
04:FOB/KP PANIC	<p>Define the devices that cannot trigger a panic alarm.</p> <p><b>DD243</b> (default) – PGx939 and PGx929.</p> <p><b>all</b> - All devices can trigger a panic alarm</p>
05:CONFIRM ALARM	<p>Define a specific time period that if 2 successive alarms occur, the second alarm will be considered as a <b>confirmed alarm</b>, (see RPT CNFM ALRM below).</p> <p>Options: <b>in 30/45/60(default)/90 minutes</b></p>
06:CONFIRM PANIC	<p>A confirmed panic alarm is reported if one of the following occurs within the confirmation time:</p> <p>a) A second panic device is activated.</p> <p>b) A second panic alarm on the same device is activated.</p> <p>c) A tamper event is activated (not from the zone / device that initiated the panic alarm).</p> <p>Options: <b>in 4/8/12/20(default)/24 hours and disabled</b></p>
07:RPT CNFM ALRM	<p>Define whether the system will report a confirmed alarm.</p> <p><b>enable + bypass</b> (default) – The system will report a confirmed alarm and will bypass all alarmed open zones when the siren ends or when the confirmation timer expires.</p> <p><b>disable</b> – The system will not report a confirmed alarm.</p> <p><b>enable</b> – The system will report a confirmed alarm.</p>
08:ENTRY DELAY 1 09:ENTRY DELAY 2	<p>Two different entry delays allow the user to enter the protected site (while the system is in the armed state) via 2 specific doors and routes without causing an alarm.</p> <p>Following entry, the user must disarm the control panel before the entry delay expires. Slow-rate warning beeps start sounding once the door is opened, until the last 10 seconds of the delay, during which the beeping rate increases. Locations No. 1 (entry delay 1) and 2 (entry delay 2) allow you to program the length of these delays.</p> <p>Options: <b>10/15/30(ENTRY DELAY 1 default)/45/60(ENTRY DELAY 2 default) seconds; 3/4 minutes</b></p>
10:ABORT TIME	<p>The WP8360 can be configured to provide a delay before reporting an alarm to the monitoring station (not applicable to alarms from FIRE, 24H SILENT and EMERGENCY zones). During this delay period, the siren sounds but the alarm is not reported. If the user disarms the system within the delay time, the alarm is aborted. You can activate the feature and select the <b>Abort Time</b> interval.</p> <p>Options: <b>in 00</b> (default in USA)/<b>15/30</b> (default)/<b>45/60 seconds; in 2/3/4 minutes</b></p>
11:CANCEL ALARM	<p>The WP8360 can be configured to provide a <b>Cancel Alarm</b> time window that starts upon</p>

<sup>1</sup> Applies only when the keyfob is defined as "skip exit delay" (for further details, see the keyfob's User's Guide)

Option	Configuration Instructions
	reporting an alarm to the Monitoring Station. If the user disarms the system within that <b>cancel alarm</b> time, a <b>cancel alarm</b> message is sent to the Monitoring Station indicating that the alarm was canceled by the user.
	Options: <b>not active</b> (default in USA); <b>in 1/5</b> (default)/ <b>15/60 minute(s)</b> and <b>in 4 hours</b> .

#### 4.14.5 CP01 Setup

13:OPERATION MOD   ...  CP01 SETUP 

Enter the **04:CP01 SETU** menu to configure its settings.

Option	Configuration Instructions
<b>01:DISARM OPTION</b>	<p>Certain regulations require that when the system is armed in <b>AWAY</b> mode, it may not be disarmed from the outside of the house (such as by keyfobs) before entering the protected premises and activating an Entry Delay zone. To answer this requirement, the WP8360 provides you with the following configurable options to disarm the system:</p> <p><b>any time</b> (default) – the system can be disarmed at all times from all devices.</p> <p><b>on entry wrless</b> – During entry delay, the system can be disarmed only using keyfob or prox operated devices.</p> <p><b>entry + away kp.</b> – During entry delay by code, the system can be disarmed only using WP8360 Virtual Keypad .</p> <p><b>on entry all.</b> – During entry delay, the system can be disarmed using keyfobs or by code using the WP8360 Virtual Keypad.</p>
<b>03:END EXIT MODE</b>	<p>Define how the exit delay is terminated or restarted according to the following options:</p> <p><b>restart+arm home</b> (default) – During exit delay if the door was not opened, the alarm system will be armed HOME instead of armed AWAY.</p> <p><b>restart&gt;reentry</b> - Exit delay restarts when the door is reopened during exit delay. The restart occurs once only. Restarting the exit delay is helpful if the user re-enters immediately after going out to retrieve an item that was left behind.</p> <p><b>door/fob/timer</b> - When the door is closed, by pressing the AUX button on the keyfob<sup>1</sup>, or when the exit delay has expired, whichever first.</p> <p><b>fob/timer</b> - By pressing the AUX button on the keyfob<sup>1</sup>, or when the exit delay has expired, whichever first.</p>
<b>05:CONFIRM ALARM</b>	<p>Define a specific time period that if 2 successive alarms occur, the second alarm will be considered as a confirmed alarm, (see <b>RPT CNFM ALRM</b> below).</p> <p>Options: <b>disable</b> (default in USA); <b>in 30/45/60</b>(default)/<b>90 minutes</b></p>
<b>07:RPT CNFM ALRM</b>	<p>Define whether the system will report a confirmed alarm.</p> <p><b>report disabled</b> (default) - The system will not report a confirmed alarm.</p> <p><b>report enabled</b> - The system will report a confirmed alarm.</p>
<b>08:ENTRY DELAY 1</b> <b>09:ENTRY DELAY 2</b>	<p>Two different entry delays allow the user to enter the protected site (while the system is in the armed state) via 2 specific doors and routes without causing an alarm.</p> <p>Following entry, the user must disarm the control panel before the entry delay expires. Slow-rate warning beeps start sounding once the door is opened, until the last 10 seconds of the delay, during which the beeping rate increases. Locations No. 1 (entry delay 1) and 2 (entry delay 2) allow you to program the length of these delays.</p> <p>Options: <b>30</b> (default)/<b>45/60 seconds</b>; <b>3/4 minutes</b></p>
<b>10:ABORT TIME</b>	<p>The WP8360 can be configured to provide a delay before reporting an alarm to the monitoring station (not applicable to alarms from FIRE, 24H SILENT, EMERGENCY, GAS FLOOD and TEMPERATURE zones). During this delay period, the external siren will not sound and the alarm is not reported. If the user disarms the system within the delay time, the alarm is aborted.</p> <p>Options: <b>in 15</b> (default)/<b>30/45 seconds</b></p>
<b>11:CANCEL ALARM</b>	<p>Define the <b>cancel alarm</b> period that starts upon reporting an alarm to the Monitoring Station.</p>

<sup>1</sup> Applies only when the keyfob is defined as **skip exit delay** (for further details, see the keyfob's User's Guide)

Option	Configuration Instructions
	If the user disarms the system within that time period, a <b>cancel alarm</b> message is sent to the Monitoring Station. Options: <b>in 5 (default)/15/60 minutes; in 4 hours</b>
12:CNCEL ANOUNCE	Define whether a special beep will sound when an alarm cancel event is sent to the monitoring station. <b>enable</b> (default) and <b>disable</b>
13:ABORT ANOUNCE	Define that when the user disarms the system within the allowed abort interval a special beep will sound to <b>indicate no alarm transmission</b> . <b>enable</b> (default) and <b>disable</b>

#### 4.14.6 Other setup

13:OPERATION MOD   ...  05:OTHERS SETUP 

Enter the **05:OTHERS SETUP** menu to configure its settings.

Option	Configuration Instructions
01:DISARM OPTION	Certain regulations require that when the system is armed in AWAY mode, it may not be disarmed from the outside of the house (such as by keyfobs) before entering the protected premises and activating an <b>Entry Delay</b> zone. To answer this requirement, the WP8360 provides you with the following configurable options to disarm the system: <b>any time</b> (default) – the system can be disarmed at all times from all devices. <b>on entry wrless</b> – During entry delay, the system can be disarmed only using keyfob or prox operated devices. <b>entry + away kp.</b> – During entry delay by code, the system can be disarmed only using WP8360 Virtual Keypad. <b>on entry all.</b> – During entry delay, the system can be disarmed using keyfobs or by code using the WP8360 Virtual Keypad.
03:END EXIT MODE	The <b>Exit Delay</b> time can be further adjusted according to your preferred exit route. The control panel provides you with the following <b>Exit Mode</b> options: <b>A: normal</b> (default) – The exit delay is exactly as defined. <b>B: restart&gt;reentry</b> – The exit delay restarts when the door is reopened during exit delay. The restart occurs once only. Restarting the exit delay is helpful if the user re-enters immediately after going out to retrieve an item that he left behind. <b>C: end by exit</b> – The exit delay expires (ends) automatically when the exit door is closed even if the defined exit delay time was not completed. Options: <b>normal</b> (default); <b>restart&gt;reentry</b> and <b>end by exit</b> .
05:CONFIRM ALARM	Define a specific time period that if 2 successive alarms occur, the second alarm will be considered as a confirmed alarm, (see <b>RPT CNFM ALRM</b> below). Options: <b>disable</b> (default in USA); <b>in 30/45/60 (default)/90 minutes</b>
07:RPT CNFM ALRM	Define whether the system will report a confirmed alarm. <b>report disabled</b> (default) - The system will not report a confirmed alarm. <b>report enabled</b> - The system will report a confirmed alarm.
08:ENTRY DELAY 1 09:ENTRY DELAY 2	Two different entry delays allow the user to enter the protected site (while the system is in the armed state) via 2 specific doors and routes without causing an alarm. Following entry, the user must disarm the control panel before the entry delay expires. Slow-rate warning beeps start sounding once the door is opened, until the last 10 seconds of the delay, during which the beeping rate increases. Locations No. 1 (entry delay 1) and 2 (entry delay 2) allow you to program the length of these delays. Options : <b>00/15 (ENTRY DELAY 2 default)/30 (ENTRY DELAY 1 default)/45/60 seconds; 3/4 minutes</b>
10:ABORT TIME	The WP8360 can be configured to provide a delay before reporting an alarm to the monitoring station (not applicable to alarms from FIRE, 24H SILENT and EMERGENCY zones). During




Option	Configuration Instructions
	<p>this delay period, the siren sounds but the alarm is not reported. If the user disarms the system within the delay time, the alarm is aborted. You can activate the feature and select the <b>Abort Time</b> interval.</p> <p>Options: <b>in 00</b> (default in USA)/<b>15/30</b>(default)/<b>45/60 seconds</b>; <b>in 2/3/4 minutes</b></p>
<b>11:CANCEL ALARM</b>	<p>The WP8360 can be configured to provide a <b>Cancel Alarm</b> time window that starts upon reporting an alarm to the Monitoring Station. If the user disarms the system within that <b>cancel alarm</b> time, a <b>cancel alarm</b> message is sent to the Monitoring Station indicating that the alarm was cancelled by the user.</p> <p>Options: <b>not active</b> (default in USA); <b>in 1/5</b> (default)/<b>15/60 minute(s)</b> and <b>in 4 hours</b>.</p>

# 5. Periodic test

## 5.1 General guidance




This mode provides you with the means to conduct a periodic test of all system sirens, detectors, keyfobs, keypads, repeaters, and other peripheral devices, via the **PERIODIC TEST** menu, at least once a week and after an alarm event. When you are instructed to perform a periodic test, walk throughout the site to check the detectors / sensors (except for Temperature Sensors). When a detector/sensor is triggered into alarm, its name, number, and the alarm reception level should be indicated (for example, **Bathroom, Z19 strong**), and the buzzer should sound according to the alarm reception level (1 of 3). Each device should be tested according to the device Installation Instructions.

To enter the **PERIODIC TEST** menu and to conduct a periodic test, proceed as follows:

Step 1	①	Step 2	①
READY	[1]	Select the test to be performed	[2]
			
<b>PERIODIC TEST</b> (enter installer / master code)		<b>SIRENS TEST</b> <b>TEMP/LIGHT TEST</b> <b>TEST ALL DEVICES</b> <b>TEST ONE DEVICE</b>	

### ① ① – Periodic Test

[1] Not including Siren and Temperature Sensors

[2] After reviewing all untested devices the control panel will read **<OK> TO END**. You can now do one of the following: press  to abort the testing procedure; press  to continue the testing procedure; or press  to exit the testing procedure.

## 5.2 Conducting a periodic test

The WP8360 enables you to conduct the periodic test in five parts:

**Siren Test:** Each siren of the system is automatically activated for 3 seconds (outdoor sirens with low volume).

**Temp/Light Test:** For devices with temperature sensing, the panel displays the temperature of each zone in Celsius or Fahrenheit. For devices that have both temperature and light sensing, the panel displays the temperature and light intensity of each zone.




**Test all devices:** All devices are tested.














**Other Device Test:** Each of the other devices in the system is activated by the installer and the display indicates which devices were not yet tested. The **it's me** indication helps to identify the untested devices if necessary. A counter also indicates the number of devices that remain untested.

**Email Test:** Generates an event to be sent to the predefined private email addresses.

READY   ...  **PERIODIC TEST**   ...  **MENU required** 

To conduct a periodic test, make sure the system is disarmed and then enter the **PERIODIC TEST** menu using your installer code (8888 by default) or master installer code (9999 by default). Immediately after entering the **PERIODIC TEST** menu, all the LEDs on the panel will momentarily light (LED test).

Option	Instructions
<b>SIRENS TEST</b>	<p>You can test wireless sirens and strobes and sirens of smoke sensors.</p> <p>To initiate the siren test, press . The display now reads <b>SIREN N</b>. <b>N</b> indicates the zone location assigned to the siren that is currently being tested.</p> <p>The first siren enrolled in the panel sounds for 3 seconds after which the WP8360 system will automatically repeat the procedure for the next siren enrolled in the system until all sirens are tested. You should listen to the sirens sounds and make sure that all sirens sound.</p> <p>Once all the sirens have been tested, the control panel will now test the sirens of smoke sensors that are enrolled in the alarm system. The display now reads <b>Zxx: SMOKE SIREN</b>, where <b>Zxx</b> indicates the zone number of the smoke sensor, and alternates with <b>&lt;OK&gt; TO CONTINUE</b>. During this time, the siren of the tested smoke sensor will sound for up to one minute.</p> <p>Press  to test the siren of the next smoke sensor.</p> <p>When the sirens test is complete, the display reads <b>SIREN TESTS END</b>. Press the .</p>

Option	Instructions
<b>TEMP/LIGHT TEST</b>	<p>or the  button to confirm the test.</p> <p>The control panel reads the temperature and light intensity of the zone.</p> <p>While testing, all previous temperature and light results from the sensors are cleared. To display the temperature and light intensity of zones on the control panel, press . After 20 seconds the control panel reads the temperature of the zone. If there is no result the following message is displayed: Zxx TEMP: No TST. The control panel reads the light intensity of each zone. The light level indication is dynamic; if a detector has only two light thresholds the following is displayed on the panel:</p> <ul style="list-style-type: none"> <li>• For 100% light: LIGHT (**)</li> <li>• For complete darkness: LIGHT ()</li> </ul> <p>If there is no light result the following message is displayed "Zxx LIGHT: No TST".</p> <p>The display alternates between the temperature, light, sensor number and the sensor location, as in the following example: <b>Z01 24.5°C &gt; Z01: LIGHT (**)</b> &gt; <b>Z01: Sensor number &gt; Room location</b>. Repeatedly click the  button to review the temperature and light intensity of each zone.</p> <p>When the temperature and light of all zones is reviewed, the display reads <b>DEVICE TESTS END</b>. Press the  or the  button to confirm the test and then move to the next step to test the other devices.</p>
<b>TEST ALL DEVICES</b>	<p>You can test all devices in one procedure.</p> <p>While in <b>TEST ALL DEVICES</b>, press  to initiate the test.</p> <p>The control panel now reads <b>NOT TESTED NNN</b>. <b>N</b> indicates the number of enrolled devices in the control panel that have not been tested. This number automatically drops one count for every tested device.</p> <p>When the <b>NOT TESTED NNN</b> screen appears, walk throughout the site to test the detectors / sensors or press any key of the selected handheld device to initiate the test.</p> <p>After a device has been activated, the control panel reads <b>Zxx IS ACTIVATED</b> and the <b>N</b> indicator drops one count.</p> <p>Pressing  during the testing process will display details of each device that has not yet been tested. The control panel reads the device number, followed by the device type (for example, Contact Sensor, Motion Sensor or Keyfob) and followed by the device location. At this stage, pressing any one of the following keys will open the following options:</p> <ol style="list-style-type: none"> <li>1. Press  to view details of the next untested device.</li> <li>2. Press  to exit the test process.</li> </ol> <p>During testing, you can also check the signal strength indication of each device according to the number of LED blinks of the device, (for further details, refer to the device Installation Instructions).</p> <p>After all devices have been tested, the control panel reads <b>DEVICE TESTS END</b>.</p>
<b>TEST ONE DEVICE</b> →CONTACT SENSORS →MOTION SENSORS →GLASSBREAK SENS. →SHOCK SENSORS	<p>Select a specific device group you require to test, for example, Motion Sensors.</p> <p>Press  to enter the <b>TEST ONE DEVICE</b> sub menu and use  to scroll through the device families. Press  to enter the &lt; device family &gt; sub menu. For example: <b>MOTION SENSORS</b>.</p> <p>The following screens will appear: <b>Xxx:&lt;device name&gt; ↻ &lt;location&gt;</b>  Where <b>Xxx</b> indicates the device number.</p> <p>If there is no device, the following screen will appear: <b>NO EXISTING DEV.</b></p> <p>Press  to test the selected device. The following screen will appear: <b>Z01 ACTIVATE NOW</b>.</p> <p>Walk throughout the site to test the detectors / sensors or press any key of the selected handheld device to initiate the test.</p> <p>During testing, you can also check the signal strength indication of each device, (for further</p>

Option	Instructions
--------	--------------

details, refer to the device Installation Instructions).

At the end of the test process the panel will revert to: **TEST ONE DEVICE**.

**To test the microwave range of the dual detector:**

1. Press **OK** to enter the **TEST ONE DEVICE** sub menu and use **▶▶** to navigate to **MOTION SENSORS**.
2. Press **OK**; the following screens will appear: **Z01:Motion Sens ↻ <location>**.
3. Press **▶▶** continuously to select a different zone number.
4. Press **OK**; If the selected device is PGx984, the following screens will appear: **<OK MW ADJUST> ↻ <NEXT> TEST ONE**.

To test the microwave range, go to step 5. To test a different microwave range, go to step 7.

5. Press **▶▶**; the following screen will appear: **ACTIVATE MW NOW**.
6. Activate the device; the screen will return to **TEST ONE DEVICE**.

You can now repeat the procedure for another dual detector.

7. Press **OK** to select the sensitivity setting.
8. Press **▶▶** continuously to select between **Minimum** (default), **Medium** or **Maximum**
- 9a. Press **OK**; the panel will receive an acknowledge from the device that is indicated by a black box next to the selected setting. Thereafter, the screen momentarily changes to **ACTIVATE MW NOW** and then returns to the selected setting.
- 9b. If you press **⏏**, the adjustment procedure ends.

**Important:** The procedure mentioned above is for testing purposes only and does not change the detector settings. The settings must be saved through the MODIFY DEVICES menu.

**To test the shock detector:**

1. Press **OK** to enter the **TEST ONE DEVICE** sub menu and use **▶▶** to navigate to **SHOCK SENSORS**.
2. Press **OK**; the following screens will appear: **Zxx:Shk+AX+CntG3<sup>1</sup> ↻ <location>**.
3. Press **▶▶** continuously to select a different zone number.
4. Press **OK**; the following screens will appear: **Zxx ACTIVATE NOW ↻ SHOCK NOT ACTIV. ↻ CNTACT NOT ACTIV ↻ AUXIL. NOT ACTIV**.

*Note: The above screens are the full range of screens that can appear and indicate the inputs that have not yet been activated. However, since there are various models of the shock detector, not all of these screens will appear on some models.*

5. At this stage, activate each input of the shock detector in turn.

**To test motion detector with integrated camera (PGx934 or PGx944):**

1. Press **OK** to enter the **TEST ONE DEVICE** sub menu and use **▶▶** to navigate to **MOTION SENSORS**.
2. Press **OK**; the following screens will appear: **Z01:Motion Sens ↻ <location>**.
3. Press **▶▶** continuously to select a different zone number.
4. Press **OK**; the following screen will appear: **Zxx ACTIVATE NOW**.
5. Activate the input of the detector; the following screens will appear: **<Zxx IS ACTIVATE> ↻ <OK> SEND IMAGE**.

<b>E-MAIL TEST</b>	To test emails, proceed as follows:
--------------------	-------------------------------------

<sup>1</sup> Depending on shock detector model, one of the following may appear instead: "**Zxx:Shk+AX**" / "**Zxx:Shk+CntG3**" / "**Zxx:Shk+CntG2**".

---

**Option****Instructions**

While in **E-MAIL TEST**, press **OK** to initiate the test.

The following screen will appear: **Please wait...** and at the termination of the test will change to **<Pis chck MailBox>**.

Check the private email inbox to view the sent email.

**Note:**

1. *For test success, the event must first reach the server before the server can send the email to the user's inbox.*
  2. *Since a Burglary alarm is sent, an alarm event must be configured for reporting events (see sections 4.6.3 *Configuring Events Reporting to Monitoring Stations* and 4.6.4 *Configuring Events Reporting to Private Users*).*
-

# 6. Maintenance

## 6.1 Handling system faults

Fault	What it means	Possible Solution
1-WAY	The control panel cannot configure or control the device. Battery consumption increases.	<ul style="list-style-type: none"> <li>• Make sure the device is physically present.</li> <li>• Check the display for device faults, for example, low battery.</li> <li>• Use RF diagnostics to check the current signal strength and during the last 24 hours.</li> <li>• Open the device cover and replace the battery or press the tamper switch.</li> <li>• Install the device in a different location.</li> <li>• Replace the device.</li> </ul>
AC FAILURE	There is no power to gas sensor	Make sure that the AC power supply is connected properly
AC SUPPLY FAILURE	There is no power and the system is working on backup battery power	Make sure that the AC power supply is connected properly
CLEAN ME	The fire detector must be cleaned	Use a vacuum cleaner to clean the detector air vents occasionally to keep them free of dust.
COMM. FAILURE	A message could not be sent to the monitoring station or to a private telephone (or a message was sent but was not acknowledged)	<ul style="list-style-type: none"> <li>• Check telephone cable connection</li> <li>• Check that correct telephone number has been dialed.</li> <li>• Dial Monitoring Station to check whether or not events are received.</li> </ul>
CPU LOW BATTERY	The backup battery within the control panel is weak and must be replaced (see section 6.2, Replacing the Backup Battery).	<ul style="list-style-type: none"> <li>• Check for AC power is available in the Panel.</li> <li>• If trouble exists for more than 72 hours, replace the battery pack</li> </ul>
CPU TAMPER OPEN	The control panel was physically tampered with or its cover was opened, or it was removed from wall.	The control panel is not closed properly. Open the control panel and then close it.
GAS TROUBLE	Gas detector failure	Gas detector: Disconnect and then put back the AC power supply connector CO Gas detector: Replace the detector
GSM NET FAIL	The GSM communicator is not able to connect to the cellular network.	<ul style="list-style-type: none"> <li>• Move the Panel and GSM unit to another location.</li> <li>• Enter and exit the Installer Mode menu</li> <li>• Disconnect GSM unit and install it again</li> <li>• Replace SIM card</li> <li>• Replace the GSM unit</li> </ul>
JAMMING	A radio-frequency signal which is blocking communication channel of sensors and control panel is detected.	Locate the source of interference by switching off any wireless devices (cordless telephones, wireless ear plugs, etc.) in the house for 2 minutes then check if trouble continues. Use also RF diagnostics to check signal strength.
LINE FAILURE	There is a problem with the telephone line	<ul style="list-style-type: none"> <li>• Lift the telephone receiver and make sure a telephone line can be heard</li> <li>• Check the telephone connection to the control panel</li> </ul>

LOW BATTERY	The battery in a sensor, keyfob or wireless commander is near the end of its useful life.	<ul style="list-style-type: none"> <li>• For AC powered devices, check AC power is available and connected to the device.</li> <li>• Replace the device battery.</li> </ul>
MISSING	A device or detector has not reported for some time to the control panel.	<ul style="list-style-type: none"> <li>• Make sure the device is physically present.</li> <li>• Check the display for device faults, for example, low battery.</li> <li>• Use RF diagnostics to check the current signal strength and during the last 24 hours.</li> <li>• Replace the battery.</li> <li>• Replace the device.</li> </ul>
NOT NETWORKED	A device was not installed or not installed correctly, or, cannot establish communication with the control panel after installation.	<ul style="list-style-type: none"> <li>• Make sure the device is physically present.</li> <li>• Use RF diagnostics to check the current signal strength and during the last 24 hours.</li> <li>• Open the device cover and replace the battery or press the tamper switch.</li> <li>• Enroll the device again.</li> </ul>
RSSI LOW	The GSM communicator has detected that GSM network signal is weak	Move the Panel and GSM unit to another location.
SIREN AC FAILURE	There is no power to the siren	Make sure that the AC power supply is connected properly
TAMPER OPEN	The sensor has an open tamper	Close sensor tamper
TROUBLE	The sensor reports trouble	Replace the sensor
SOAK TEST FAIL	Detector alarms when in Soak Test mode	<p>If you wish to continue the Soak Test, no further action should be taken.</p> <p>If you wish to abort the Soak Test, disable the Soak Test (see section 4.4.6).</p>

## 6.2 Replacing the backup battery

Replacement and first-time insertion of battery pack is similar, see Figure 3.2.

Separate the panel from the base, see section 3.2 *Installing the WP8360 battery and cables* for details. After inserting the new battery pack correctly, return the panel to the base and place the screw in the locked position. The TROUBLE indicator is extinguished. However, the MEMORY message will now blink in the Virtual Keypad display. This message is caused by the tamper alarm that is triggered when you remove the panel from the base. Clear the message by arming the system and immediately disarming the system.

## 6.3 Replacing and relocating detectors

Whenever maintenance work involves replacement or re-location of detectors, always perform a **full diagnostic test according to section 4.8**.

**Remember!** A poor signal is not acceptable.

## 6.4 Annual system check

**Note:** *The WP8360 system must be checked by a qualified technician at least once every three (3) years (preferably every year).*

The annual system check is designed to ensure proper operation of the alarm system by performing the following checks:

- Periodic test
- Arm/disarm function
- No trouble messages are displayed on the Virtual Keypad
- The clock displays the correct time
- Reporting: generating an event to be transmitted to the Monitoring Station and to the user.

# 7. Reading the event log

Up to 100 events are stored in the event log. You can access this log and review the events, one by one. If the event log fills up completely, the oldest event is deleted upon registration of each new event. The date and time of occurrence are memorized for each event.

**Note:** Up to 1000 events are stored in the event log that can be reviewed via the Configurator software or AlarmInstall app.

When reading the event log, events are shown in chronological order – from the newest to the oldest. Access to the event log is provided by clicking the button and not through the Installer Mode menu. The reading and erasing process of the event log is shown below.

Step 1	Step 2	Step 3	Step 4
In normal operating mode [1]	Enter Installer Code [2]	Reviewing Events [3]	Scroll List of Events [4]
READY 00:00	ENTER CODE: █ ↓ LIST OF EVENTS	Z13 alarm 09/02/11 3:37 P	SR2 TAMPER-ALARM 07/02/11 11:49 a
CLEAR EVENT LOG display [5]	Erase the Event Log [6]	Event Log is erased [7]	Returns to normal operating mode [8]
CLEAR EVENT LOG		<OFF> to delete	<OK> TO EXIT

① **① - Reading Events**

[1] While the system is in the normal operating mode, press the key.

**Reading the Event Log**

[2] Enter the current Installer Code and then press to enter **LIST OF EVENTS**.

[3] The latest event is shown.  
The event is displayed in two parts, for example, **Z13 alarm** then **09/02/10 3:37 P**.  
**Note:** In Soak Test mode, the panel displays the alarmed zone and alternates with **Zxx:Soak T.Fail**.

[4] Press repeatedly to scroll through the list of events.

**Erasing and Exiting the Event Log:**

[5] From anywhere within the event log, press the button and then press .

[6] At this stage in the procedure, clicking the or buttons will take you to **<OK> TO EXIT** without erasing the event log. Clicking the button will revert to **CLEAR EVENT LOG**.  
Press the button to erase the event log.

[7] The system erases the event log

[8] Press to revert to normal operating mode.

---

Clicking the button repeatedly at any stage in the procedure takes you one level up with each click.  
Clicking the button will take you to **<OK> TO EXIT**.

# APPENDIX A. Working with the AlarmInstall Application

The AlarmInstall mobile application is used by installers to configure the WP8360 security system and provides an easy-to-use Virtual or Touch Keypad that allows you to fully control the panel configurations.

## Installing the AlarmInstall application

**Note:** The AlarmInstall App can be installed on Apple or Android devices.

1. Download and install the application from Apple App Store or Google Play App.
2. Click the AlarmInstall application icon to open the Welcome screen on the mobile device.
3. Connect to the panel using one of the following methods:
  - a) For Android devices only. Insert the micro-USB connector of the OTG cable into the micro-USB port on your Android device. Insert the micro-USB connector cable into the micro-USB port on the panel.
  - b) Connect the mobile device to WP8360 Wi-Fi access point using direct or remote mode.

**Remote mode:** The installer can connect to the panel and control it remotely without travelling to the premises of the user. Both the panel and the mobile device connect to a server over a wide area network (WAN).

**Direct mode:** The mobile device connects directly to the panel by local Wi-Fi or a USB cable. The installer must travel on-site to the user's premises.

4. Add one or more panels. For more information, see [Adding a panel](#).

## Connecting to a panel with Wi-Fi in direct mode

**Pre-requisite:** From the label placed on the back of the label, extract the panel ID (Panel ID: XXXXXX) and the serial number (S/N: XXXXXXXXXXX).

1. Ensure that Access Point mode is enabled and Access Point is activated. See point 4.6.8 for more details.
2. Open the AlarmInstall app and on the connect screen, tap **Direct**.
3. In your mobile device Wi-Fi setting, select the panel Wi-Fi ID that matches the Panel ID.
4. If the panel Wi-Fi ID does not display, simultaneously press the +/- buttons on the back of the panel to activate Wi-Fi on the panel.
5. In the AlarmInstall app, enter the panel ID number as the panel ID and the serial number as the password.
6. Tap **CONNECT**.
7. Enter your configuration code and tap **LOGIN**.
8. Enter the default installer code: 9999.

## Connecting to a panel using remote mode

**Note:** You can only use remote mode after the initial programming and connection to the server is established.


**Important:** If you connect with remote mode, authenticate your device with two factor authentication. If you have already completed two factor authentication, to login, enter your email address and password.

1. Open the AlarmInstall app and on the connect screen, tap **Remote**. If you already enabled 'Keep me signed in', or enabled a biometric log on, you must first log out of the server. In the panels list, tap the menu icon, then tap **Log out**.
2. Enter your email address and password.
3. Tap **LOGIN**.

## Adding a panel

You can only add panels to the AlarmInstall app if the panel is connected to the server.

1. Tap the plus button on the screen.
2. Optional: If the server is upgraded to PowerManage 4.6, tap RESTORE to restore the panels you added previously.
3. Enter the required information in the following fields:
  - Panel name: Enter a recognizable panel name that appears in the app only.
  - Panel serial: Enter the panel ID. The six digit ID is on the label on the back of the panel.
  - Installer code: Enter the installer code.



4. Tap CONNECT. The panel appears in the panels list.

**Note:** If you enter incorrect information or if the panel does not connect to the server after three logon attempts, the following message displays: User is temporarily blocked. The application is blocked for 300 seconds. After 300 seconds, you can try to add the panel again.

## Panel icons and keys







Icons show the status of the WP8360. Use the control keys to move through the menu items of the panel and the arming keys to arm or disarm the system. Other keys are designated for certain tasks for example to review event logs.

### Icons




Alarm Install Icons	Configurator LED	Function
		Power
		Armed away – LED lights steadily. Armed home – LED blinks
		Trouble
		Active service to the server
		Smart home service
		Wi-Fi connection

Use the control keys to move through the menu items of the panel and the arming keys to arm or disarm the system. Other keys are designated for certain tasks for example to review event logs.




### Control keys

Key	Function
	<b>OFF:</b> Delete a device
	<b>NEXT:</b> Advance from item to item within a given menu.
	<b>BACK:</b> Move one step back within a given menu.
	<b>UP:</b> Use to move one level up in the menu or to return to previous setting step.
	<b>OK:</b> Review status messages one by one and also selects a displayed option.
	<b>ESC:</b> Cancel operation.

### Arming Keys

Key	Function
	<b>AWAY:</b> Arming when nobody is at home
	<b>HOME:</b> Arming when people remain at home.
<b>0</b>	<b>INSTANT:</b> Canceling the entry delay upon arming (AWAY or HOME)
	<b>DISARM / OFF:</b> Disarming the system and stopping alarms

### Other Keys

Key	Function
<b>8</b>	Chime ON/OFF
<b>*</b>	Reviewing the event log
	Emergency
	Fire
	Panic

**Note:** The above buttons are identical in function to the corresponding buttons shown throughout the document.

# APPENDIX C. Specifications

## C1. Functional

<b>Zones Number</b>	64 wireless zones
<b>Installer and User Codes</b>	<ul style="list-style-type: none"> <li>• 1 master installer (9999 by default)*</li> <li>• 1 installer (8888 by default)*</li> <li>• 1 master user, no. 1 (1111 by default)</li> <li>• Users nos. 2 – 48</li> <li>• Latchkey users 5 - 8</li> </ul> <p>* Codes must not be identical</p>
<b>Control Facilities</b>	Virtual keypad, wireless keyfobs and keypads
<b>Arming Modes</b>	AWAY, HOME, AWAY-INSTANT, HOME-INSTANT, FORCED, BYPASS.
<b>Alarm Types</b>	Silent, personal panic/emergency, burglary, gas (CO), and fire.
<b>External Siren (bell) Timeout</b>	Programmable (4 min. by default)
<b>Supervision</b>	Programmable time frame for inactivity alert
<b>Special Functions</b>	<ul style="list-style-type: none"> <li>- Chime zones</li> <li>- Diagnostic test and event log.</li> <li>- Local and Remote Programming over Broadband and GPRS IP connections.</li> <li>- Calling for help by using an emergency transmitter.</li> <li>- Tracking inactivity of people.</li> </ul>
<b>Data Retrieval</b>	Alarm memory, trouble, event log
<b>Real Time Clock (RTC)</b>	The control panel keeps and displays time and date. This feature is also used for the log file by providing the date and time of each event
<b>Battery Test</b>	Once every 10 seconds
<b>PowerG Receiver Range</b>	160 ft. (50 m) internal, 6500 ft. (2000 m) external
<b>Connectors</b>	<p><b>External:</b></p> <ul style="list-style-type: none"> <li>• DC Power Jack</li> <li>• RJ-45 Ethernet Connector</li> <li>• Micro USB Connector</li> </ul> <p><b>Internal:</b></p> <ul style="list-style-type: none"> <li>• SIM Card Slot (part of GPRS Module)</li> <li>• Micro SD Card Slot</li> <li>• Battery Backup Connector</li> </ul>

## C2. Wireless

<b>RF Network</b>	PowerG – 2-way synchronized Frequency Hopping (TDMA / FHSS)		
<b>Frequency bands (MHz)</b>	433 – 434	868 - 869	912 – 919
<b>Hopping frequencies</b>	8	4	50
<b>Region</b>	Worldwide	Europe	North America and selected countries
<b>Encryption</b>	AES-128		
<b>Maximum Tx Power</b>	868.20-869.05 MHz: 14MW (PG2) 868.7MHz – 869.2MHz: 14MW(PG2) 880.2-914.8: 1356MW(WCDMA) 1710-1784MHz : 1000MW(WCDMA) 2402-2480MHz: 12MW(WIFI) 868.0-868.4: 1.25MW(Z-WAVE)		
<b>GSM (MHz)</b>	2G Band	3G Band	
	850, 900, 1800, 1900	850 <sup>1</sup> , 900 <sup>2</sup> , 1900 <sup>1</sup> , 2100 <sup>2</sup>	
<b>Z-Wave (MHz) (optional)</b>	868.4, 908.4, 921.4		
<b>WiFi - optional</b>	2.4 GHz. Access Point is for IP camera support only		

<sup>1</sup> Covered by Module 2

<sup>2</sup> Covered by Module 1

### C3. Electrical

<b>External AC/DC adaptor</b>	<b>Input:</b> AC 100-240V, 50/60 Hz, 0.4A <b>Output:</b> 5.1V DC 1.96A
<b>Current Drain</b>	Approx. 200 mA standby, 1200 mA peak at full load.
<b>Low Battery Threshold</b>	3.8 V
<b>Backup Battery Pack</b>	3.7 V, 1000 mAh LIPO
<b>Backup Battery Time</b>	4 Hrs
<b>Time to Charge</b>	80 % (~ 2 Hrs)

### C4. Communication

<b>Communication</b>	IP, Ethernet 10/100
<b>Monitoring Station Report</b>	2 via PowerManage on IP and/or GPRS
<b>Private Notifications</b>	4 emails, 4 SMS numbers
<b>Local Management Protocol to Windows PC and Android Mobile</b>	USB
<b>Report Destinations</b>	2 Monitoring Stations, 4 private SMS telephones via the server and 4 emails
<b>Reporting Format Options</b>	SIA, Contact ID, SIA IP

### C5. Physical Properties

<b>Operating Temp. Range</b>	32°F to 120°F (0°C to 49°C)
<b>Storage Temp. Range</b>	50°F to 122°F (10°C to 50°C)
<b>Humidity</b>	93% relative humidity, @ 30°C (86°F)
<b>Size</b>	158x114.5x36.5 mm (6.22x4.5x1.43 in.)
<b>Weight</b>	225g (8 Oz)
<b>Color</b>	White

## C6. Peripherals and Accessory Devices

<b>Modules – factory default (SKU)</b>	<b>Base (default):</b> IP and PowerG <b>GSM:</b> 2G or 3G <b>Wi-Fi:</b> 2.4 GHz <b>Z-Wave:</b> 500 Series
<b>Number of wireless devices</b>	Accommodates more than 120 wireless devices: <ul style="list-style-type: none"> <li>• Up to 64 zones</li> <li>• Up to 15 PIR cameras, 32 keypads, 32 keyfobs, 8 sirens, 4 repeaters</li> </ul>
<b>Wireless Devices and peripherals</b>	<b>Pendants:</b> PGx949, PGx938 <b>Magnetic Contact:</b> PGx945, PGx975, PGx303, PGx312 <b>Motion Detectors:</b> PGx914, PGx974, PGx984, PGx994, PGx924, PGx902, PGx862, PGx872 <b>PIR Camera Detectors:</b> PGx934, PGx944 <b>Note:</b> A maximum of 15 PIR cameras are supported, but the panel will communicate to the PowerManage server only the first 10 clips received from the cameras. <b>Smoke Detector:</b> PGx936 <b>Keyfob:</b> PGx939, PGx929 <b>Keypad:</b> WK241, WK160 <b>Indoor Siren:</b> PGx901 <b>Outdoor Sirens:</b> PGx911 <b>Repeater:</b> PGx920 <b>Gas:</b> PGx913 (CO detector) <b>Glass-break:</b> PGx922 <b>Temperature:</b> PGx905 <b>Flood:</b> PGx985 <b>Shock:</b> PGx935

# APPENDIX D. Working with Partitions

Your alarm system is equipped with an integrated partitioning feature that can divide your alarm system into three distinct areas identified as Partition 1 through 3. A partition can be armed or disarmed regardless of the status of the other partitions within the system. Partitioning can be used in installations where shared security systems are more practical, such as a home office or warehouse building. When partitioned, each zone, each user code and many of your system's features can be assigned to Partition 1 to 3. Each user code is assigned with the list of partitions it is allowed to control in order to limit access of users to certain partitions.

When partitioning is enabled, menu displays are changed to incorporate the partition feature and also each device, user, and proximity tag has additional partitions menu, where it is assigned to certain partitions and excluded from others.

**Note:** When Partition Mode is disabled, all zones, user codes, and features of the control panel will operate as in a regular unit. When partition mode is enabled, all zones, user codes, and features of the control panel are automatically assigned to Partition 1.

## D1. User Interface and Operation

Refer to the control panel User's Guide for a detailed description of the user interface.

## D2. Common Areas

Common areas are areas used as walkthrough zones to areas of 2 or more partitions. There may be more than one common area in an installation depending on the layout of the property. A common area is not the same as a partition; it cannot be armed / disarmed directly. Common areas are created when you assign a zone or zones to 2 or 3 partitions. Table A1 summarizes the behavior of the different zone types in a common area.

**Table A1 – Common Area Definitions**

Common area zone types	Definition
<b>Perimeter</b>	<ul style="list-style-type: none"> <li>Acts as defined only after the last assigned partition is armed AWAY or HOME.</li> <li>In case that one of the partitions is disarmed, an alarm initiated from this zone is ignored for all assigned partitions.</li> </ul>
<b>Delay zones</b>	<ul style="list-style-type: none"> <li>Delay zones will not trigger an entry delay unless all assigned partitions are armed. It is, therefore, not recommended to define delay zones as common areas.</li> </ul>
<b>Perimeter follower</b>	<ul style="list-style-type: none"> <li>Act as defined only after the last assigned partition is armed AWAY or HOME.</li> <li>In case that one of the partitions is disarmed, an alarm initiated from this zone is ignored for all assigned partitions.</li> <li>In case that one of the common area assigned partitions is in a delay state (and the other partitions are armed), the alarm will behave as a perimeter follower for this partition only. The event will be ignored for other assigned armed partitions.</li> </ul>
<b>Interior</b>	<ul style="list-style-type: none"> <li>Acts as defined only after the last assigned partition is armed AWAY.</li> <li>In case that one of the partitions is disarmed or armed HOME, an alarm initiated from this zone is ignored for all assigned partitions.</li> </ul>
<b>Interior follower</b>	<ul style="list-style-type: none"> <li>Acts as defined only after the last assigned partition is armed AWAY.</li> <li>In case that one of the partitions is disarmed or armed HOME, an alarm initiated from this zone is ignored for all assigned partitions.</li> <li>In case that one of the common area assigned partitions is in a delay state (and the other partitions are armed), the alarm will behave as an interior follower for this partition only. The event will be ignored for other assigned armed partitions.</li> </ul>
<b>Home / Delay</b>	<ul style="list-style-type: none"> <li>Acts as a Perimeter-Follower type when all assigned partitions are armed AWAY.</li> <li>Acts as a Delay type when at least one of the assigned partitions is armed HOME.</li> <li>Will be ignored when at least one of the assigned partitions is disarmed.</li> </ul>
<b>Emergency; Fire; Flood; Gas; Temperature; 24-hour silent; 24-hour audible; Non-alarm</b>	<ul style="list-style-type: none"> <li>Always armed.</li> </ul>

**Note:** A Soak Test of Common areas cannot be initiated when one of its partitions is armed. When Soak Test of a Common area is active, an alarm event is ignored unless all the partitions that are assigned to the zone are armed.

# APPENDIX E. Detector Deployment & Transmitter Assignments

## E1. Detector Deployment Plan

Zone No.	Zone Type		Location		Chime (melody Location) or Off (*)	Sensor Type	Holder
	Default	Programmed	Default	Programmed			
1	Exit/Entry 1		Front Door				
2	Inter-Follow		Living Room				
3	Exit/Entry 2		Attic				
4	Perimeter		Back Door				
5	Perimeter		Child Room				
6	Inter-Follow		Office				
7	Inter-Follow		Dining Room				
8	Perimeter		Dining Room				
9	Perimeter		Kitchen				
10	Perimeter		Living Room				
11	Inter-Follow		Living Room				
12	Inter-Follow		Bedroom				
13	Perimeter		Bedroom				
14	Perimeter		Guest Room				
15	Inter-Follow		Master Bedroom				
16	Perimeter		Master Bedroom				

**Zone Types:** 1 = Exit / Entry 1 \* 2 = Exit / Entry 2 \* 3 = Home Delay \* 4 = Interior Follower \* 5 = Interior \* 6 = Perimeter \* 7 = Perimeter Follower \* 8 = 24hr Silent \* 9 = 24hr Audible \* 10 = Emergency \* 11 = Arming Key \* 12 = Non-Alarm \* 17 = Guard \* 18 = Outdoor.

**Zone Locations:** Note down the intended location for each detector. When programming, you may select one of 31 custom locations – see "02:ZONES/DEVICES" menu).

**Notes:**

All zones are chime off by default. Enter your own choice in the last column and program accordingly.

## E2. Keyfob Transmitter List

Transmitter Data						AUX button Assignments	
No.	Type	Holder	No.	Type	Holder	Skip exit delay or Arming "instant"	
1			17			Indicate the desired function (if any)	
2			18				
3			19				
4			20				
5			21				
6			22				
7			23				
8			24				
9			25				
10			26				
11			27				
12			28				
13			29				
14			30				
15			31				
16			32				

Skip exit delay   
 Arming "instant"

### E3. Emergency Transmitter List

<b>Tx #</b>	<b>Transmitter Type</b>	<b>Enrolled to Zone</b>	<b>Name of holder</b>
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

### E4. Non-Alarm Transmitter List

<b>Tx #</b>	<b>Transmitter Type</b>	<b>Enrolled to Zone</b>	<b>Name of holder</b>	<b>Assignment</b>
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				

# APPENDIX F. Event Codes

## F1. Contact ID Event Codes

Code	Definition
101	Emergency
110	Fire
114	Heat
120	Panic
121	Duress
122	Silent
123	Audible
129	Confirm panic
131	Perimeter
132	Interior
133	24 Hour (Safe)
134	Entry/Exit
137	Tamper/CP
139	Burglary verified
140	General alarm
151	Gas alarm
152	Freezer alert
153	Freeze alert
154	Flood alarm
158	High temperature
159	Low temperature
180	Gas trouble
220	Guard sensor alarmed
301	AC loss
302	Low system battery
311	Battery disconnect
313	Engineer reset
321	Fuse
333	Expansion modem failure
344	RF receiver jam detect

Code	Definition
351	Telco fault
373	Fire detector trouble
374	Exit error alarm (zone)
350	Communication trouble
380	Sensor trouble
381	Inactive event
383	Sensor tamper
384	RF low battery
389	Sensor self-test failure
391	Sensor Watch trouble
393	Fire detector clean me
401	O/C by user
403	Auto arm
406	Cancel
408	Quick arm
412	Successful download/access
426	Door open event
441	Armed home
454	Fail to arm
455	Autoarm failed
456	Partial arm
459	Recent close event
570	Bypass
602	Periodic test report
607	Walk test mode
625	Time/Date change
627	Program mode entry
628	Program mode exit
641	Senior watch trouble

## F2. SIA Event Codes

Code	Definition
AR	AC Restore
AT	AC Trouble
BA	Burglary Alarm
BB	Burglary Bypass
BC	Burglary Cancel
BJ	Burglary Trouble Restore
BR	Burglary Restore
BT	Burglary Trouble / Jamming
BV	Burglary Verified
BX	Burglary test
BZ	Inactive event
CF	Forced Closing
CG	Armed home
CI	Fail to Close
CL	Armed Away
CP	Auto Arm
CR	Recent Close
EA	Door Open
FA	Fire Alarm
FJ	Fire detector trouble
FR	Fire Restore

Code	Definition
LT	Phone Line Trouble
LX	Local Programming Ended
OP	Opening Report
OT	Fail to Arm
PA	Panic Alarm
PR	Panic Restore
QA	Emergency Alarm
RN	Engineer Reset
RP	Automatic Test
RS	Remote Program Success
RX	Manual Test
RY	Exit from Manual Test
TA	Tamper Alarm
TE	Communicator restored to operation
TR	Tamper Restore
TS	Communicator taken out of operation
UJ	Detector mask restore
UT	Detector mask
WA	Flood alarm
WR	Flood alarm restore
XR	Sensor Battery Restore


Code	Definition
FT	Fire Detector Clean
FX	Fire test
GA	Gas alarm
GJ	Gas trouble restore
GR	Gas alarm restore
GT	Gas trouble
GX	Gas test
HA	Holdup Alarm (duress)
JT	Time Changed
KA	Heat alarm
KH	Heat alarm restore
KJ	Heat trouble restore
KT	Heat trouble
LB	Local Program
LR	Phone Line Restore

Code	Definition
XT	Sensor Battery Trouble
YA	Fuse Fault
YH	Bell Restored
YI	Overcurrent Trouble
YM	System battery disconnect
YR	System Battery Restore
YT	System Battery Trouble / Disconnection
YX	Service Required
YZ	Service Completed
ZA	Freeze alert
ZH	Freeze alert restore
ZJ	Freezer alert restore
ZT	Freezer alert

### F3. Understanding the Scancom Reporting Protocol Data Format

The SCANCOM data format consists of 13 decimal digits divided into 4 groups, from left to right, as shown on the right. Each channel is associated with a specific event as follows:

- 1<sup>st</sup> "C": Fire
- 2<sup>nd</sup> "C": Personal attack
- 3<sup>rd</sup> "C": Intruder
- 4<sup>th</sup> "C": Open/close
- 5<sup>th</sup> "C": Alarm cancel
- 6<sup>th</sup> "C": Emergency
- 7<sup>th</sup> "C": Second alarm
- 8<sup>th</sup> "C": Trouble messages



### F4. SIA over IP - Offset for Device User

Type	Number Range In decimal	Example	Remarks
System reports	00	System tamper would report as 000	
Normal Zones/Detectors	1-499	Zone 5 would report as 005	
Keyfobs / Users /Tags	501-649	Keyfob/User number 101 would report 601	
Pendants	651-699	Pendant number 1 would report 651	
Keypads/ASU	701-799	Keypad number 8 would report 708	
Sirens	801-825	Siren number 9 would report 809	
Repeaters	831-850	Repeater number 4 would report 834	
Expanders/Bus devices	851-875	Device number 2 would report 852	
Troubles for:			
GSM	876	GSM module network fail 876	
BBA	877	BBA bus trouble 877	
Plink	878		
Guard	879		
	901- 999		For future use

# APPENDIX G. Sabbath mode

## G1. General guidance

The Sabbath Mode allows you to use the alarm system without violating the Sabbath. The basic feature of this alarm system is that the PIR sensors are not activated during Disarm mode.

The method of installation, as illustrated in the drawing below, is used in order to prevent transmission from the magnetic contact device. The PGX945 device is used only as a transmitting device to report the status of the door to the control panel. A wired magnetic contact is connected to the input of the PGX945 device and an open/close switch is connected in parallel to the PGX945 input.


**Note:** Before the Sabbath, closing the circuit neutralizes the detector's magnet. You can use the front door without violating the Sabbath. On the Sabbath day itself, you can open the switch to allow the door to be protected. This operation is permitted on the Sabbath and also when the control panel is armed.

## G2. Connection

1. Enroll an PGX945 to the WP8360 control panel (see section 4.4.2).
2. Configure the "Input #1" setting option of the PGX945 to "Normally Closed" (refer to the PGX945 Installation Instructions, section 2.3).
3. Connect to the PGX945 a wired magnetic contact to be installed on the door and that is operated by opening/closing the door (see drawing below).
4. An open/close switch must be connected in parallel to the input of the PGX945.

### Wiring Setup

- A. PGX945 device
- B. Wired magnetic contact
- C. Fixed frame
- D. Moving part
- E. Open/close switch
  - E1. Closed
  - E2. Open



## G3. Arming the system by Sabbath clock

1. Enroll an PGX945 to the WP8360 control panel (see section 4.4.2).
2. Configure the Zone Type to "11.Arming Key" (see section 4.4.2)
3. Configure the "Input #1" setting option of the PGX945 to "Normally Open" (refer to the PGX945 Installation Instructions, section 2.3).
4. From the "03:CONTROL PANEL" menu, configure the "09:ARMING KEY" setting option to "arm HOME" (see section 4.5.2).

**Note:** When the alarm system is armed at night by a Sabbath clock, the open / close switch must be opened when the door is closed.

# APPENDIX H. Glossary

**Abort Period:** When an alarm is initiated, the internal sounder is activated first for a limited period of time which is the abort period set by the installer. If you cause an alarm accidentally, you can disarm the system within the abort period before the real sirens start and before the alarm is reported to the *remote responders*.

**Alarm:** There are 2 kinds of alarms:

Loud alarm – the external siren blares out constantly and the control panel reports the event.

Silent alarm – the sirens remain silent, but the control panel reports the event.

A state of alarm is caused by:

- Motion detected by a *motion detector* (when the system is in the Armed state)
- Change of state detected by a *magnetic contact detector* – a closed window or door is opened
- Detection of smoke by a *smoke detector*, detection of gas by a *gas detector* and detection of water based fluids by a *flood detector* (when in any state).
- *Tampering* with any one of the detectors

**Arming:** Arming the alarm system is an action that prepares it to sound an alarm if a zone is “violated” by motion, or by opening a door or window. The control panel may be armed in various modes (see *AWAY*, *HOME*, *INSTANT* and *LATCHKEY*).

**Assigned:** Refers to zones.

**Associated:** Refers to devices.

**AWAY:** This type of arming is used when the protected site is vacated entirely. All zones, *interior* and *perimeter* alike, are protected.

**Chime Zones:** Allow you to keep track of activity in the protected area while the alarm system is in the disarmed state. Whenever a chime zone is “opened”, the buzzer beeps twice via the Configuration device (PC or mobile). The buzzer does not beep, however, upon closing the zone (return to normal). Residences can use this feature to announce visitors or look after children. Businesses can use it to signal when customers enter the premises or when personnel enter restricted areas.

**Note:** *Your installer will never designate a 24-hour zone or a fire zone as a chime zone, because both zone types actuate an alarm if disturbed while the system is in the disarmed state.*

Although one zone or more are designated as chime zones, you can still enable or disable the chime function.

**Communicators:** Refers to communication channel, for example, GSM.

**Control Panel:** The control panel is a cabinet that incorporates the electronic circuitry and microprocessor that control the alarm system. It collects information from various sensors, processes it and responds in various ways. It also includes the user-interface – control keys, numerical keypad, display, sounder and loudspeaker.

**Default Settings:** Settings that are applicable to a specific device group.

**Detector:** The device (apparatus) that sends an alarm, that communicates with the control panel (for example, PGx914 is a motion detector; PGx936 is a smoke detector).

**Disarming:** The opposite of arming - an action that restores the control panel to the normal standby state. In this state, only *fire* and *24-hour zones* will sound an alarm if violated, but a *“panic alarm”* may also be initiated.

**Disturbed Zone:** A zone in a state of alarm (this may be caused by an open window or door or by motion in the field of view of a motion detector). A disturbed zone is considered “not secured”.

**Forced Arming:** When any one of the system zones is *disturbed* (open), the alarm system cannot be armed. One way to solve this problem is to find and eliminate the cause for zone disturbance (closing doors and windows). Another way to deal with this is to impose **forced arming** - automatic de-activation of zones that are still *disturbed* upon termination of the exit delay. Bypassed zones will not be protected throughout the arming period. Even if restored to normal (closed), bypassed zones will remain unprotected until the system is disarmed. Permission to “force arm” is given or denied by the installer while programming the system.

**HOME:** This type of arming is used when people are present within the protected site. A classic example is night-time at home, when the family is about to retire to bed. With HOME arming, perimeter zones are protected but interior zones are not. Consequently, motion within interior zones will be ignored by the control panel, but disturbance of a perimeter zone will cause an alarm.

**Instant:** You can arm the system AWAY-INSTANT or HOME-INSTANT, thereby canceling the entry delay for all delay zones for the duration of one arming period.

For example, you may arm the control panel in the HOME-INSTANT mode and remain within the protected area. Only perimeter protection is active, and if you do not expect somebody to drop in while the system is armed, alarm upon entry via the main door is an advantage.

To disarm the system without causing an alarm, use your control keypad (which is normally accessible without disturbing a perimeter zone) or use a keyfob transmitter.

**Latchkey:** The Latchkey mode is a special arming mode in which designated “latchkey users” will trigger a “latchkey message” to be sent to a telephone when they disarm the system.

For example, if a parent wants to be sure that their child has returned from school and disarmed the system. Latchkey arming is only possible when the system is armed in the AWAY mode.

**Location:** Assigning a named location to a device (for example, Garage, Front Door etc.)

**Magnetic Contact Detector, Wireless:** A Magnet- controlled switch and a wireless PowerG transmitter in a shared housing. The detector is mounted on doors and windows to detect changes in state (from closed to open and vice versa). Upon sensing that a door or window is open, the detector transmits its unique identification code accompanied by an “alarm” signal and various other status signals to the control panel.

The control panel, if not armed at that time, will consider the alarm system as “not ready for arming” until it receives a “restored” signal from the same detector.

**Motion Detector, Wireless:** A passive Infrared motion sensor and a wireless PowerG transmitter in a shared housing. Upon sensing motion, the detector transmits its unique identification code, accompanied by an alarm signal and various other status signals to the control panel. After transmission, it stands by to sense further motion.

**Non-Alarm Zone:** Your installer can designate a zone for roles other than alarm. For instance, a motion detector installed in a dark stairway may be used to switch on lights automatically when someone crosses the dark area. Another example is a wireless transmitter linked to a zone that controls a gate opening mechanism.

**Quick Arming:** Arming without a user code. The control panel does not request your user code when you press one of the arming buttons. Permission to use this arming method is given or denied by the installer while programming the system.

**Remote Responder:** A responder can be either a professional service provider to which the home or business owner subscribes (a *Monitoring Station*) or a family relation/friend who agrees to look after the protected site during absence of its occupants. The *control panel* reports events by telephone to both kinds of responders.

**Restore:** When a detector reverts from the state of alarm to the normal standby state, it is said to have been “restored”. A *motion detector* restores automatically after detection of movement, and becomes ready to detect again. This kind of “restore” is not reported to the remote *responders*.

A *magnetic contact detector* restores only upon closure of the protected door or window. This kind of “restore” is reported to the remote *responders*.

**Sensor:** The sensing element – pyroelectric sensor, photo-diode, microphone, smoke optical sensor, etc.

**Signal Strength:** The quality link communication between the system components and the control panel.

**Smoke Detector, Wireless:** A regular smoke detector and a wireless PowerG transmitter in a shared housing. Upon detection of smoke, the detector transmits its unique identification code accompanied by an alarm signal and various status signals to the *control panel*. Since the smoke detector is linked to a special *fire zone*, a fire alarm is initiated.

**State:** AWAY, HOME, AWAY-INSTANT, HOME-INSTANT, LATCHKEY, FORCED, BYPASS.

**Status:** AC fail, low battery, trouble, etc.

**User Codes:** The WP8360 is designed to obey your commands, provided that they are preceded by a valid security access code.

Unauthorized people do not know this code, so any attempt on their part to *disarm* or defeat the system is bound to fail. Some operations, however, can be carried out without a user code as they do not degrade the security level of the alarm system.

**Virtual Keypad:** Contains the user-interface – control keys, numerical keypad, and display.

**Zone:** A zone is an area within the protected site under supervision of a specific detector. During programming, the installer allows the *control panel* to learn the detector’s identity code and links it to the desired zone. Since the zone is distinguished by number and name, the control panel can report the zone status to the user and register in its memory all the events reported by the zone detector. Instant and delay zones are “on watch” only when the control panel is armed, and other (*24-hour*) zones are “on watch” regardless of whether the system is armed or not.

**Zone Type:** The zone type determines how the system handles alarms and other signals sent from the device.

# APPENDIX I. Compliance with standards

## Compliance with Standards

- European CE Standards: EN 300220, EN 300328, EN 301489, EN 50130-4, EN 62368-1



Hereby, Tyco Safety Products Canada Ltd. declares that the radio equipment type **WP8360** is in compliance with Directive 2014/53/EU.  
The full text of the EU declaration of conformity is available in appendix J.

**WARNING!** Changes or modifications to this unit not expressly approved by the party responsible for compliance (Tyco Safety Products Canada Ltd.) could void the user's authority to operate the equipment.

# APPENDIX I. Declaration of Conformity



CERTIFICATE NUMBER  
**2008001**

## EC DECLARATION OF CONFORMITY

IN ACCORDANCE WITH EN ISO/IEC 17050-1:2004

WE TYCO SAFETY PRODUCTS CANADA LTD.  
OF 3301 LANGSTAFF RD. CONCORD, ONTARIO CANADA L4K 4L2

DECLARE UNDER OUR SOLE RESPONSIBILITY THAT:

EQUIPMENT	<b>SELF-CONTAINED WIRELESS ALARM SYSTEM</b>
MODEL NUMBERS	<b>WP8360</b>
FREQUENCY AND POWER LEVEL:	<b>868.20-869.05 MHz: 14mW (PG2)</b> <b>868.7MHz – 869.2MHz: 14mW (PG2)</b> <b>880.2-914.8: 1356mW (WCDMA)</b> <b>1710-1784MHz : 1000mW (WCDMA)</b> <b>2402-2480MHz: 12mW (WiFi)</b> <b>868.0-868.4: 1.25mW(Z-WAVE)</b>

IN ACCORDANCE WITH THE FOLLOWING DIRECTIVES:


2014/30/EU	THE ELECTROMAGNETIC COMPATIBILITY DIRECTIVE
(EU) 2015/863	THE ROHS DIRECTIVE 2011/65/EU AMENDED
2014/35/EU	THE LOW VOLTAGE DIRECTIVE
2014/53/EU	THE RADIO EQUIPMENT DIRECTIVE

HAS BEEN DESIGNED AND MANUFACTURED TO THE FOLLOWING SPECIFICATIONS:

EN 62368-1: 2014 + A11: 2017  
EN 300 220-1 V3.1.1: 2017  
EN 300 220-2 V3.1.1: 2017  
EN 300 220-2 V3.2.1: 2018  
EN 301 489-3: V2.1.1: 2019, CLASS B,  
EN 301 489-1: V2.2.3: 2019, CLASS B,  
EN 301 489-52: V1.1.0: 2016 (DRAFT), CLASS B,  
EN 301 489-17: V3.2.2: 2019 (DRAFT), CLASS B.  
EN 50130-4: 2011+ A1 (14)  
EN 61000-6-3: 2007 + A1: 2011 + AC: 2012

I HEREBY DECLARE THAT THE EQUIPMENT NAMED ABOVE HAS BEEN DESIGNED TO COMPLY WITH THE RELEVANT SECTIONS OF THE ABOVE REFERENCED SPECIFICATIONS. THE UNIT COMPLIES WITH ALL ESSENTIAL REQUIREMENTS OF THE DIRECTIVES WHEN INSTALLED AND USED AS PER MANUFACTURER'S INSTRUCTIONS.

**CE<sub>20</sub>**



SIGNED BY:

NAME: DAN NITA  
POSITION: APPROVALS MANAGER  
DONE AT VAUGHAN, ONTARIO, CANADA  
UPDATED ON 07/08/2020

# Limited Warranty

Digital Security Controls warrants that for a period of 12 months from the date of purchase, the product shall be free of defects in materials and workmanship under normal use and that in fulfillment of any breach of such warranty, Digital Security Controls shall, at its option, repair or replace the defective equipment upon return of the equipment to its repair depot. This warranty applies only to defects in parts and workmanship and not to damage incurred in shipping or handling, or damage due to causes beyond the control of Digital Security Controls such as lightning, excessive voltage, mechanical shock, water damage, or damage arising out of abuse, alteration or improper application of the equipment.

The foregoing warranty shall apply only to the original buyer, and is and shall be in lieu of any and all other warranties, whether expressed or implied and of all other obligations or liabilities on the part of Digital Security Controls. Digital Security Controls neither assumes responsibility for, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

In no event shall Digital Security Controls be liable for any direct, indirect or consequential damages, loss of anticipated profits, loss of time or any other losses incurred by the buyer in connection with the purchase, installation or operation or failure of this product.

Warning: Digital Security Controls recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

Important Information: Changes or modifications not expressly approved by Digital Security Controls could void the user's authority to operate this equipment.

IMPORTANT - READ CAREFULLY: DSC Software purchased with or without Products and Components is copyrighted and is purchased under the following license terms:

• This End-User License Agreement ("EULA") is a legal agreement between You (the company, individual or entity who acquired the Software and any related Hardware) and Digital Security Controls, a division of Tyco Safety Products Canada Ltd. ("DSC"), the manufacturer of the integrated security systems and the developer of the software and any related products or components ("HARDWARE") which You acquired.

• If the DSC software product ("SOFTWARE PRODUCT" or "SOFTWARE") is intended to be accompanied by HARDWARE, and is NOT accompanied by new HARDWARE, You may not use, copy or install the SOFTWARE PRODUCT. The SOFTWARE PRODUCT includes computer software, and may include associated media, printed materials, and "online" or electronic documentation.

• Any software provided along with the SOFTWARE PRODUCT that is associated with a separate end-user license agreement is licensed to You under the terms of that license agreement. • By installing, copying, downloading, storing, accessing or otherwise using the SOFTWARE PRODUCT, You agree unconditionally to be bound by the terms of this EULA, even if this EULA is deemed to be a modification of any previous arrangement or contract. If You do not agree to the terms of this EULA, DSC is unwilling to license the SOFTWARE PRODUCT to You, and You have no right to use it.

## LICENSE

The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.

1. GRANT OF LICENSE This EULA grants You the following rights:

(a) Software Installation and Use - For each license You acquire, You may have only one copy of the SOFTWARE PRODUCT installed.

(b) Storage/Network Use - The SOFTWARE PRODUCT may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Device"). In other words, if You have several workstations, You will have to acquire a license for each workstation where the SOFTWARE will be used.

(c) Backup Copy - You may make back-up copies of the SOFTWARE PRODUCT, but You may only have one copy per license installed at any given time. You may use the back-up copy solely for archival purposes. Except as expressly provided in this EULA, You may not otherwise make copies of the SOFTWARE PRODUCT, including the printed materials accompanying the SOFTWARE.

## 2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

(a) Limitations on Reverse Engineering, Decompilation and Disassembly - You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not make any changes or modifications to the Software, without the written permission of an officer of DSC. You may not remove any proprietary notices, marks or labels from the Software Product. You shall institute reasonable measures to ensure compliance with the terms and conditions of this EULA.

(b) Separation of Components - The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE unit.

(c) Single INTEGRATED PRODUCT - If You acquired this SOFTWARE with HARDWARE, then the SOFTWARE PRODUCT is licensed with the HARDWARE as a single integrated product. In this case, the SOFTWARE PRODUCT may only be used with the HARDWARE as set forth in this EULA.

(d) Rental - You may not rent, lease or lend the SOFTWARE PRODUCT. You may not make it available to others or post it on a server or web site.

(e) Software Product Transfer - You may transfer all of Your rights under this EULA only as part of a permanent sale or transfer of the HARDWARE, provided You retain no copies, You transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades and this EULA), and provided the recipient agrees to the terms of this EULA. If the SOFTWARE PRODUCT is an upgrade, any transfer must also include all prior versions of the SOFTWARE PRODUCT.

(f) Termination - Without prejudice to any other rights, DSC may terminate this EULA if You fail to comply with the terms and conditions of this EULA. In such event, You must destroy all copies of the SOFTWARE PRODUCT and all of its component parts.

(g) Trademarks - This EULA does not grant You any rights in connection with any trademarks or service marks of DSC or its suppliers.

## 3. COPYRIGHT

All title and intellectual property rights in and to the SOFTWARE PRODUCT (including but not limited to any images, photographs, and text incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT, are owned by DSC or its suppliers. You may not copy the printed materials accompanying the SOFTWARE PRODUCT. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE PRODUCT are the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants You no rights to use such content. All rights not expressly granted under this EULA are reserved by DSC and its suppliers.

## 4. EXPORT RESTRICTIONS

You agree that You will not export or re-export the SOFTWARE PRODUCT to any country, person, or entity subject to Canadian export restrictions.

## 5. CHOICE OF LAW

This Software License Agreement is governed by the laws of the Province of Ontario, Canada.

## 6. ARBITRATION

All disputes arising in connection with this Agreement shall be determined by final and binding arbitration in accordance with the Arbitration Act, and the parties agree to be bound by the arbitrator's decision. The place of arbitration shall be Toronto, Canada, and the language of the arbitration shall be English.

## 7. LIMITED WARRANTY

(a) NO WARRANTY - DSC PROVIDES THE SOFTWARE "AS IS" WITHOUT WARRANTY. DSC DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE.

(b) CHANGES IN OPERATING ENVIRONMENT - DSC shall not be responsible for problems caused by changes in the operating characteristics of the HARDWARE, or for problems in the interaction of the SOFTWARE PRODUCT with non-DSC-SOFTWARE or HARDWARE PRODUCTS.

(c) LIMITATION OF LIABILITY; WARRANTY REFLECTS ALLOCATION OF RISK - IN ANY EVENT, IF ANY STATUTE IMPLIES WARRANTIES OR CONDITIONS NOT STATED IN THIS LICENSE AGREEMENT, DSC'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU TO LICENSE THE SOFTWARE PRODUCT AND FIVE CANADIAN DOLLARS (CAD\$5.00). BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

(d) DISCLAIMER OF WARRANTIES - THIS WARRANTY CONTAINS THE ENTIRE WARRANTY AND SHALL BE IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF DSC. DSC MAKES NO OTHER WARRANTIES. DSC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON PURPORTING TO ACT ON ITS BEHALF TO MODIFY OR TO CHANGE THIS WARRANTY, NOR TO ASSUME FOR IT ANY OTHER WARRANTY OR LIABILITY CONCERNING THIS SOFTWARE PRODUCT.

(e) EXCLUSIVE REMEDY AND LIMITATION OF WARRANTY - UNDER NO CIRCUMSTANCES SHALL DSC BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF THE SOFTWARE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF SUBSTITUTE OR REPLACEMENT EQUIPMENT, FACILITIES OR SERVICES, DOWN TIME, PURCHASERS TIME, THE CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY.

WARNING: DSC recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this SOFTWARE PRODUCT to fail to perform as expected.

Always ensure you obtain the latest version of the User Guide. Updated versions of this User Guide are available by contacting your distributor.

[www.dsc.com](http://www.dsc.com)

Tech. Support: 1-800-387-3630

EMAIL: [info@dsc.com](mailto:info@dsc.com)

© 2021 Johnson Controls. All rights reserved. JOHNSON CONTROLS, TYCO and DSC are trademarks of Johnson Controls.

WP8360 Installation Guide D-308259 Rev 0 (01/21)



29011011R001



D-308259



# WP8360 Quick user guide

## Arming and disarming the system

Step	Operation	User Actions	Notes	
Optional	1	Press the Partition Selection button and then select a PARTITION (if Partition is enabled) – used to divide the alarm system into three independently controllable areas	#  followed by any combination of , , or	A “protest” beep will be heard when selecting a partition to which no sensors / peripherals were enrolled.
	Optional	2	Arm AWAY - used to arm the system when the protected site is vacated entirely.	+  or enter code
		Arm HOME – used to arm the system when people are present within the protected site.	+  or enter code	
		Disarm (OFF) – used to restore the control panel to the normal standby state	+  or enter code	
		Quick arm AWAY (If Quick Arm is enabled) – used to arm in the AWAY state without a user code		
		Quick arm HOME (If Quick Arm is enabled) – used to arm in the HOME state without a user code		
		Forced arming AWAY (system not ready) – used to arm the alarm system in the AWAY state when any of the system zones is disturbed	+  or enter code to silence the “protest” buzzer	
		Forced arming HOME (system not ready) – used to arm the alarm system in the HOME state when any of the system zones is disturbed	+  or enter code to silence the “protest” buzzer	
Optional	3	INSTANT – used to arm in the Instant mode, without an entry delay.	(After arming HOME/AWAY) 	
		LATCHKEY – used for keyfob transmitters 5 through 8		

**Note:** The factory default master user code is 1111. The code is not required if quick arming has been permitted by the installer. Change the factory default code to a secret code without delay.

### Initiating Alarms

Alarms	Actions	Notes
Emergency alarm	(≈ 2 sec.)	To stop the alarm, press  and then key in your valid user code.
Fire alarm	(≈ 2 sec.)	
Panic alarm	+   (≈ 2 sec.)	

### Preparing to Arm

Before arming, make sure that READY is displayed.

This indicates that all zones are secured and you may arm the system as desired.

If at least one zone is open (disturbed) the display will read:

This indicates that the system is not ready for arming and in most cases that one or more zones are not secured. However, it can also mean that an unresolved condition exists such as certain trouble conditions, jamming etc., depending on system configuration.

To review the open zones click **OK**. The details and location of the first open zone detector (usually an open door or window sensor) will be displayed. To fix the open zone, locate the sensor and secure it (close the door or window) – see "device locator" below. Each click of **OK** will display another open zone or trouble indication. It is highly recommended to fix the open zone(s), thus restoring the system to the state of "ready to arm". If you do not know how to do this, consult your installer.

**Note:** To quit at any stage and to revert to the "READY" display, click **←**.

**Device Locator:** The WP8360 system has a powerful device locator that helps you to identify open or troubled devices indicated on the LCD display. While the LCD displays an open or faulty device, the LED on the respective device flashes indicating "it's me". The "it's me" indication will appear on the device within max. 16 seconds and will last for as long as the LCD displays the device.

### Zone Bypass Scheme

Bypassing permits arming only part of the system and at the same time allowing free movement of people within certain zones when the system is armed. It is also used to temporarily remove from service faulty zones that require repair work or to deactivate a sensor if, for example, you are decorating a room.

You can set the Zone Bypass Scheme i.e. to scroll through the list of registered (enrolled) sensors to your WP8360 system and to Bypass (deactivate) faulty or disturbed sensors (either READY or NOT-READY) or to Clear (reactivate) BYPASSED zones (sensors).

Once you have set a Bypass Scheme you can use the following 3 options:

- Quickly clear a bypassed zone i.e. to reactivate the bypassed zone
- Quickly review the bypassed zones
- Repeat (recall) the last used zone bypassing scheme

For more information refer to the ConnectAlarm User's Guide.

**Notes:**

1. Zones will be bypassed throughout one disarm-arm period only. Disarming the system after arming will suspend the entire bypassing scheme but you can recall and reuse it as described in For more information refer to the ConnectAlarm User's Guide.
2. Fire zones cannot be bypassed.
3. If a SIM card is installed in the panel, the WP8360 displays the GSM signal strength indication, as follows: "GSM RSSI STRONG" / "GSM RSSI GOOD" / "GSM RSSI POOR".  
If a PIR camera is enrolled in the system, the control panel will read "GPRS initialize" to indicate that the modem is undergoing initialization. This message appears at the end of all trouble messages and immediately following the GSM signal strength indication (if a SIM card is installed).

The trouble indications (illuminated TROUBLE indicator and flashing TRBL message) are cleared once you eliminate the cause of trouble. The following table describes the system faults and respective corrective actions.

**If you do not know how to correct a trouble situation, report it to your installer and seek his advice.**

<b>Fault</b>	<b>What it means</b>
<b>GSM NET FAIL</b>	The cellular communicator is not able to connect to the cellular network
<b>COMM. FAILURE</b>	A message could not be sent to the monitoring station or to a private telephone (or a message was sent but was not acknowledged)

4. The WP8360 system allows you to authorize up to 48 people to arm and disarm the system by providing each with a unique 4 digit personal security code (code 0000 is not allowed, minimum number of variations of PIN codes for each user – 10000 for logical keys), and assigning them with different security levels and functionalities. For more information, refer to Chapter 6, section B.4 of the WK250.
5. Up to 1000 events are stored in the event log that can be reviewed via the Configurator software or AlarmInstall app.